


---

## MG ZS/MG ZS Hybrid+



Version 1.0

---

# CONTENTS

---

<b>MG ZS/MG ZS Hybrid+ .....</b>	<b>1</b>
<b>I Instructions Before Using the Vehicle .....</b>	<b>19</b>
<b>Introduction to User's Handbook.....</b>	<b>20</b>
The Owner's Handbook .....	20
Status at Time of Printing .....	20
Warranty and Service .....	20
Symbols Used .....	21
In an Emergency .....	22
<b>Vehicle Identification Information.....</b>	<b>23</b>
Vehicle Identification Markings(Gasoline) .....	23
Vehicle Identification Markings(HEV) .....	23
Vehicle Identification Plate.....	24
<b>Instructions for Use of Hybrid Vehicle* .....</b>	<b>26</b>
Effects of Ambient Temperature .....	26
Instructions for High Voltage Battery Pack Recycling .....	26
Precautions in the Event of an Accident .....	27
High Voltage System.....	28
Crash Outage Control .....	30

<b>2 Brief Introduction to Vehicle Functions .....</b>	<b>31</b>
<b>Instrument Pack .....</b>	<b>32</b>
Instrument Message Display Operation .....	32
Instrument Pack - Type A * .....	33
Instrument Pack - Type B * .....	35
Warning Message .....	37
<b>Warning Lights and Indicators.....</b>	<b>38</b>
<b>Lights and Switches.....</b>	<b>52</b>
Master Lighting Switch.....	52
Headlamp Levelling.....	53
Switching between Main Beam and Dipped Beam Headlamps.....	54
Turn Signal Lamps .....	57
Fog Lamps.....	58
Hazard Warning Lamps .....	58
<b>Wipers and Washers.....</b>	<b>59</b>
Windscreen Wiper and Washer Operation .....	59
Wash and wipe .....	60
Rear Window Wiper and Washer Operation * .....	61
<b>Horn.....</b>	<b>63</b>

# CONTENTS

---

<b>Rearview Mirror</b> .....	<b>64</b>
Exterior Rearview Mirrors .....	64
Interior Rearview Mirror .....	66
<b>Windows</b> .....	<b>67</b>
Power Operated Window Switch .....	67
Window Operation .....	68
<b>Sunroof*</b> .....	<b>70</b>
Instructions .....	70
Sunroof Operation .....	70
<b>Sunvisor</b> .....	<b>75</b>
<b>Interior Lighting</b> .....	<b>76</b>
AUTO ON Function .....	77
<b>Power Socket</b> .....	<b>78</b>
Front Console Power Socket .....	78
Rear Console Power Socket* .....	78
Power Socket of Interior Rearview Mirrors* .....	79
<b>Storage Compartments</b> .....	<b>80</b>
Instructions for Use .....	80

Glove Box.....	80
Storage Box.....	81
Glasses Box* .....	81
<b>Cup Holder.....</b>	<b>83</b>
Centre Console Cup Holder.....	83
<b>3 Preparation for Driving .....</b>	<b>85</b>
<b>Keys.....</b>	<b>86</b>
Overview .....	86
<b>Alarm System .....</b>	<b>89</b>
Power Immobiliser .....	89
Body Anti-theft System .....	89
<b>Alcohol Interlocks* .....</b>	<b>94</b>
<b>Tail Gate .....</b>	<b>95</b>
Tailgate Emergency Open .....	96
<b>Load Carrying.....</b>	<b>98</b>
Loadspace Loading.....	98
Internal Loading.....	99
<b>Towing* .....</b>	<b>100</b>

# CONTENTS

---

<b>Fuel System</b> .....	<b>102</b>
Fuel Requirements.....	102
Fuel Filler .....	103
Refueling.....	103
<b>Steering System Adjustment</b> .....	<b>104</b>
Steering Wheel Position Adjustment.....	104
Electric Power Steering.....	104
Electric Power Steering Module Angle Initialisation .....	105
Steering Wheel Heating* .....	105
<b>4 Driving the Vehicle</b> .....	<b>107</b>
<b>Power Start/Stop</b> .....	<b>108</b>
Starting the Power System (Key Start)* .....	108
Starting the Power System(Keyless Start)* .....	109
Start the Power System.....	111
Stopping the Power System.....	113
<b>Electric Drive Transmission*</b> .....	<b>114</b>
Gear Shift Control.....	114
Protection Mode.....	115

<b>Manual Transmission *</b> .....	<b>116</b>
Gear Shift Indications.....	117
<b>Continuously Variable Automatic Transmission (CVT) *</b> .....	<b>118</b>
Instructions for Use .....	118
Gear Shift.....	119
Protection Mode.....	122
<b>Drive Mode *</b> .....	<b>124</b>
<b>Parking Brake</b> .....	<b>126</b>
Parking Brake System - Electronic Parking Brake (EPB ) * .....	126
Parking Brake System - Manual Parking Brake * .....	128
<b>Service Brake</b> .....	<b>129</b>
<b>Energy Regeneration *</b> .....	<b>131</b>
<b>Start-Stop Intelligent Fuel Saving System *</b> .....	<b>132</b>
Automatic Shutdown of Engine.....	132
Automatic Engine Start .....	134
Battery.....	135
Start-Stop Intelligent Fuel Saving System Failure.....	135
Starter Inoperative, Serious Battery Capacity Loss.....	135

# CONTENTS

---

<b>Economical and Environmental Driving .....</b>	<b>137</b>
Running-in.....	137
Environmental Protection .....	137
Economical Driving and Maintenance .....	137
Driving in Special Environment.....	139
<b>5 Safety.....</b>	<b>141</b>
<b>Seat Belt.....</b>	<b>142</b>
Protection Provided by Seat Belts .....	143
Wearing Seat Belts.....	144
Children and Seat Belts .....	147
Seat Belt Pre-tensioners.....	149
Seat Belt Checks, Maintenance and Replacement.....	150
<b>Airbag .....</b>	<b>153</b>
Overview .....	153
Airbag Deployment .....	154
Conditions in Which Airbags Will Not Deploy .....	159
Service and Replacement of Airbags.....	163
<b>Child Restraints .....</b>	<b>166</b>



Important Safety Instructions about Using Child Restraints .....	166
Fixing Child Restraints.....	169
Child Restraint Groups and Installation Position .....	172
<b>Child Proof Locks .....</b>	<b>178</b>
<b>Body Stability Control System.....</b>	<b>179</b>
Resuming the body stability control system.....	180
<b>Anti-lock Brake System (ABS) .....</b>	<b>181</b>
<b>Auxiliary Brake System .....</b>	<b>183</b>
<b>Auto Hold* .....</b>	<b>184</b>
<b>Hill Hold Control (HHC).....</b>	<b>186</b>
<b>Hill Descent Control (HDC) .....</b>	<b>187</b>
<b>Active Rollover Protection (ARP) .....</b>	<b>190</b>
<b>Emergency Braking Hazard Warning Strobe (HAZ)* .....</b>	<b>191</b>
<b>Multi-Collision Brake System (MCB)* .....</b>	<b>192</b>
<b>Pedestrian Alert System* .....</b>	<b>193</b>
<b>Tyre Pressure Monitoring System (TPMS)* .....</b>	<b>194</b>
<b>6 Comfort Systems .....</b>	<b>197</b>

# CONTENTS

---

<b>Seat Adjustment</b> .....	<b>198</b>
Front Seats .....	198
Rear Seats .....	200
Head Restraint Operation .....	200
<b>Ventilation System</b> .....	<b>202</b>
A/C Filter Element.....	203
Vents .....	203
<b>A/C Control Panel-1</b> * .....	<b>205</b>
<b>A/C Control Panel-2</b> * .....	<b>206</b>
Shortcut Key of A/C On/Off.....	206
Defrost/Demist Button .....	206
Heated Rear Window Button.....	206
<b>A/C Control Interface</b> .....	<b>208</b>
System On/Off.....	208
AUTO A/C mode* .....	208
Heat Pump Heating On/Off.....	208
Air Distribution Mode.....	208
Air Recirculation Mode .....	209
Defrost/Demist Mode* .....	209

A/C Settings*	210
Blower Speed Control	210
Temperature Control	210
<b>Radio*</b>	<b>211</b>
MOGI Screen	211
Steering Wheel Entertainment Control Buttons	211
Notes On Playing Storage Media Mode For USB Music	212
USB Storage Device	213
Bluetooth Pairing and Connection	213
<b>Intelligent Display Interface*</b>	<b>214</b>
Steering Wheel Entertainment Control Buttons	214
Basic Operations	215
Main System Interface	215
Bluetooth Pairing and Connection	216
Vehicle-Mobile Phone Interconnection	217
<b>7 Intelligent Driver Assistance</b>	<b>219</b>
<b>Constant Speed Cruise Control*</b>	<b>220</b>
<b>Instructions for Intelligent Driver Assistance</b>	<b>224</b>

# CONTENTS

---

Disclaimers for Intelligent Driver Assistance Function.....	224
<b>Camera and Radar .....</b>	<b>226</b>
Driver Assistance Camera.....	226
Driver Assistance Radar.....	228
<b>Adaptive Cruise Control (ACC) * .....</b>	<b>230</b>
Adaptive Cruise Activation.....	230
Adaptive Cruise Target Following Distance Adjustment.....	232
Adaptive Cruise Control Target Speed Adjustment.....	232
Adaptive Cruise Control Pause.....	233
Automatic Deactivation of Adaptive Cruise Control .....	233
Adaptive Cruise Override .....	234
Adaptive Cruise Resume.....	234
Clearing Target Speed Memory.....	234
Special Driving Environments.....	235
<b>Intelligent Cruise Assit (ICA) * .....</b>	<b>238</b>
<b>Intelligent Overspeed Warning * .....</b>	<b>241</b>
<b>Speed Limit Assistance System * .....</b>	<b>243</b>
Speed Limit Assistance System.....	243
<b>Lane Departure Assist .....</b>	<b>247</b>

<b>Front Collision Assist (FCA)</b> .....	<b>250</b>
<b>Blind Zone Safety Assit(BSD, LCA)*</b> .....	<b>253</b>
<b>Rear Cross Traffic Alert ( RCTA)*</b> .....	<b>255</b>
<b>Door opening warning (DOW ) *</b> .....	<b>257</b>
<b>Rear Collision Warning ( RCW ) *</b> .....	<b>259</b>
<b>Ultrasonic Sensor Parking Aid*</b> .....	<b>260</b>
<b>Parking Camera *</b> .....	<b>262</b>
<b>360 Around View Monitor System *</b> .....	<b>263</b>
<b>Drive Fatigue Monitoring System *</b> .....	<b>264</b>
<b>8 Road Emergency Response</b> .....	<b>265</b>
<b>Hazard Warning Devices</b> .....	<b>266</b>
Warning Triangle .....	266
<b>Emergency Starting</b> .....	<b>267</b>
<b>eCall-SOS Emergency Assistance *</b> .....	<b>271</b>
<b>Vehicle Recovery</b> .....	<b>274</b>
Towing Vehicle .....	274
Transporting the Vehicle .....	277

# CONTENTS

---

<b>Tyre Repair*</b> .....	<b>278</b>
Tire repair tool.....	278
Tyre Repair.....	278
<b>Wheel replacement*</b> .....	<b>281</b>
Spare tire and tools.....	281
Wheel Replacement.....	281
<b>9 Maintenance</b> .....	<b>285</b>
<b>Maintenance Instructions</b> .....	<b>286</b>
Regular Maintenance.....	286
<b>High Voltage Battery Pack*</b> .....	<b>290</b>
Precautions and restricted conditions for use of battery .....	290
<b>Bonnet</b> .....	<b>292</b>
Opening the Bonnet.....	292
Closing the Bonnet.....	292
Bonnet Open Alarm* .....	292
<b>Front Compartment</b> .....	<b>294</b>
<b>Engine Oil</b> .....	<b>297</b>
Engine Oil .....	297

Engine Oil Check and Refill.....	298
Engine Oil Specification.....	299
<b>Catalytic Converters and Particulate Filters *</b> .....	<b>300</b>
<b>Cooling System</b> .....	<b>302</b>
Coolant Check and Top Up.....	302
Coolant Specification.....	304
<b>Brake</b> .....	<b>305</b>
Brake Fluid Check and Top Up.....	306
Brake Fluid Specification.....	307
<b>Fuse Replacement</b> .....	<b>308</b>
Fuse.....	308
Passenger Compartment Fuse Box.....	309
Front Compartment Fuse Box.....	311
<b>12V Battery</b> .....	<b>316</b>
Battery Maintenance.....	316
Battery Replacement.....	317
<b>Bulb Replacement</b> .....	<b>318</b>
Bulb Specification.....	318
<b>Bulb Replacement</b> .....	<b>318</b>

# CONTENTS

---

<b>Washer .....</b>	<b>325</b>
Washer Fluid Check and Top Up .....	325
Washer Nozzles .....	326
<b>Wipers .....</b>	<b>327</b>
Wiper Blades .....	327
Windscreen Wiper Blade Replacement .....	328
Rear Window Wiper Blade Replacement .....	329
<b>Replacing the Smart Key Battery .....</b>	<b>330</b>
<b>Tyres .....</b>	<b>333</b>
Overview .....	333
Caring for Your Tyres .....	335
Tyre Wear Indicators .....	336
Wheel Fitment Rotation .....	337
Tyre/Snow Chains .....	338
<b>Cleaning and Caring .....</b>	<b>339</b>
Exterior .....	339
Cleaning the Interior .....	343
<b>10 Technical Data .....</b>	<b>345</b>



# CONTENTS

---

<b>Technical Data Dimensions .....</b>	<b>346</b>
<b>Weights.....</b>	<b>348</b>
Towing Weights.....	349
<b>Main Engine Parameters .....</b>	<b>351</b>
<b>Dynamic Performance Parameters .....</b>	<b>353</b>
<b>Parameters of Drive Motor* .....</b>	<b>354</b>
<b>Recommended Fluids and Capacities .....</b>	<b>355</b>
<b>Wheel Alignment (Unladen Condition) .....</b>	<b>357</b>
<b>Wheels and Tyres .....</b>	<b>358</b>
<b>Tyre Pressure (Cold) .....</b>	<b>359</b>



## ***Instructions Before Using the Vehicle***

---

<i>Introduction to User's Handbook</i>	20
<i>Vehicle Identification Information</i>	23
<i>Instructions for Use of Hybrid Vehicle*</i>	26

# **INSTRUCTIONS BEFORE USING THE VEHICLE**

---

## **Introduction to User's Handbook**

### **The Owner's Handbook**

This Handbook describes all of the vehicles and standard equipment specification within the model range. Some information may be inapplicable to your individual model.

If you have any questions about the operation and parameters of the vehicle, please contact an MG Authorised Repairer will be glad to advise you.

The illustrations in the Owner's Handbook are for reference only.

The information contained in this Handbook may vary slightly depending on the vehicle configuration, software version and sales regions.

### **Status at Time of Printing**

MG operates a policy of constant product improvement and therefore reserves the right to change specifications without notice at any time.

Whilst every effort is made to ensure complete accuracy of the information in this publication, no liabilities for inaccuracies or the consequences thereof, including loss or

damage to property, or injury to persons, can be accepted by the manufacturer or the MG Authorised Repairer who supplied the publication, except in respect of personal injury caused by the negligence of the manufacturer or the MG Authorised Repairer .

### **Warranty and Service**

Please consult the owners section at MG website for the warranty terms and conditions, warranty statement, exemptions and service item renewal schedule.

# INSTRUCTIONS BEFORE USING THE VEHICLE

## Symbols Used

The following symbols used within the handbook call your attention to specific types of information.

## Warning



*This warning symbol identifies procedures that must be followed precisely, or information that must be considered with great care, in order to reduce the risk of personal injury or serious damage to the car.*

## IMPORTANT

IMPORTANT

The statements stated here must be followed strictly, otherwise your car could be damaged.

## Note

*Note: This describes helpful information.*



This symbol indicates parts described must be disposed of by authorised persons or bodies to protect the environment.

## Asterisk

An asterisk (\*) appearing after the title or the text, identifies features or items of equipment that are only fitted to some models, and may not be fitted on the vehicle your purchased.

## Illustration Information



Identifies components being explained.



Identifies movement of components being explained.

# INSTRUCTIONS BEFORE USING THE VEHICLE

---

## In an Emergency

### IMPORTANT

Remember the breakdown safety code


If a breakdown occurs while travelling:

- Wherever possible, consistent with road safety and traffic conditions, the car should be moved off the main thoroughfare, preferably into a lay-by. If a breakdown occurs on a motorway, pull well over to the inside of the hard shoulder.
- Switch on hazard lights.
- If available, position a warning triangle or a flashing amber light 50 to 150 metres (150 to 500 ft) behind your vehicle to warn approaching traffic. Note it is a legal requirement of some countries that a warning triangle is carried in the vehicle, if in doubt consult the local highways agency for further information.
- Consider evacuating passengers through nearside doors onto the verge to reduce risk of injury in the event of collision.


# INSTRUCTIONS BEFORE USING THE VEHICLE

## Vehicle Identification Information

### Vehicle Identification Markings(Gasoline)



### Vehicle Identification Markings(HEV)



- 1 Vehicle Identification Number (VIN)
- 2 Engine Number
- 3 Transmission Number

When communicating with your local Authorised Repairer, always quote the Vehicle Identification Number (VIN) . If the engine or transmission is involved, it may be required to provide the identification numbers of these assemblies.

# INSTRUCTIONS BEFORE USING THE VEHICLE

---

## Location of Vehicle Identification Markings

### *Vehicle Identification Number (VIN) Location*

- On the inner side of hood visible by opening the hood ;
- On the water tank upper crossbeam visible by opening the hood.\* ;
- On the door arrester visible by opening the door.\* ;
- On the floor under the front passenger seat;
- Stamped on a plate visible through the bottom left hand corner of the windscreen;
- On the identification plate;
- On the inner side of the tailgate visible by opening the tailgate.

**Note:** *The DLC is located in the driver footwell above the accelerator pedal. The VIN information can be extracted from the vehicle using the approved diagnostic equipment.*

### *Engine Number Location*

Stamped on the front left of the engine (view from the front of the engine).

### *Transmission Number Location*

On the surface of the transmission housing in the engine compartment or on the surface of the transmission valve body cover. The transmission numbers of certain models are only visible by raising the vehicle, please contact a local Authorised Repairer.


## Vehicle Identification Plate

The Vehicle Identification Label is located at the lower side of right side B pillar. Contains VIN ,engine model and other signals.



# INSTRUCTIONS BEFORE USING THE VEHICLE

---



# INSTRUCTIONS BEFORE USING THE VEHICLE

## Instructions for Use of Hybrid Vehicle\*

### Effects of Ambient Temperature

Extremely high or low temperatures will affect the performance of the high-voltage battery pack and the vehicle. It is recommended that where possible the vehicle should be used within the temperature range of -30°C~55°C . This will ensure that the vehicle is in the optimum working state and help extend the service life of the high-voltage battery pack.

## Instructions for High Voltage Battery Pack Recycling



*If you decide not to use the recommended MG Authorised Repairer to dispose of your high voltage battery, the responsibility of the consequences of environmental pollution or accidents must be borne by the owner.*

The high-voltage battery pack contains several lithium based battery cells. Arbitrary disposal may cause pollution, hazard and damage to the environment. The high-voltage battery pack **MUST** be recycled by an MG Authorised Repairer or a professional approved dismantling agent. Please refer to the following information and requirements.

- **ONLY** qualified personnel should work with the high voltage system - there is danger of **DEATH**.
- High voltage safety: the high-voltage battery pack contains high voltage components such as lithium battery packs and high voltage wiring harness; **DO NOT** attempt to dismantle any area of this system, suitably trained professional staff must observe insulation safety protection before working on or near the high voltage system.

# INSTRUCTIONS BEFORE USING THE VEHICLE

- **Transportation:** The high-voltage battery pack is classed as a Category 9 hazardous material and must be transported by vehicles qualified in transporting Category 9 hazardous materials.
- **Storage:** All HV components (including lithium batteries, PCB, HV/LV harness, metal casing and other components. ) should be stored at room temperature and in a dry environment. They must be kept away from dangerous sources, such as flammable objects, heat and water sources.

It is strongly recommended that the used high-voltage battery pack generated from vehicle scrappage or any other reasons should be disposed of by an MG Authorised Repairer. Please consult an MG Authorised Repairer for more details.

## Precautions in the Event of an Accident



***Ensure the vehicle is in P gear and the vehicle power system/lignition is OFF.***



***If any cables on the vehicle are exposed, in order to prevent electric shock or even death DO NOT make any contact with any cable.***



***If the vehicle catches fire, and the fire is small and slow, a carbon dioxide extinguisher can be used to extinguish the fire, and contact the fire services as soon as possible; if the fire is large and spreading quickly, immediately evacuate the vehicle and contact the fire services immediately.***



***If the vehicle is involved in a collision, it cannot be re-started, the negative cable of 12V battery and Manual Service Disconnect (MSD) MUST be disconnected prior to rescue.***

## INSTRUCTIONS BEFORE USING THE VEHICLE

---



*When the vehicle is completely or partially immersed in water, switch off the vehicle power system and evacuate the car immediately. The negative cable of 12V battery and Manual Service Disconnect (MSD) MUST be disconnected prior to rescue or as soon as the vehicle is refloated/removed from the water. Observe the water/vehicle for any abnormal signs such as excessive bubbles or noises, this may indicate battery short circuit issues. If no signs are evident, there should not be a shock risk from the bodywork and recovery can commence.*



*After the accident is resolved, please contact an MG Authorised Repairer for maintenance.*

### High Voltage System




*All high voltage components have warning labels attached - please observe these warnings and any requirements when operating within or close to these areas.*



*ONLY qualified personnel should work on, or with, the high voltage system - there is danger of DEATH.*

# INSTRUCTIONS BEFORE USING THE VEHICLE

The high voltage system component layout is shown below:



- 1 Manual Service Disconnect (MSD)
- 2 High Voltage Battery (ESS)
- 3 High Voltage Harness
- 4 Electric Drive Transmission
- 5 Electric A/C Compressor

# **INSTRUCTIONS BEFORE USING THE VEHICLE**

---

## **Crash Outage Control**

If a serious collision occurs, a signal from the SDM will disconnect the relays within the High-voltage battery back to cut off the high-voltage output of the high-voltage battery pack.

## Brief Introduction to Vehicle Functions


---

<i>Instrument Pack</i>	32
<i>Warning Lights and Indicators</i>	38
<i>Lights and Switches</i>	52
<i>Wipers and Washers</i>	59
<i>Horn</i>	63
<i>Rearview Mirror</i>	64
<i>Windows</i>	67
<i>Sunroof*</i>	70
<i>Sunvisor</i>	75
<i>Interior Lighting</i>	76
<i>Power Socket</i>	78
<i>Storage Compartments</i>	80
<i>Cup Holder</i>	83

# BRIEF INTRODUCTION TO VEHICLE FUNCTIONS

## Instrument Pack

### Instrument Message Display Operation



#### 1 Infotainment/Instrumentation Switching Button

The Infotainment/Instrumentation Button is a multi-use key. Pressing this button will switch control between the infotainment system and instrument pack.


#### 2 Function Adjustment Button (OK button)

- Push the button up, down, left and right to switch the items displayed in the message centre.
- Push the button up and down to make adjustments.
- Short press the button to confirm, or long press to reset.



# BRIEF INTRODUCTION TO VEHICLE FUNCTIONS

## Instrument Pack - Type A \*




- 1 Speedometer
- 2 Warning Lights and Indicators
- 3 Message Centre
- 4 Tachometer
- 5 Engine Coolant Temperature
- 6 Odometer
- 7 Energy recovery level\*
- 8 Driving mode\*
- 9 Gear Display\*
- 10 Driving Range
- 11 Fuel gauge

# BRIEF INTRODUCTION TO VEHICLE FUNCTIONS

## Message Centre


The message centre provides the followings:



- 1 Active Safety\*  
Display the current active safety information of the vehicle, please refer to the "Intelligent Driving Assistance" chapter for details.
- 2 Health Centre  
Display tire pressure monitoring and warning information, etc.
- 3 My Vehicle  
Display default page, cumulative driving, Energy flow\*, Power information\*, etc.
- 4 Settings  
Settings such as backlight adjustment, speed limit setting.


# BRIEF INTRODUCTION TO VEHICLE FUNCTIONS

## Instrument Pack - Type B \*



- 1 Speedometer
- 2 Message Centre
- 3 Warning Lights and Indicators
- 4 Tachometer
- 5 Engine Coolant Temperature
- 6 Odometer
- 7 Gear Display\*
- 8 Driving Range
- 9 Fuel gauge

## BRIEF INTRODUCTION TO VEHICLE FUNCTIONS




- 1 Speedometer
- 2 Message Centre
- 3 Warning Lights and Indicators
- 4 Tachometer
- 5 Engine Coolant Temperature
- 6 Odometer
- 7 Driving mode
- 8 Energy Recovery Level
- 9 Gear Display
- 10 Driving Range
- 11 Fuel Gauge

# BRIEF INTRODUCTION TO VEHICLE FUNCTIONS

## Message Centre

The message centre provides the followings:



- 1 My Vehicle  
Display current vehicle speed, after self start, after self reset and other information.
- 2 Settings  
Settings such as backlight adjustment, and speed limit setting can be set.
- 3 Multi-media
- 4 Active Safety\*  
Display the current active safety information of the vehicle, please refer to the "Intelligent Driving Assistance" chapter for details.
- 5 Fault information

Display the current vehicle's fault information or important reminder information.

## Warning Message

The message centre in the instrument pack displays any warning messages via a pop-up box. The warning messages are mainly classified into:

- Operation Instructions
- System State Prompts
- System Malfunction Alert





Please follow the text prompts or refer to the relevant control system sections for the failure cause, actions and appropriate solutions.

# BRIEF INTRODUCTION TO VEHICLE FUNCTIONS

## Warning Lights and Indicators






When the vehicle is starting or traveling, if the warning lights or indicators appear in the instrument display, it indicates that the relevant system is in a certain state or is faulty. Some warning lights illuminate or flash with warning tones or prompt message.

Please carefully read the following instructions to understand the meaning of relevant warning lights and indicators. In case of a failure, please take any necessary actions in an appropriate time and contact an MG Authorised Repairer for service as soon as possible.




<b>Name</b>	<b>Icon</b>	<b>Description</b>
Dipped Beam Indicator		The dipped beam headlamp has been switched on.
Main Beam Indicator		The main beam headlamp is on.
Automatic Headlamp Indicator*		The auto headlamp function has been enabled.
Side Lamp Indicator		The side lamps have been switched on.

## BRIEF INTRODUCTION TO VEHICLE FUNCTIONS

2

Rear Fog Lamp Indicator		The rear fog lamps have been switched on.
Direction indicator lamp		<p>When the left or right turn signal lamp flashes, the direction indicator lamp on the corresponding side also flashes. If the hazard warning lamps are turned on, both direction indicator lamps will flash simultaneously.</p> <p>If either direction indicator lamp in the instrument pack flashes very rapidly, it indicates the turn signal lamp on the corresponding side has a failure.</p>
Airbag Warning Lamp		There may be a risk that the SRS system or seat belt(s) may not be able to work properly if an accident occurs.
Seat Belt Unfastened Warning Lamp		If this lamp illuminates or flashes, it indicates that the seat belt for an occupied front or rear seat remains unfastened.
Anti-theft System Warning Lamp		If this lamp illuminates, it indicates that no valid key is detected, in which case please use the correct key, or put the smart key in the alternative starting position. For details, refer to 'Alternative Starting Procedure' in 'Starting and Driving' section.






## BRIEF INTRODUCTION TO VEHICLE FUNCTIONS

<p>Tyre Pressure Monitoring System (TPMS) Warning Lamp*</p>		<p>If this lamp illuminates, it indicates that a tyre pressure is low. Please check the tyre pressure.</p> <p>If this lamp flashes and then remains ON after a period of time, it indicates the system has a fault present.</p>
<p>Electric Power Steering System (EPS) Warning Lamp / Electronic Steering Column Lock (ESCL ) Warning Lamp*</p>		<p>If this lamp is illuminated a fault has been detected within the electric power steering system and the performance of the system will be reduced. Please contact an MG Authorised repairer immediately.</p> <p>If this lamp flashes, it indicates that the electronic steering column lock has a failure, Stop the car as soon as safety permits and turn off the start switch.</p>
		<p>If this lamp is illuminated a fault has been detected within the electric power steering system and the performance of the system will be reduced. Please contact an MG Authorised repairer immediately.</p> <p>If this lamp flashes, it indicates that the electric power steering system has a severe failure,, making it hard to steer. Stop the car as soon as safety permits, power off the vehicle, and contact an MG Authorised Repairer urgently.</p>







## BRIEF INTRODUCTION TO VEHICLE FUNCTIONS






2

<p>Dynamic Stability Control/ Traction Control System Warning Lamp</p>		<p>If this lamp illuminates, it indicates that the dynamic stability control system/traction control system has failed.</p> <p>If this lamp flashes while driving, it indicates that the system is operating to assist the driver.</p>
<p>Dynamic Stability Control/ Traction Control System Warning Lamp</p>		<p>The dynamic stability control/traction control system has been switched off.</p>
<p>AUTO HOLD System Status Indicator Lamp*</p>		<p>The AUTO HOLD system is operating to assist the driver.</p>
		<p>The AUTO HOLD system has a fault.</p>
		<p>The AUTO HOLD system function has been activated to be in the 'Standby' state.</p>








## BRIEF INTRODUCTION TO VEHICLE FUNCTIONS

<p>Electronic Parking Brake (EPB ) System Indicator Lamp*</p>		<p>If this lamp illuminates, it indicates that the EPB is enabled or the handbrake is pulled up.</p> <p>If this lamp flashes, it indicates that the vehicle is parked on a slope with an excessive angle or the electronic parking brake system has failed, in which case please park the vehicle on a suitable safe road.</p> <p>For the manual parking brake, if this lamp illuminates, it indicates that the handbrake is pulled up.</p>
<p>Electronic Parking Brake (EPB ) System Malfunction Indicator Lamp*</p>		<p>It indicates that the EPB system has a fault .</p>
<p>Brake System Malfunction Indicator Lamp</p>		<p>If this lamp illuminates it indicates that the brake system has a fault, please stop the car as soon as safety permits and switch the vehicle off.</p>
<p>ABS Malfunction Indicator Lamp</p>		<p>This indicator will illuminate when a fault is found within the Anti-lock braking system.</p> <p>If an ABS failure occurs while driving, the ABS function will be disabled while normal braking will still be available.</p>

## BRIEF INTRODUCTION TO VEHICLE FUNCTIONS




<p>Low-voltage Battery Charging System Malfunction Indicator Lamp</p>		<p>Low battery voltage will result in this lamp flashing followed by a prompt message appearing in the instrument pack.</p> <p>If this lamp illuminates, it indicates that the battery control system has failed.</p>
<p>System Failure Message Indicator</p>		<p>Illumination of this warning lamp indicates that the vehicle has warning information. Please view the failure message or important prompt message in the message centre. Refer to 'Instrument Pack' in this section.</p>
<p>Adaptive Cruise Control System Indicator Lamp*</p>		<p>The adaptive cruise control system is activated but not in the Standby state.</p>
		<p>The adaptive cruise control system is in Standby state.</p>
		<p>The adaptive cruise control system has been activated.</p>

## BRIEF INTRODUCTION TO VEHICLE FUNCTIONS





Speed Limit Assistance System Indicator Lamp*		Manual speed limit assistance system is in Standby state.
		If this lamp illuminates, it indicates that the manual speed limit assistance system has been activated.  If this lamp flashes, it indicates that current speed is greater than the speed limit value.
		The intelligent speed limit assistance system is in Standby state.
		The intelligent speed limit assistance system is activated.
Constant Speed Cruise Control System Indicator Lamp*		The constant speed cruise control system is in the Standby mode.
		The constant speed cruise control system has been activated.
Cruise/Speed Limit System Malfunction Indicator Lamp		If a fault is detected within the constant speed cruise control system, adaptive cruise control system or speed limit assistance system this lamp will then illuminate.

## BRIEF INTRODUCTION TO VEHICLE FUNCTIONS







2

<p>Engine Coolant Temperature Warning Lamp</p>		<p>When the engine coolant temperature warning lamp illuminates red, it indicates that the coolant temperature is high. High engine coolant temperature could result in severe damage. Please stop the car as soon as safety permits, switch OFF the START/STOP Switch and contact an MG Authorised Repairer immediately.</p> <p>If this lamp flashes, it indicates that the coolant temperature sensor has a fault. Please stop the car as soon as safety permits.</p>
<p>Engine Malfunction Warning Lamp</p>		<p>If this lamp illuminates, it indicates that there are some faults that could seriously affect the engine performance. Please stop the vehicle as soon as safety permits, switch the power OFF and contact an MG Authorised Repairer immediately.</p>
<p>Engine Emissions Malfunction Warning</p>		<p>After the vehicle has been started, the light will illuminate to indicate an engine emission malfunction. Continuing to drive may cause damage to the catalytic converter. It is recommended to stop the vehicle as soon as safety permits and turn off the start switch.</p> <p>After the vehicle is started, The lamp flashes, it indicates a serious engine misfire fault. Please stop the vehicle as soon as possible and turn off the start switch under safe conditions.</p>







## BRIEF INTRODUCTION TO VEHICLE FUNCTIONS

<p>ECO Mode Indicator Lamp*</p>		<p>If this lamp illuminates, it indicates that the vehicle is in energy-saving driving mode.</p>
<p>Particulate Filter Warning Lamp</p>		<p>If this lamp illuminates after the vehicle has been started, or whilst it is being driven, it indicates that the particulate filter needs to be regenerated or is currently being regenerated</p> <p>If this lamp flashes after the vehicle has been started or whilst being driven, it indicates that the particulate filter is full. Seek assistance from an MG Authorised Repairer.</p>
<p>Low Oil Pressure Warning Lamp</p>		<p>If this lamp illuminates after starting the vehicle, it indicates that the oil pressure is too low, which may result in severe engine damage. Please stop the vehicle as soon as safety permits and switch off the engine.</p>
<p>Drive motor malfunction warning light*</p>		<p>When this light illuminates, a malfunction has been detected in the motor system. Please stop the vehicle as soon as possible under safe conditions and seek assistance from an MG Authorised Repairer.</p>

## BRIEF INTRODUCTION TO VEHICLE FUNCTIONS

<p>Speed Limit Sign Speed Indicator Lamp*</p>		<p>' NNN ' indicates the speed limit sign speed that has currently been identified. When the vehicle speed is greater than the speed limit value, the lamp will flash.</p> <p>' — ' indicates the speed limit sign has not been recognized.</p>
<p>Traffic Jam Assist System Indicator Lamp*</p>		<p>Traffic jam assist system is activated and not in Standby state.</p>
		<p>The traffic Jam assist system is in Standby state.</p>
		<p>The traffic Jam assist system is activated.</p>
		<p>The traffic Jam assist system has a fault.</p>
<p>Lane Keeping Assist System Indicator*</p>		<p>If this lamp illuminates, it indicates that the lane keeping assist system has detected a fault or is switched off.</p> <p>If this lamp flashes, it indicates that the lane keeping function is activated.</p>





## BRIEF INTRODUCTION TO VEHICLE FUNCTIONS

Speed Limit Sign Ancillary Information Warning Lamp*		The speed limit sign currently identified has ancillary information. Please check.
		The road speed limit was not recognised and the alert tone is currently off. After a certain period of time, the sound alarm mute icon in the lower left corner will disappear.
		The road speed limit was recognised and the alert tone is currently off. After a certain period of time, the sound alarm mute icon in the lower left corner will disappear.
		Repeat of the above but no mention of the '...' symbol.
		Simultaneous shutdown of overspeed alarm and intelligent speed limit assist system.
		Overspeed alarm fault.








## BRIEF INTRODUCTION TO VEHICLE FUNCTIONS

2




<p>Forward Collision Assist System Indicator Lamp*</p>		<p>When a function regarding the forward collision assist system has been disabled, the following lamp will illuminate. If all functions of the forward collision assist system are enabled and the lamp remains on.</p> <p>When the functions of the forward collision assist system are fully enabled, if the lamp stays on, it indicates that forward collision assist system cannot work properly.</p> <p>If this lamp flashes, it indicates that forward collision function activated.</p>
<p>Rear Driving Assistance System Indicator*</p>		<p>If the rear driving assistance system is turned off, the radar is obscured or the system malfunctions, the instrument panel will display corresponding prompt messages.</p>
<p>Power battery fault*</p>		<p>If this lamp illuminates, it indicates a serious malfunction of the battery system. Please stop the car as soon as safety permits, power off the vehicle, and leave the vehicle immediately. Contact an MG Authorised Repairer at the earliest opportunity.</p>
<p>Driving Power Limited Indicator*</p>		<p>This lamp will illuminate if the vehicle power has been limited.</p>

## BRIEF INTRODUCTION TO VEHICLE FUNCTIONS

<p>Low Fuel Warning Lamp</p>		<p>When the remaining fuel in the tank is too low, the light will light up or flash. Please try to replenish fuel before the low fuel warning light comes on as much as possible.</p> <p>When the fuel in the tank exceeds the low level alert line, this lamp will extinguish. If not, please contact an MG Authorised Repairer for service as soon as possible.</p>
<p>Driver Status Indicator*</p>		<p>The illuminated light indicates that the driver detection system is faulty or unavailable.</p> <p>The flashing light indicates detection of driver fatigue and distraction.</p>
<p>Trailer Warning Lamp*</p>		<p>A trailer lamp has failed.</p>
<p>Start Stop System Status Indication*</p>		<p>This light is constantly on to indicate that the start stop system is activated</p> <p>The flashing light indicates that the start stop system has not met the shutdown conditions.</p>
<p>Start Stop System Fault Warning Lamp*</p>		<p>This light will illuminate constantly to indicate a malfunction has been detected in the start stop function.</p>

## BRIEF INTRODUCTION TO VEHICLE FUNCTIONS


2

eCall SOS Indicator*		The system is ready and an emergency service call (eCall) is in progress.
		The eCall system can send out a vehicle message to the call centre, but other eCall capabilities are limited due to a fault in the system.
		If a fault is found within the ecall system, the following indicator will be displayed.

# BRIEF INTRODUCTION TO VEHICLE FUNCTIONS

## Lights and Switches

### Master Lighting Switch



- 1 AUTO Lamp
- 2 Side Lamp/Switch Backlights
- 3 Headlamp
- 4 AUTO Lamp Off

### AUTO Lamp

The AUTO lighting system is active by default (position 1). The system will automatically switch the side lamps and switch backlights on and off according to the intensity of current ambient light.

**Note:** *This function is acknowledged by a sensor mounted in your vehicle to monitor the exterior light levels in real time. It is installed in the upper part of the dashboard near the windscreen. DO NOT mask or cover this area. Failure to adhere to this may result in the headlamps being turned on unnecessarily.*

### Side Lamp/Switch Backlights

Rotate the master light switch to position 2 to switch on the side lamps/daytime running lamps and switch backlights.

With the vehicle power in the OFF position, the side lamps on and the driver's door is open, an audible alarm will sound.

### Headlamps

Rotate the master light switch to position 3 to switch on the dipped beam headlamps, side lamps and switch backlights.

# BRIEF INTRODUCTION TO VEHICLE FUNCTIONS

2

## Lights Off

Turning the master light switch to position 4 will switch off the 'AUTO' lamp. Releasing the switch will return it to position 1 automatically.

## Daytime Running Lamps

The daytime running lamps turn on automatically when the vehicle power is in the ON/RUNNING position. When the dipped beam is on, the daytime running lamps will extinguish automatically.


## Welcome Light

When the vehicle is unlocked, the system will turn on the dipped beams and side lamps automatically to 'welcome' the driver and assist in locating the vehicle and will work according to the current intensity of the ambient lighting.

## Follow Me Home

After the vehicle power is turned off, pull the light lever towards the steering wheel. The follow me home function will be enabled and the dipped beams and side lamps will illuminate.

## Headlamp Levelling



The headlamp levelling can be adjusted as per the following table according to the vehicle load.


## BRIEF INTRODUCTION TO VEHICLE FUNCTIONS

Location	Load
0	Driver, or driver & front passenger
1	All the seats occupied with no load in the trunk.
2	All the seats occupied plus an evenly distributed load in the trunk.
3	Driver only, plus an evenly distributed load in the trunk.

### Switching between Main Beam and Dipped Beam Headlamps



*Take care not to dazzle oncoming vehicles when switching between the main and dipped beams.*



### Manual Switching between Main Beam and Dipped Beam Headlamps

Push the light stalk lever(1) towards the instrument panel to turn on the main beams, the main beam indicator will

## BRIEF INTRODUCTION TO VEHICLE FUNCTIONS

illuminate on the instrument pack. Push or Pull the lever (1 or 2) once again to switch to dipped beams.

### Main Beam Flash

Repeatedly pull the lever ( 2 ) towards the steering wheel, and the main beams will flash.

### Smart Main Beam System\*



*The Automatic High Beam serves only as an auxiliary function. The driver must check the status of the front lamps and turn on the front lamps when necessary.*



*The Automatic High Beam may not operate normally in the following cases but is not limited to the following and so the main and dipped beams should be switched manually:*

- *The windscreen is dirty, broken or obstructed by other objects blocking the view of the sensor.*
- *The headlamps of other vehicles are obstructed or blocked and cannot be detected.*
- *When pedestrians, non-motor vehicles and other objects with no obvious light or reflected light are encountered.*
- *When the headlamps and tail lamps of other vehicles cannot be detected due to the sensor view being impaired due to undulating road conditions such as bends, dips or hills.*
- *When the car is driving on a winding road or mountainous road.*
- *The wiper switch is in the 'Fast' position.*

Smart main beam system detects the light intensity of the vehicle ahead by the front view camera and the main beams

## BRIEF INTRODUCTION TO VEHICLE FUNCTIONS

can be turned on or off once certain conditions are met. When the smart main beam system is enabled, the smart main beam indicator on the instrument pack will illuminate.

When the lights are in 'AUTO' and when driving on dark roads with no light and vehicles in the surrounding area, the system will turn on the main beams. When the road is more lit or the system detects headlamps or tail lights, the system will automatically turn off the main beams.

To enable the smart main beam system, the following conditions should be met:

- 1 The lighting lever switch is placed in the 'AUTO' position and the dipped beams should automatically turn on. .
- 2 The vehicle is running and the speed is above 20 MPH (40km/h).

The vehicle will exit the smart main beam system if the following conditions are met. With the system exited, quickly push the main beam 'ON' switch twice towards the instrument panel, this will enter the smart main beam system again. The smart main beam system will not be enabled in the current start cycle if it has exited over 3 times:

- When the smart main beam system is enabled and dipped beam headlamps are automatically turned on, manually switch to main beams.
- When the smart main beam system is enabled and main beams are automatically turned on, manually switch to dipped beams.
- When the smart main beam system is enabled and main beams are automatically turned on, toggle the main beam flashing switch.


### IMPORTANT

The Automatic High Beam function uses data from the front view camera, always keep the windscreen clean and free from residue in this area to maintain optimum performance of this system. Any damage in this area such as stone chips must be repaired at the earliest convenience.



## BRIEF INTRODUCTION TO VEHICLE FUNCTIONS

### Turn Signal Lamps



lamp will need to be manually operated. If briefly moved and released, the lever will reset immediately. The turn signal lamps and direction indicator lamps will flash three times and then go out.

2

Push the lighting lever downward (1) to turn on the left turn signal lamp; push the lever upward (2) to turn on the right turn signal lamp. The corresponding GREEN indicator lamp in the instrument pack will flash when the turn signal lamps are working.


When an indicator has been set and the steering wheel has been returned to the centre position following a turn, the indicator lamp will switch off. However, if the steering wheel angle is too small, the lever to switch off the indicator

# BRIEF INTRODUCTION TO VEHICLE FUNCTIONS

## Fog Lamps




*In severe conditions (during foggy weather for instance), the fog lamps can provide additional light and improve the visible range. Do not use the fog lamps in clear conditions as this will dazzle pedestrians and/or other road users.*



on and the corresponding indicator will illuminate on the instrument panel.

## Hazard Warning Lamps

Press the hazard warning lamp button at the middle of the centre vents  to operate the hazard warning lamps. All turn signal lamps and direction indicator lamps will flash together. Press the button again to switch off the hazard warning lamp.


## Rear Fog Lamps

When the headlamps are on and the left stalk has been turned to the '1' position, the rear fog lamps will turn

# BRIEF INTRODUCTION TO VEHICLE FUNCTIONS

## Wipers and Washers

### Windscreen Wiper and Washer Operation



- Automatic wipe (1)
- Slow speed wipe (2)
- Fast speed wipe (3)
- Single wipe (4)
- Automatic wipe speed adjustment\*/Rain sensor sensitivity adjustment\*(5)

- Wash and wipe (6)

### Automatic wipe

Pushing the lever up to the automatic wipe position (1) will cause the wipers to operate automatically.

Turn the switch (5) to adjust the automatic wipe speed for models without rain sensor. This speed will also change with the vehicle speed. As the vehicle speed increases, the wiping interval decreases. As the vehicle speed decreases, the wiping interval increases.

Turn the switch (5) to adjust the sensitivity of rain sensor for models equipped with a rain sensor. As the sensitivity increases, the wiping interval decreases. The rain sensor is equipped within the interior rearview mirror base and detects varying amounts of water outside of the windscreen. The automatic wipe feature will adjust the wiping speed according to the signals provided by the rain sensor.

**Note:** When increasing the sensitivity of rain sensor, the wiper will operate once immediately; if the rain sensor detects continuous rainwater, the wiper will keep working. When no rain is detected, it is recommended to switch off the automatic wipe function.

# BRIEF INTRODUCTION TO VEHICLE FUNCTIONS

## Slow speed wipe

By pushing the lever up to the slow speed wipe position (2), the wipers will operate slowly.

## Fast speed wipe

By pushing the lever up to the fast speed wipe position (3), the wipers will operate at fast speed.

## Single wipe

Pressing the lever down to single wipe position (4) and releasing will operate a single wipe. If the lever is held in single wipe position (4), the wipers will operate continuously until the lever is released.

**Note:** *When the car is stationary, if the bonnet is opened, the front wiper/washer operation will be disabled.*

### IMPORTANT

- Avoid operating the wipers on a dry windscreen.
- In freezing or extremely hot conditions, make sure that the wiper blades are not frozen or adhered to the windscreen.
- In winter, remove snow or ice from around the wiper arms and blades, including the wiped area of the screen.

## Wash and wipe

Pulling the lever toward the steering wheel (6) will operate the front windscreen washers. After a short delay, the wipers will commence operating in conjunction with the washers.


**Note:** *The wipers continue operating for three wipes after the lever switch is released. After several seconds, there will be a further wipe to remove any washer fluid from the windscreen.*

## BRIEF INTRODUCTION TO VEHICLE FUNCTIONS

### IMPORTANT

If the washers fail to deliver the screen wash solution (dirt or ice may have blocked the jets), release the lever immediately. This will prevent the wipers from operating and the consequent risk of visibility being impaired by dirt smearing across the unwashed windscreen.

### Rear Window Wiper and Washer Operation\*



Operate the lever to select different wiping modes:

- Intermittent wipe (1)
- Wash and wipe (2 or 3)
- Wipe interval adjustment (4)

# BRIEF INTRODUCTION TO VEHICLE FUNCTIONS

---

## **Intermittent wipe**

If the rear wiper switch is turned to intermittent wipe (1), the rear wiper will operate. It will complete 3 continuous wipes before changing to intermittent mode. The interval between the wipes can be increased/decreased via the switch (4).

## **Wash and wipe**

If the rear wash and wipe (2) is selected, the rear wiper and washer will operate together. If the switch is set back to intermittent wipe (1), the rear washer will stop operating.

If setting (3) is selected, the rear wiper and washer will operate together. If the switch is released to the 'off' position, the rear wiper and washer will stop operating. After several seconds, there will be a further wipe to remove any fluid draining down the screen.

**Note:** *When the tail gate is opened, rear wiper operations will be disabled.*

**Note:** *After the windscreen wipers are switched on, if the shift lever is in "R" position, the rear wiper will operate.*

## BRIEF INTRODUCTION TO VEHICLE FUNCTIONS

### Horn



Press the horn button area on the steering wheel (as indicated by the arrow) to operate the horn.

**Note:** *The vehicle horn button areas and the driver's airbag are located in close proximity on the steering wheel. The illustration shows the position of the horn (indicated by the arrows). Please ensure that you press in this area to avoid any potential conflict with the operation of the airbag.*

#### IMPORTANT

To avoid possible SRS issues, please do not press with excessive force or hit the airbag cover when operating the horn.

# BRIEF INTRODUCTION TO VEHICLE FUNCTIONS

## Rearview Mirror


The rearview mirrors consist of an interior rearview mirror positioned at the top of the windscreen and two exterior mirrors, one positioned on the left side of the vehicle and another on the right side.

The rearview mirrors are safety-critical parts. Proper use and reasonable mirror angle adjustment can improve driving safety and comfort.

## Exterior Rearview Mirrors

The exterior rearview mirrors are vulnerable in the event of a collision. The exterior rearview mirrors feature a manual or electric folding function, which helps avoid damage and allows folding when manoeuvring through narrow passages.

**Note:** *The vehicles or objects viewed behind in the exterior rearview mirrors may appear further away than they actually are.*



## Electric Adjustment of Door Mirror Glass

The exterior rearview mirror glass adjustment switch is located under the instrument panel on the driver's side and the mirror adjustment function will work when the vehicle is powered on.


- Rotate the round knob in the middle to select left ( L ) or right ( R ).
- Move the knob in the desired direction to adjust the angle of the exterior mirror glass.



## BRIEF INTRODUCTION TO VEHICLE FUNCTIONS

- Upon completion of the adjustment, rotate the knob back to the central position, this will ensure no accidental adjustment of the mirror.

### Manual Folding \*



For vehicles fitted with the manual exterior rearview mirror folding option, the exterior mirrors can only be folded backwards manually and return to their original position by being pushed forward.

### Electric Folding of Door Mirror\*


When the vehicle is powered on, rotate the adjustment knob to the middle position ( O ) and push the knob down, the door mirrors will be folded automatically. Pushing the knob downwards again will return the mirrors to their original position.

**Note:** While unlocking/locking the vehicle, the exterior rearview mirrors will be deployed/folded automatically.

**Note:** For vehicles equipped with electrical folding door mirrors, if the mirrors have been moved from their positions by manual or accidental means, they can be reset by operating the knob to complete fold and deployment one time.

### Mirror Glass Heating\*

The exterior rearview mirrors have integral heating elements which disperse ice or mist from the glass.

The heating elements operate while the Heated Rear Window is switched on, that is, only when the vehicle is running/powerd on, and the heated rear window is turned on  .

## BRIEF INTRODUCTION TO VEHICLE FUNCTIONS

### IMPORTANT

- The electric adjustment and regulation of mirrors are operated using the electric switch, operating them directly by hand may result in the failure of related devices.
- Washing or flushing door mirrors with high pressure water jets or car washes may result in electrical motor failure.

### Interior Rearview Mirror

Before driving, adjust the body of the interior rearview mirror to achieve the best possible view. The anti-dazzle function of the interior rearview mirror helps reduce glare from the headlamps of following vehicles at night.

### Manual Anti-dazzle Interior Rearview Mirror



Move the lever at the base of the interior rearview mirror to change its angle, so as to achieve the anti-dazzle function. Normal visibility is restored by pulling the lever back again.

**Note:** *In some circumstances, the view reflected in a manual anti-dazzle mirror can confuse the driver as to the precise location of following vehicles.*

# BRIEF INTRODUCTION TO VEHICLE FUNCTIONS

## Windows



*Please correctly operate the windows to avoid danger. The driver should ensure passengers operate the windows in a safe manner.*




*Ensure children are kept clear when raising or lowering a window.*



***DO NOT** operate the power window controls continuously in a short time frame, otherwise the power window controls may be disabled to protect the motor. If this occurs, please wait a few seconds until the motor cools down. Do not disconnect the negative battery during this time.*

## Power Operated Window Switch




- 1 Front Right Window Switch
- 2 Front Left Window Switch
- 3 Rear Left Window Switch
- 4 Rear Right Window Switch
- 5 Rear Window Isolation Switch

# BRIEF INTRODUCTION TO VEHICLE FUNCTIONS

## Window Operation

The electric windows can be operated when the vehicle is powered on (Doors should be closed during operation).



Press the window control switch ( 1 ~ 4 ) down to the 1st position (Position C) to lower the window and pull the switch up to the 1st position (Position B) to raise the window. The window will stop moving as soon as the switch is released.

## One-Touch Down

Press the window control switch ( 1 ~ 4 ) down to the 2nd position (Position D) and release. The window will automatically descend to open. Window movement can be stopped at a desired position at any time by operating the corresponding switch during descent.

## One-Touch Up with Anti-pinch\*

Depending on vehicle specification, some windows may have the 'One-Touch Up' and 'Anti-pinch' function. Lifting the switch ( 1 ~ 4 ) to the 2nd position (Position A) and releasing will automatically close the window completely. Window movement can be stopped at a desired position at any time by briefly operating the switch again during ascent.

The 'Anti-pinch' function is a safety feature which prevents the window from ascending and allows the window to descend automatically to a certain distance if an obstacle is sensed.

**Note:** *The front and rear passenger windows can also be operated by individual window switch mounted on each door. If the rear window isolation switch has been activated, the window switches on rear doors will not work.*

## **BRIEF INTRODUCTION TO VEHICLE FUNCTIONS**

---

### **Rear Window Isolation Switch**

Press the switch (5) to isolate the rear window controls (an indicator lamp in the switch pack will illuminate). Press again to restore control.

# BRIEF INTRODUCTION TO VEHICLE FUNCTIONS

## Sunroof\*

### Instructions



**DO NOT allow passengers to lean out of an open sunroof whilst the vehicle is in motion. Injuries may occur from objects such as tree branches.**




**Safety of the vehicle occupants must be observed at all times. DO NOT allow limbs to be placed in the moving path of the sunroof at any time, injury may occur.**


- Do not open the sunroof in poor weather conditions;
- Try to avoid opening the sunroof at high speed;
- Open the sunroof only after the water on the sunroof glass has been cleared, otherwise there may be water dripping down when opening the sunroof;
- Clean the glass with cleaning solvents such as alcohol;
- Upon completion of the sunroof operation, release the switch in good time, otherwise, this may result in a fault;
- To ensure the sunroof always operates correctly, please clean it frequently and ensure it is serviced regularly by an MG Authorised Repairer.

### Sunroof Operation

After the vehicle is powered on, the sunroof can be operated.




# BRIEF INTRODUCTION TO VEHICLE FUNCTIONS



The sunroof switch is located on the ceiling above the windscreen. Depending on different configurations, the styles of the roof console are different, but the sunroof switches are in the same position. The opening methods of the sunroof can be identified according to the switch symbols. Switch 1 will be used to operate the sunroof sunshade, and switch 2 will be used to operate the sunroof glass.

## Sunroof Glass Operation

### Open by Tilting



Push up the sunroof glass switch to position 1 and hold. The sunroof will be manually opened in a tilt way. Sunroof operation can be stopped at any time by releasing the switch.

Push up the glass switch to position 2 and release, this will allow the sunroof to open completely automatically.


### Close by Tilting

Pull down the sunroof glass switch to position ( 3 ) and hold, the sunroof will close. Sunroof movement can be stopped at any time by releasing the switch.

## BRIEF INTRODUCTION TO VEHICLE FUNCTIONS

Pull down the glass switch with excessive force to the 2nd position ( 4 ) and then release, the sunroof will be fully closed automatically.

### **Open by Sliding**



Push the sunroof glass switch backward to position ( 3 ) and hold, this will allow the sunroof to slide open manually. . Sunroof movement can be stopped at any time by releasing the switch.

Push the glass switch backward to position 4 and release, this will allow the sunroof to completely open automatically. Sunroof movement can be stopped at any time by pushing the switch backwards again.

### **Close by Sliding**

Push the sunroof glass switch forward to position ( 1 ) and hold, this will cause the sunroof to close manually. Sunroof movement can be stopped at any time by releasing the switch.

Push the glass switch forward to position ( 2 ) and then release, this will allow the sunroof to close automatically. Sunroof movement can be stopped at any time by pushing the switch frontwards again.

**Note:** *Because the sunroof glass motor is steplessly regulated, in order to prevent the glass from being not closed completely due to the error of visual perception, it is recommended to use the second gear for automatic closing when the sunroof glass needs to be closed completely.*



# BRIEF INTRODUCTION TO VEHICLE FUNCTIONS

## Sunroof Sunshade Operation



### Open

Push the sunshade switch backward to position ( 3 ) and hold, this will allow the sunshade to slide open manually. You can stop the movement of the sunshade at any time by releasing the switch.

Push the sunshade switch backward to position ( 4 ) and then release, this will allow the sunshade to slide open automatically. You can stop the movement of the sunshade at any time by pushing the switch backward again.

### Close

Push the sunshade switch forward to position ( 1 ) and hold, the sunshade will close automatically. You can stop

the movement of the sunshade at any time by releasing the switch.

Push the sunshade switch forward to position ( 2 ) and then release, the sunshade will be fully closed automatically. You can stop the movement of the sunshade at any time by pushing the switch forward again.

**Note:** *If you park the vehicle for a long period of time, it is recommended to close the sunshade; if possible, park the vehicle into garage to prevent the in-car temperature from rising due to long-time exposure, without damaging the interiors.*

### 'Anti-pinch' Function\*

During closing/opening operation, the sunroof glass and sunshade will stop closing/opening automatically when the closing resistance has increased due to an obstacle, extreme weather (i.e, temperature below - 20 °C) or other causes; following this will increase longevity of the sunroof movement mechanism.

### Forcibly Close the Sunroof Glass

To reset the sunroof in a situation where it cannot be opened, for example, when the anti-pinch function has

## BRIEF INTRODUCTION TO VEHICLE FUNCTIONS

---

been triggered. Push and hold the glass switch forward to position 1 for 5 seconds until the sunroof has closed completely. Please note, the anti-pinch function is not available when closing the sunroof.

### ***Forcibly Close the Sunshade***

To reset the sunshade in a situation where it cannot be opened, for example, when the anti-pinch function has been triggered. Push and hold the sunshade switch forward to position 1 for 5 seconds until the sunshade has closed completely. Please note, the anti-pinch function is not available when closing the sunshade.

### **Linkage between Sunshade and Sunroof Glass**

To prevent the sunshade from being exposed, the sunshade will move together when the sunroof glass is opened. To close the sunshade, please close the sunroof glass first.

### **Sunroof Initialisation**

Sunroof operation will be affected by power failure when sunroof glass or sunshade is in motion, and it is necessary to initialize after power on.

Glass initialisation - Close the sunroof glass completely by pushing the sunroof glass switch forward to position 2 and hold for approximately 10 seconds. The glass will automatically slide open and then close, during which, ensure the switch is kept at position 2 until the sunroof glass has closed.

Sunshade initialisation - Close the sunshade completely by pushing the Sunshade switch forward to position 2 and hold for approximately 10 seconds. The Sunshade will automatically slide open and then close, during which, ensure the switch is kept at position 2 until the sunshade has closed.

### **Thermal Protection**

To prevent the sunroof glass motor and sunshade motor from overheating and further damage; they are provided with a thermal protection function.


In the thermal protection state, only the closing operation is allowed.

# BRIEF INTRODUCTION TO VEHICLE FUNCTIONS

## Sunvisor



*For safety, do not use vanity mirror on the driver side whilst driving.*




Sunvisors are arranged on the roof ahead of both the driver and the front passenger ( 3 ). The sunvisors are provided with vanity mirror ( 2 )<sup>\*</sup>and vanity mirror light ( 1 )<sup>\*</sup>.

Pull the sunvisor down to use the vanity mirror. If the roof has vanity mirror lights, the vanity mirror light is switched on when the cover is opened and it is switched off when the cover is closed.

# BRIEF INTRODUCTION TO VEHICLE FUNCTIONS


## Interior Lighting

### Front courtesy lights - Style A\*



Press one of the switches ( 2 ) to turn the corresponding courtesy light on; press it again to turn off.


### Front courtesy lights - Style B\*



- 1 Automatic control switch
- 2 Corresponding side lighting manual control switch
- 3 Manual control main switch for indoor lighting

## BRIEF INTRODUCTION TO VEHICLE FUNCTIONS

### Front courtesy lights - Style C\*



- 1 Automatic control switch
- 2 Corresponding side lighting manual control switch
- 3 Manual control main switch for indoor lighting

### AUTO ON Function

Press the switch ( 1 ) of the courtesy light to turn on AUTO ON function; press it again to turn off the function.

When the AUTO ON function is enabled, the courtesy light illuminates automatically whenever the followings occur.

- The vehicle is unlocked.
- Any door is opened.
- The power supply is switched off when the vehicle equipped with a light sensor detects that the ambient light is in dark or the side lamp illuminates or the side lamp turns off for 30 seconds.

**Note:** *If a door is open for more than a certain period of time, the front interior lamp will be switched off automatically to avoid battery drain. In case of low battery, the courtesy light will extinguish earlier.*


# BRIEF INTRODUCTION TO VEHICLE FUNCTIONS

## Power Socket



*Using the power socket or USB port when the vehicle is not started will cause premature discharging of the vehicle battery, and prolonged use may cause flat battery, thus the vehicle cannot be started.*

## Front Console Power Socket




The 12 V front console power socket is located in the front of the centre console. Remove the socket lid, exposing the

power socket which can be used as a power supply with 120W maximum power.

There is one or two USB ports equipped at the side of the 12 V front console power socket (1/2). The USB port can supply 5 V voltage as the power interface. The left USB ports (1) can also achieve data transmission function.

The maximum operating current of USB port is 2.1 A.

## Rear Console Power Socket\*



## BRIEF INTRODUCTION TO VEHICLE FUNCTIONS


There is also 1 USB port equipped at the rear of the centre console for some models. The USB port can supply 5 V voltage as the power interface. The maximum operating current is 2.4 A.

voltage as the power interface, and the maximum operating current is 2 A.

**Note:** *The vehicle's USB ports may not support some fast charging devices.*

2

### Power Socket of Interior Rearview Mirrors\*



There is also 1 USB port equipped at the interior rearview mirror for some models. The USB port can supply 5 V


# BRIEF INTRODUCTION TO VEHICLE FUNCTIONS

## Storage Compartments

### Instructions for Use

- Please close all storage devices when the vehicle is in motion to avoid personal injuries in cases of a harsh acceleration, emergency braking and a car accident.
- Do not place liquid or flammable materials such as lighters in any storage compartments to avoid igniting flammable materials, leading to a fire.

## Glove Box



To open the glove box, press the open button (as indicated by the arrow) .


Push the lid forward to close the glove box. Make sure the glove box is fully closed when the vehicle being driven.



# BRIEF INTRODUCTION TO VEHICLE FUNCTIONS


## Storage Box

### Centre Console Rear Storage Box



The centre console rear storage box is located behind the centre console.

## Centre Console Armrest Box



Lift the centre console armrest (as indicated by the arrow) to open the centre console armrest box. Gently press the lid down to close the centre console armrest box.


## Glasses Box\*



*The glasses box should only be used only when the vehicle has stopped.*

## BRIEF INTRODUCTION TO VEHICLE FUNCTIONS

---



The glasses box is located in the proximity of the front courtesy lights. Press the panel (as indicated by the arrow), and place the glasses into the glasses box after opening it. Close the glasses box when it is not in use.

**Note:**



***Only glasses that feature a standard frame can be inserted into the glasses box.***

# BRIEF INTRODUCTION TO VEHICLE FUNCTIONS

## Cup Holder


**Note:** Do not place hot drinks in the cup holder while driving. Spillage may result in personal harm or damage.

### Centre Console Cup Holder



## BRIEF INTRODUCTION TO VEHICLE FUNCTIONS

---



The centre console cup holder is situated at the front end of the centre console armrest assembly and can be used to hold a cup or beverage bottle.

## **Preparation for Driving**

---

<i>Keys</i>	86
<i>Alarm System</i>	89
<i>Alcohol Interlocks*</i>	94
<i>Tail Gate</i>	95
<i>Load Carrying</i>	98
<i>Towing*</i>	100
<i>Fuel System</i>	102
<i>Steering System Adjustment</i>	104

### Keys

#### Overview



*Please keep the spare key in a safe place - not in the car!*



*It is recommended that spare keys are not kept on the same key ring, since this may cause interference and prevent correct key recognition and therefore prevent the correct operation of the vehicle power system.*



*The smart key contains delicate circuits and must be protected from impact, high temperature, humidity, direct sunlight and fluid corrosion.*



#### WARNING

The keys of vehicle contains coin / button batteries. The battery is **HAZARDOUS** and is to be kept away from children (whether the battery is new or used).



#### WARNING

A lithium coin / button battery can cause **SEVERE** or **FATAL** injuries within 2 hours or less if it is swallowed or placed inside any part of the body.



#### WARNING

If you think batteries may have been swallowed or placed inside any part of the body, please seek medical rescue immediately.

## PREPARATION FOR DRIVING


We provide remote key. The mechanical key can be used to unlock the door in emergency, but cannot be used to start the vehicle.

Two smart keys and common keys are provided for some models.

The keys supplied have been programmed for the security system on your vehicle. Any key that is not programmed to your vehicle can not start the car.

The smart key will only work within a certain range. Its working range is sometimes influenced by the key battery condition, physical and geographical factors. For safety consideration, after you lock your car using the smart key, please ensure that the car is locked.

### Keys - Type A\*



1 Lock Button

2 Tailgate Button


3 Unlock Button

4 Remote Key

5 Mechanical Key

## PREPARATION FOR DRIVING

### Keys - Type B\*



1 Lock Button

4 Smart Key

2 Tailgate Button

5 Mechanical Key

3 Unlock Button

If your key is lost/stolen or broken, a replacement can be obtained from an MG Authorised Repairer. The lost/stolen key can be deactivated. If the lost key is found, an MG Authorised Repairer can reactivate it.

**Note:** Any key made privately may not start the vehicle, and may affect the safety of your car. To obtain a suitable key replacement, it is recommended that you consult an MG Authorised Repairer.

**Note:** The new key cannot be offered to you immediately because it requires programming to the vehicle by the MG Authorised Repairer.

**Note:** If your car is equipped with induction-type wireless charging function, always keep the key more than 20 cm away from the mobile phone which is being charged to prevent the key from the interference of wireless charging device.

**Note:** Avoid operating the smart key close to strong radio interference devices (such as notebook computers and other electronic products), the normal function of the key may be affected.



### **Alarm System**

Your vehicle is fitted with an engine immobiliser and body anti-theft system. To ensure maximum safety and operation convenience, we strongly recommend you read this section carefully to completely understand the activation and deactivation of anti-theft systems.

### **Power Immobiliser**

The power immobiliser is designed to safeguard the vehicle from theft. A vehicle cannot be started until the power immobiliser is deactivated.

Once a valid key has been detected in the vehicle, the power immobiliser will be deactivate automatically.

### **Body Anti-theft System**

#### **Locking and Unlocking**

When the vehicle is locked, the turn signal lamps illuminate three times; when it is unlocked, the turn signal lamps illuminate once.

#### **Operation of Door Lock System (Key)**

##### ***Key Locking***

- Using the remote key to lock: press the Lock button on the smart key to lock the vehicle after closing the doors, bonnet and tailgate.
- Using the mechanical key to lock: remove the driver side door lock trim cover, insert the key into the lockhole and turn counterclockwise to lock the car.

##### ***Key Unlocking***

- Using the remote key to unlock: press the Unlock button on the key to unlock the vehicle.
- Using the mechanical key to unlock: remove the driver door lock trim cover, insert the key into the lockhole and turn clockwise to unlock the car.

##### ***Find My Car***

## PREPARATION FOR DRIVING


After the vehicle has been locked for several minutes, press the Lock button on the smart key for several seconds, the Find My Car function will then be enabled and the vehicle alarm will sound and the external lights will flash. Press this button on the smart key again to suspend the Find My Car function. At this time, press the Unlock button on the smart key to cancel the Find My Car function and unlock the vehicle. Find My Car can be set in the 'Vehicle Settings' interface on the entertainment display.

**Note: If the vehicle power system has not been started and the remote key unlock has not been activated within more than a few seconds after the vehicle is unlocked with the mechanical key, the anti-theft alarm system will be triggered.**

**Note: When the complete vehicle is locked, press the UNLOCK button on the remote key\* and perform no other operations for a period of time, the vehicle will automatically lock.**

### Operation of Door Lock System (Keyless)\*

The keyless entry system can lock and unlock the doors or open the tailgate as long as you carry the smart key and approach the car.



**Note: Keep the distance between the smart key and the door handle within the 1.5 m range in order to lock and unlock the doors using the keyless function.**

### Keyless Locking

Press the button on the front door handle once (no need to press the lock button on the smart key) to lock all doors before leaving the car. The vehicle will enter anti-theft alarm state.

### **Keyless Unlocking**

Press the button on the front door handle once to unlock the door.

**Note: When the vehicle is locked, if you are within the smart key range and operate the door handle button but carry out no further action, the vehicle will then automatically lock itself to remain secure.**

#### IMPORTANT

Once the door has been locked by the key, press the button on the door handle to unlock the vehicle. If the vehicle can not be unlocked or locked normally, please contact a local MG Authorised Repairer.

### **Mislock**

If the locking operation is performed when the driver's door is not fully closed, the door will not be locked and the horn will sound once to indicate a mislock and with the body anti-theft system being inoperative.

If the locking operation is performed when the driver's door is closed but the passenger's door or tailgate is not fully closed, the vehicle horn will sound once, indicating a mislock. In this case, the 'partial arming' attributes of the body anti-theft system will be enabled (all fully closed doors or tailgate apertures will be protected but an open aperture will not!) As soon as the respective aperture is closed, the system will automatically revert to an armed state; if the remote key is placed back (or left behind) in the car and the open door is closed, the entire vehicle will automatically unlock.

### **Inadvertent Locking of Keys in Vehicle\***


When one smart key is left inside the vehicle and the other key is used to lock the vehicle, the function of the locked smart key to activate the vehicle's power system will be disabled and the locking and unlocking functions of the vehicle will be retained. At this point, the second smart key outside the vehicle can be used to unlock the vehicle, and the starting function of the key inside the vehicle will automatically resume.

## PREPARATION FOR DRIVING

### Anti-theft Alarm

If the anti-theft alarm has been activated before it is turned off, the car horn will sound continuously. Press the unlock button on the remote key to release the anti-theft alarm.

### Interior Lock Switch



- 1 Lock Switch
- 2 Unlock Switch

When the body anti-theft system is disabled, press the interior lock switch (1) after closing all doors to lock all doors; press the Unlock switch (2) to unlock all doors.

**Note:** *If the vehicle anti-theft system is set, pressing the lock/unlock switch of the interior locks will not lock/unlock doors but will trigger the alarm system.*

If the doors, bonnet and tailgate are closed, press the interior lock switch and the yellow indicator on the lock switch will illuminate.

If the non-driver door, bonnet or tailgate is not fully closed and the interior lock switch has been pressed, the yellow indicator on the lock switch will flash.

### Interior Door Handles

When the vehicle anti-theft alarm system is not set, use the interior door handle to open the door:

- 1 Pull the interior door handle once to unlock the door.
- 2 Release and then pull the interior door handle again to open the door.



*When the anti-theft alarm system is activated by locking the vehicle with the remote key, the interior door handles will not be operational due to the anti-theft deadlocking of the doors. Please ensure people or animals do not remain in the vehicle when locking the vehicle with the remote key as they will be unable to exit the vehicle and there is a risk of injury or death.*

### **Auto Lock When Driving**

All the doors will be locked automatically when the vehicle speed exceeds 10 mph (15 km/h).

### Alcohol Interlocks\*



*The alcohol lock is a detection device used to assist in limiting drivers from driving when their blood alcohol concentration exceeds a preset limit. You are responsible for the safety of your passengers and other road users. Drink driving is an offence and is strictly prohibited.*

To operate the alcohol lock device, hold the handheld device and blow into the mouthpiece/orifice, by providing a breath sample the blood alcohol concentration will be analysed. If the levels are below the preset limit you will then be able to start the vehicle.

**Note:** *The handheld device should be placed in a position that is easy to access and does not affect driving. Please contact an MG Authorised Repairer for device installation and set up.*

#### IMPORTANT

If the alcohol test fails, for safety reasons, do not attempt to forcefully start the vehicle. If you suspect a malfunction with the alcohol lock device, please contact an MG Authorised Repairer for device installation and set up.

### Tail Gate






If the tailgate can not be closed due to the type of cargo loaded or if the weatherstrip seal is damaged, it is recommended you close all windows during driving, select the face distribution mode of the air conditioning and set the blower to maximum speed, so as to decrease any fumes entering the vehicle.



Prior to opening or closing the tailgate always ensure there are no people or objects that may obstruct operation. This may cause physical harm or damage.

### Tailgate Open/Close Mode



The tailgate can be opened or closed using the following methods:

- **Open the tailgate using the key:** With the Start switch in the 'OFF' state, long press the tailgate button ( B ) on the remote key to manually open the tailgate.
- **Open the tailgate from outside the vehicle\*:** When the vehicle is unlocked or the matched key can be

## PREPARATION FOR DRIVING

---

detected within 1 m range around the tailgate, directly press the open switch ( A ) on the tailgate to open the tailgate.

### **Tailgate Emergency Open**

#### **Manual Tailgate**




A tailgate emergency open switch is located in the tailgate catch assembly.

To access the mechanism, lower the rear seat to gain access to the tailgate trim. Identify the emergency release mechanism blanking plug (A).

Remove the plug trim, insert a suitable flat bladed tool into the release slot and rotate counterclockwise to open the tailgate (B).



## PREPARATION FOR DRIVING



3

### Load Carrying



**DO NOT** exceed the gross vehicle weight or the permitted front and rear axle loads. Failure may result in vehicle damage or serious injury.

### Loadspace Loading



Ensure that the rear seat backrests are securely latched in the upright position when loads are carried in the load space behind the seats.

When luggage is carried in the load space, always ensure heavy items are placed as low and as far forward as possible, so as to avoid cargo shift in the event of an accident or sudden stop.

Drive carefully and avoid emergency braking or hard acceleration when loaded with large or heavy items.

#### IMPORTANT

Traffic regulations must be observed when loading cargo, if the cargo extrudes the loadspace appropriate warning measures must be taken to warn other road users.

### Internal Loading



**DO NOT** carry unsecured equipment, tools or luggage that could move, causing personal injury in the event of an accident, or emergency braking or hard acceleration.



**DO NOT** obstruct the driver's or passenger's vision with loads.

Folding the rear seats can increase luggage space, refer to "Seat adjustment" described in the "Comfort Systems" section.

## PREPARATION FOR DRIVING

### Towing\*

#### General Towing Safety



***Exceeding any load limits advised by MG Motor is dangerous. Consult the recommended load limits and loading prior to any journey.***



***Excessive towing loads reduce front tyre traction and steering control, too little trailer nose load can make the trailer unstable and cause it to sway.***

Your vehicle can tow a trailer if you carefully observe load limits, use approved equipment, and follow the towing guidelines. Always check load limits before towing.

Towing loads in excess of the maximum towing weight can seriously affect vehicle handling and performance, this could damage your vehicle and drive-train.

#### ***When adding a towing device to the vehicle***

When towing, all rear vehicle lights must remain visible to road users behind the vehicle and must not be obscured / partially obscured.

If towing light sources are obscured, a secondary lighting source shall be used such as a lighting board.

When you are not towing, the fitted towing device must not obscure any lighting source. If the towing device obscures or partially obscures a lighting source such as the fog lamp it must be removed or retracted when not towing.

#### ***Tow bars***

Only genuine MG approved towbars should be fitted to your vehicle. Only use the attachment method specified by the vehicle manufacturer for securing the towing hitch. Contact an MG Authorised Repairer for more information.

#### ***Safety chains***

Safety chains must be used as a precautionary measure to avoid the trailer from becoming unintentionally unhitched. Make sure the safety chain is securely attached to both the trailer and the vehicle prior to departure.

## PREPARATION FOR DRIVING

### **Altitude**

Your engine delivers less power at higher altitude. If you tow a trailer in a mountainous area you should reduce the combined vehicle and trailer weight by 10% for every 1000 m of elevation.

### **Gradients**

Where possible, when towing, you should plan your journey to avoid steep gradients. The advised brake towing mass stated assumes a maximum gradient capability of 12% . Where possible it is recommended you drive on gradients less than 12% . Follow the trailer associations recommendations for suitable roads.

### **Running in period**

Avoid towing a trailer during your vehicles first 621 miles( 1000 km).

### **Towing Mode**

Your vehicle provides towing mode selection, it can be engaged or disengaged via:

- 1 Automatically: Connection or disconnection of the electrical connection with the trailer and the vehicle.
- 2 Manually: Enter the entertainment display to switch the function On/Off.

**Note:** *When towing mode is engaged automatically, manual adjustment via the entertainment display is not possible.*

When towing mode is activated, some vehicle functions will be limited or turned off, such as:

- Auto emergency brake\*;
- Adaptive cruise control system\*;
- Traffic jam assist system\*;
- Lane departure assist system\*;
- Rear driving assistance system\*;
- Rear parking aid system.

**Note:** *If the towed device is equipped with a tail light cluster, the vehicle also controls the trailer's lights after connecting the electrical connection.*

**Note:** *When operating the rear fog lamps, the trailer's rear fog lamps will also operate.*

## PREPARATION FOR DRIVING

### Fuel System

#### Fuel Requirements



***Use only gasoline which meets the national standards and the OEM specifications. Serious damage to the catalytic converter, a reduction in engine power / torque and increase in fuel consumption will occur if the wrong fuel is used.***

Please carry out refueling according to the information on the refueling label. Refer to 'Main Engine Parameters' in the 'Technical Data' section for details.

E5: Unleaded petrol fuel containing a maximum 2.7% (m/m) of oxygen and a maximum 5% (v/v) of ethanol.

E10: Unleaded petrol fuel containing a maximum 3.7% (m/m) of oxygen and a maximum 10% (v/v) of ethanol.



If a lower grade of fuel is used, an engine knocking noise may occur, please use the recommended or above grade gasoline as soon as possible. If the engine knocking noise is still noticeable after using the recommended or above grade fuel, please contact an MG Authorised Repairer immediately. It is permitted that the octane number of gasoline is higher than that required by the engine, but it is not advantageous for engine output power and fuel consumption.

### Fuel Filler

#### Fuel Filler Flap

The fuel filler door is located on the left rear side of the vehicle, and the small door lock is connected to the central control door lock system. When the door lock is open, press the left side of the small door to open it.

**Note:** *The fuel filler can only be locked when the car door is lock.*

#### Fuel Filler Cap

Slowly rotate the fuel filler cap counterclockwise to release the pressure inside the tank before opening it.

After refueling, replace the fuel filler cap and tighten it till you hear a "click".

#### Refueling



***Vehicle fuel gases are highly flammable and, in confined spaces, are also extremely explosive.***

Always take care when refueling:

- Turn off the power system;
- Do not smoke or use a naked flame;

- Do not use a mobile phone;
- Prevent fuel spillage;
- Do not overfill the tank.

Do not fully refuel the tank if the vehicle is to be parked in direct sunlight or high ambient temperature - expansion of the fuel could cause a leakage.

Start the engine after the fuel filling. If the engine does not run smoothly, shut down and do not start it again, contact an MG Authorised Repairer immediately for service.

#### IMPORTANT

During refueling, gasoline should be prevented from splashing on the surface of any painted or adjacent exterior parts. Contamination may cause the surface of the paint or adjacent exterior parts to become damaged.


## PREPARATION FOR DRIVING

### Steering System Adjustment

#### Steering Wheel Position Adjustment



**DO NOT attempt to adjust the position of the steering wheel while the car is in motion. This is extremely dangerous.**



Adjust the position of the steering wheel to suit driving posture:

- 1 Fully release the locking lever (as indicated by the arrow in the figure).
- 2 Grasp the steering wheel tightly with both hands and pull it up and down to adjust the height of the steering wheel; Push and pull the steering wheel forward and backward to adjust the distance between the steering wheel and the body (if equipped).
- 3 Once a comfortable driving position has been selected, pull the locking lever fully up to lock the steering wheel into its new position.

#### Electric Power Steering



**If the electric power steering fails, the steering may appear very heavy, which will significantly affect driving safety.**

This series of models are equipped with the electric power steering system. This system only works once the vehicle is started.



### IMPORTANT

When EPS is working, holding the steering wheel on full lock for long periods will result in a reduction in power assistance, causing a heavier feel to the steering.

3

### **Electric Power Steering Module Angle Initialisation**

When the battery is reconnected after it has been disconnected, the electric power steering ( EPS ) warning lamps may illuminate in yellow. In this case, the electric power steering ( EPS ) requires intialisation, i.e., rotate the steering wheel from lock to lock; after the initialisation is complete, the warning lamps will extinguish.

### **Steering Wheel Heating\***

Some models are equipped with a steering wheel heating function. The heating function can improve driving comfort in low temperature environments.



## **Driving the Vehicle**

---

<i>Power Start/Stop</i>	<i>108</i>
<i>Electric Drive Transmission*</i>	<i>114</i>
<i>Manual Transmission*</i>	<i>116</i>
<i>Continuously Variable Automatic Transmission (CVT)*</i>	<i>118</i>
<i>Drive Mode*</i>	<i>124</i>
<i>Parking Brake</i>	<i>126</i>
<i>Service Brake</i>	<i>129</i>
<i>Energy Regeneration*</i>	<i>131</i>
<i>Start-Stop Intelligent Fuel Saving System*</i>	<i>132</i>
<i>Economical and Environmental Driving</i>	<i>137</i>

### Power Start/Stop


#### Starting the Power System (Key Start)\*



When the vehicle is in motion, do not switching off the START/STOP switch or remove the key, otherwise the steering wheel may be locked, making it impossible to turn the vehicle.



Do not touch the key while the vehicle is in motion, otherwise it may cause the power system to flameout!



The Key barrel is located on the right side of the steering column. Function of each position is as follows:

#### **Position 0 (LOCK/OFF)**

- The key can be inserted or removed.
- After the engine is stopped and the key is removed, turn the steering wheel to one side to lock the steering wheel.

#### **Position 1 (ACC)**

## DRIVING THE VEHICLE

- The engine has not been started and the key cannot be removed.
- Some electrical equipment (such as the power windows, etc.) can be operated.

### **Position 2 (ON/RUNNING)**

- Rotate one gear clockwise from position 1 to position 2, at which point the vehicle enters the 'ON' state and some electrical equipment such as the instrument pack can be used.
- Depress the clutch pedal, turn the key clockwise to position 3 and release it once the vehicle has been started. The key will automatically return to position 2. The power system will then be in the ready state (RUNNING) and all electrical equipment will be operational.

### **Position 3 (START)**


- Start the power system.
- Release the key immediately after the power system has been started and the key will automatically return to position 2.

**Note:** *The shift knob or lever must be in P or N position and the start switch can only be operated when the vehicle is stationary.*

**Note:** *When the key is in position 0 and the driver's door has been opened, a buzzer will sound to indicate that the key has not been removed.*

**Note:** *When the steering wheel is locked and the key cannot be turned from position 0 to position 1, please turn the steering wheel slightly whilst turning the key to unlock the steering wheel.*

### **Starting the Power System(Keyless Start)\***



The keyless start switch is located on the center console and is a button type start switch. To operate the system, the smart key must be inside the vehicle.

The display states of the switch are described as follows:

### **Indicator Off (OFF)**

- The power system is shut off in this position.

### **Yellow Light (ACC)**

- When the system is in the 'OFF' state and the 'START/STOP' switch is pressed once, the vehicle will enter the ACC state, the yellow light of the START/STOP switch will illuminate, and some electrical equipment (such as the power windows, etc.) can be operated.

### **Green Light (ON/READY/RUNNING)**

- Whilst in the ACC state, pressing the 'START/STOP' Switch without the footbrake being applied will place the system in the 'ON' state, the green indicator will illuminate and some electrical equipment (such as the instrument pack etc) will operate. Whilst in the 'ACC' state, applying the footbrake and pressing the 'START/STOP' Switch will crank and start the vehicle.

- The vehicle will enter the READY/RUNNING state and all electrical equipment can be operated after the engine has been started.

**Note: After switching off the START/STOP switch and opening the door, if the key is still left in the vehicle, the horn will sound continuously when the doors are closed.**

If your car is subject to strong radio signals the keyless entry and start systems may suffer from interference and not function correctly. Please see the 'Alternative Starting Procedure'.

## Start the Power System



*Do not start and run the engine for a long time in an unventilated room. Exhaust fumes are harmful and contain carbon monoxide, which can cause unconsciousness or even death.*

## Starting Procedure (Key Start)\*


- 1 Switch off all unnecessary electrical equipment (including the air conditioning);
- 2 For vehicles with automatic transmission, make sure the shift lever is in P or N position and press the brake pedal;

**Note: When the shift lever is in any other position, the engine cannot be started.**

- 3 For manual transmission vehicle, ensure neutral is selected and the clutch pedal is fully pressed; For HEV vehicles, ensure P is selected, the EPB applied and the brake pedal pressed.
- 4 Insert the key, and rotate it to the 'START' position and then release key immediately after the engine has started.


**Note: After the engine starts, if the key is not released immediately, the starter will continue to work, which will not only discharge the battery, but also damage the starter motor, catalytic converter and particulate filter.**

## Alternative Starting Procedure (Manual Transmission Model)



## DRIVING THE VEHICLE

### Alternative Starting Procedure (Auto Transmission Model)



If the car is located in an area where there are strong radio signals causing interference or the smart key battery condition is low, please use the following steps to attempt to start the car:

- 1 Place the smart key in the position and at the angle as illustrated.

- 2 Make sure the gear selection is in P or neutral position, then press the brake pedal and operate the Start switch to start the power system.
- 3 For manual transmission models, please place the gear lever in neutral, press the clutch pedal, operate the start switch and start the power system.

After the battery of smart key is replaced or the car leaves the interference area, if the keyless start procedure can still not be used normally, seek an MG Authorised Repairer.

#### IMPORTANT

- If three consecutive attempts to start are unsuccessful, please seek assistance. Otherwise, multiple consecutive starts may cause damage to the power system and battery.
- This car is equipped with an anti-theft system. Any privately prepared key cannot start the vehicle.
- In environments with temperatures below -10 degrees Celsius, the time for the power system to start will increase. Therefore, when starting, turn off all unnecessary electrical equipment.




### Stopping the Power System

Stop the power system as follows:

- 1 After safely stopping the vehicle, press the brake pedal (automatic) or clutch pedal (manual).
- 2 Apply the parking brake.
- 3 For vehicles with automatic transmission, ensure that the shift lever is P position.
- 4 For vehicles with manual transmission, ensure that the shift lever is in neutral position.
- 5 Operate the start switch to turn off the power system.

### Electric Drive Transmission\*

#### Gear Shift Control



- **P Park**

In this position, the vehicle is locked and the EPB is applied. Please use this gear when the vehicle is stationary.

Press the P gear button and the vehicle engages the P gear.

*Note: With the brake pedal released, the driver seat belt unfastened and the driver door opened, the vehicle will automatically shift into P gear.*

- **R Reverse**

Select this gear only when the vehicle is stationary and you wish to drive backwards.

Apply the brake pedal, turn the shift control knob counterclockwise to the end and release. The vehicle will enter Reverse.

- **N Neutral**

Select this gear when the vehicle is stationary and the engine is running at idle speed for a short time (for example, waiting for traffic lights).

- **D Drive**

Apply the brake pedal, Push the shift lever until D light comes on. The vehicle will enter D Drive.

### Protection Mode




*When parking, drive the vehicle to a safe area on the premise of ensuring your own safety and complying with traffic regulations.*

### Shift System Malfunction


If serious functional faults are detected in the gear shifting system, the instrument pack will display "EP". At this time, for the sake of driving safety, when the speed is below a certain value, the power system will forcibly cut off the power transmission and the vehicle will not be able to be driven! Please contact an MG Authorised Repairer immediately.

### Electric Drive Transmission Motor Malfunction

When the system detects a fault with the electric drive transmission motor or controller, the warning indicator light  will illuminate red. Please park the vehicle safely and contact an MG Authorised Repairer immediately.

### Power Limitation of Electric Drive Transmission

The electric drive transmission may become very hot in a high-temperature environment with frequent starting, frequent rapid acceleration and deceleration, long-term continuous steep climbing and thus overload the electric drive transmission.


In some cases, to avoid motor damage, the system will implement power limitation. The following warning indicator light  will illuminate.

In this situation, stop at a safe place or maintain a lower load to continue moving at a constant speed to cool the motor. After the motor temperature drops and the warning indicator light goes out, normal driving can be reinstated.

If the electric drive transmission has cooled down for a long time (about 20 minutes) and the warning indicator has not disappeared, please park the vehicle safely and contact an MG Authorised Repairer immediately, otherwise it may seriously damage the electric drive transmission.


## Manual Transmission\*

### Gear Shift Lever



The manual transmission is a 5 -speed manual transmission with 6 gears, which are: 1st , 2nd , 3rd , 4th , 5th and R (Reverse) respectively.

### Precautions while driving:



- 1 When selecting R gear, you must ensure that the vehicle is completely stationary, wait for a moment and then fully press the clutch pedal, ensure the lever is in the N position, press the lever down and push it leftward, then push it forward into the R position, slowly release the clutch to engage drive. Please wait for 2 ~ 3 seconds before attempting to select R gear, otherwise the damage to the reverse gear may occur.
- 2 Do not rest your hand on the gear shift lever while driving - pressure from your hand may cause premature wear to the gear shift mechanism.

- 3 Do not rest your foot on the clutch pedal when driving  
- excessive wear to the clutch will be caused.
- 4 Do not hold the car stationary on a hill by holding the clutch. This will wear out the clutch.

***Note: In order to guarantee the smooth driving and good fuel economy of the vehicle, please shift at an appropriate time and never allow the engine to run at a high speed for prolonged periods, this may cause engine damage.***

### **Gear Shift Indications**

When the vehicle is in motion and the clutch pedal fully released, if all the pre-set criteria for a gear change is satisfied, the information center will display the recommended gear and an arrow to remind the driver to shift to the gear displayed when driving conditions permit.


### Continuously Variable Automatic Transmission (CVT)\*

#### Instructions for Use

The following information is very important; please read carefully before use:

- Before starting the vehicle, close the doors, confirm the shift lever is in P position, press the brake pedal and apply the parking brake.
  - After the vehicle has started, maintain brake pedal application and ensure the parking brake is applied, then shift the lever to the required gear.
  - Release the parking brake, brake whilst maintaining brake pedal application until you are ready to manoeuvre the vehicle. On a flat road, once the brake pedal is released, the vehicle will automatically begin to travel at a slow speed with the accelerator pedal not depressed.
  - When driving, do not coast in neutral, otherwise it could cause an accident.
- Do not tow the vehicle with its front wheels on the ground, this could cause severe damage to the CVT transmission.

## Gear Shift



The automatic transmission is a CVT transmission.


**Note:** *The highlighted letters or numbers on the instrument pack interface indicate the selected gear.*

A sprung loaded lock button located in the gear lever is used to prevent mistakingly selecting P (Park) or R (Reverse) whilst the gear selector is in other positions.

## Shift Lever Operation



**DO NOT** press the lock button when shifting gears, unless necessary.



During any gear shift, operate the shift lever according to the instructions indicated by the following arrows:



Free gear shift.



Press and hold the lock button to shift gear.



Press and hold the lock button and apply the brake pedal to shift gear.

### Shift Lever Position



***The shift lever must be placed in P position when parked.***



***DO NOT Switch the shift lever between D and R gears or into the P gear whilst the vehicle is in motion, otherwise, it may cause serious damage to the transmission or an accident.***

- P Park

When the shift lever is in this gear, the transmission will be locked. This gear should only be used when the vehicle is stationary and the parking brake is applied.

***Note: When the vehicle is parked on a hill, press the brake pedal and apply the parking brake first before selecting P gear.***

- R Reverse

Select this gear only when the vehicle is stationary.

- N Neutral

Select this gear when the vehicle is stationary and the engine will be running at idle speed for a short time (for example, waiting for traffic lights).

- D Drive

This is used for normal driving and will allow automatic selection of gear ratios depending on vehicle speed and accelerator pedal position.

- E ECO

Select this gear to prioritise economy over performance. The instrument pack displays ECO and E gear indicator lamps at the same time.

When the shift lever is in E gear, toggle the shift lever towards ' + ' direction to upshift to next available high gear; or toggle the shift lever towards ' - ' to downshift to next available low gear.

- Manual Mode

Select this mode when manual gearshift is required. The instrument pack displays a number (1-8) to indicate the current gear the vehicle is.



### Gear Shift Indication\*

The gear shift indication function can provide the driver with instrument prompts for upshifts, downshifts and recommended gears. Shifting gears in accordance with the system's prompts can help to save fuel.

The gear shift indication function will be activated immediately after the manual mode is turned on, an arrow indicating upshift or downshift will be displayed next to the gear, prompting the driver to switch to the recommended gear if conditions permit.

Whilst in manual mode, if the driver makes an unreasonable gear selection, such as requesting an upshift during low engine speeds, or requesting a downshift during high engine speeds, the transmission will not respond and will remain in the current gear. If the vehicle is driven and the engine speed falls below a preset threshold in certain gears, the transmission will automatically shift down to the next gear to avoid engine stalling; when the vehicle accelerates, if the engine speed increases continuously and exceeds the allowable maximum speed with no upshift request received, the transmission will automatically shift up to the next gear to protect the engine.

To return to other gear modes, move the shift lever leftwards and select D.

### Gearshift Speed

With D or E gear selected, the speed of one gear varies depending on the accelerator pedal position: a smaller throttle opening will result in the gear shift at a lower speed, and a larger throttle opening will cause the transmission to delay the gear shift action, until the gear shift is completed when the vehicle reaches a higher speed.

### Kick-down



***The drive wheels may skid when kick-down is activated on road surfaces with low adhesion, this may lead to the vehicle sliding out of control.***

With D or E gear selected, pressing the accelerator pedal all the way down in one motion (also known as Kick-down ) will provide better acceleration performance during overtaking. Under certain conditions, it will allow the transmission to shift to a lower gear immediately, and provide fast acceleration. Once the accelerator pedal is

released, it will resume a suitable higher gear (based on the vehicle speed and the position of the accelerator pedal).

### Protection Mode



*When parking, drive the vehicle to a safe area on the premise of ensuring your own safety and complying with traffic regulations.*

### CVT Transmission Failure

If the transmission develops faults or works improperly, the engine emission malfunction indicator lamp in the instrument pack will illuminate. In such a case, seek a local Authorised Repairer for service as soon as possible.

### Limp Mode

When some failures occur, the transmission will enter Limp Mode and will only function in some gears, in some cases it may fail to engage reverse, during this time the instrument pack will display the engine emission malfunction indicator lamp. In such a case, contact an MG Authorised Repairer for service as soon as possible.

### Gear Shift System Failure

If some serious functional failures occur in the gear shift system, the instrument pack will display ' EP '. During this

time, for safe driving, if the vehicle speed is below a certain value, the power system will forcibly cut off the power transmission and the vehicle will not be able to drive! In this case, please contact an MG Authorised Repairer for service as soon as possible.


### Drive Mode\*



*Switching the driving mode when the vehicle is in motion can divert driver's attention from road conditions, this operation can only be performed when safety permits.*

The driving mode enable different tuning modes for functions such as power response and steering feel etc.

Using the center console mode switch, you can switch between the following driving modes:



#### 1 **ECO**

The vehicle is in low energy consumption state for economical driving.

#### 2 **Normal**

The vehicle is in balanced tuning state for daily driving.

#### 3 **Sport**

Provide the driver with a dynamic driving experience, suitable for a sporty driving style.



*Note: When switching the driving mode in manual mode, the power system will maintain the shift logic of manual mode.*

### Parking Brake

#### Parking Brake System - Electronic Parking Brake ( EPB )\*



*In the event of an EPB malfunction where EPB release is not possible, please consult an MG Authorised Repairer in order to carry out an emergency manual release of the parking brake.*



The EPB system can be operated using the following methods:

Pull the EPB switch upwards to apply the EPB system after the vehicle is parked safely. Place the Start switch in ON/READY/RUNNING position, press the brake pedal and remove the gear shifter from P to release the EPB system.

If the indicators (P) in the EPB switch and in the instrument pack illuminate, it indicates that the EPB system has been applied. If the indicators (P) in the EPB switch and in the instrument pack extinguish, it indicates that the EPB system has been released.

**Note:** *When leaving the vehicle, the EPB must be applied.*

**Note:** *An audible motor noise may be heard when applying or releasing the EPB.*

*The electronic parking system cannot be activated or deactivated when the vehicle battery is discharged. If this is the case, apply the emergency starting power system with a jumper cable, please refer to the 'Jump Start' section in the 'Emergency' section.*

### Start Assist

If the driver's seat belt is fastened, the engine is running, D or R gear is selected and the accelerator pedal is pressed to pull away, the EPB system will automatically release.

### Emergency Braking Function



*Inappropriate use of EPB can lead to accidents and injuries. DO NOT apply the EPB for vehicle braking whilst moving, unless in an emergency.*



*During emergency braking using the EPB, DO NOT switch off the ignition/power system, this could result in serious injury.*


In the event of a brake fault when driving, emergency braking can be initiated by pulling and holding the EPB switch upward. An audible warning will sound during emergency braking. The braking process will be canceled by releasing the EPB switch.

## DRIVING THE VEHICLE

### Parking Brake System - Manual Parking Brake



***Do not drive with the parking brake applied or apply the parking brake whilst the vehicle is in motion. This could result in loss of control, prevent the ABS from functioning correctly and may even cause damage to the rear brakes.***



The parking brake operates on the rear wheels only. To apply the parking brake, pull the lever upward. Whilst parked, ensure the parking brake lever stays in applied state.

To release, pull the lever up slightly, then press the button at the end of parking brake lever and fully lower the lever.

When parking on a steep slope, do not rely on the parking brake alone to hold the vehicle.



### Service Brake

Some models are equipped with vacuum assisted hydraulic brake system as the service brake system. It allows the driver to apply the brake more easily, and also improves the braking performance.

**Note: When the vehicle has not been started and the brake pedal has been depressed, you will notice it feels hard, but once the engine has been started, the brake pedal will feel soft; conveying the brake booster is operational.**

The vacuum assisted hydraulic brake system helps the driver save effort when depressing the brake pedal, ensuring a quick and safe stop. However, in daily driving, the following non-standard operations should be avoided:

- Never allow the car to freewheel with the engine turned off. This is because the vacuum assisted hydraulic brake system works only when the engine has been started. Braking when the car is freewheeling with the engine 'flameout' may result in brake failure.
- In the case of a flameout whilst driving, you should depress the brake pedal to stop the vehicle as quickly as traffic safety permits. When braking, DO NOT pump the brake pedal as it will excessively consume the

vacuum assist in the braking system, thereby requiring an increased brake pressure force.

During driving, the following matters should be noted:

- When the braking efficiency of the vacuum booster decreases due to the change of atmospheric pressure from plain to plateau regions, the user needs to depress the brake pedal with greater effort than usual to gain effective braking.
- When driving through puddles or heavy rain, a water film may form on the surface of brake disc, which easily reduces the braking efficiency and extends braking distance. In this case, keep a safe distance from other vehicles and intermittently apply the brake pedal to keep the brake disc surface dry.
- If the braking efficiency decreases due to vehicle failure, please contact a local MG Authorised Repairer for service as soon as possible.

Some models are equipped with an integrated braking system (IBS) which has the advantages of high integration, faster braking response, and higher stability without relying on vacuum environment. Please note the following points when using IBS:

- IBS only works when the power system is ready, please do not coast with the power system turned off.
- If the power system is turned off during driving, you should firmly press the brake pedal and stop as soon as traffic safety permits.
- When the power supply of IBS decreases due to low power or other reasons, it is necessary to apply more force than usual to the brake pedal to obtain effective braking.

### Energy Regeneration\*



*The deceleration caused by the energy regeneration is NOT a substitute for braking safely. The driver must ALWAYS be prepared to make braking manoeuvres to maintain safe driving.*

When the vehicle is braking, in an overrun or coasting state, the energy regeneration function is activated, and the motor converts part of the kinetic energy of the vehicle into electric energy, which is then stored in the high-voltage battery pack.

Energy cannot be regenerated or is limited under some conditions, such as:

- N gear is selected (During driving do not coast in N gear) ;
- During torque intervention (SCS or traction control operation) ;
- High voltage battery pack is fully charged;
- High voltage battery pack temperature is too high or too low.

Energy Regeneration Level :

#### High

High Level: Maximum energy is regenerated, the vehicle exhibits shorter coasting distances and a strong sensation of over-run drag or motor braking.

#### Medium

Medium Level: Moderate energy regenerated.


#### Low

Low Level: Minimum energy is regenerated, the vehicle exhibits longer coasting distances and no significant sensation of over-run drag or motor braking.

The energy regeneration level can be selected in the entertainment display screen.

**Note: It is recommended to choose Low or Medium levels on surfaces that have low adhesion levels (e.g. icy roads).**

### Start-Stop Intelligent Fuel Saving System\*



- 1 Start/Stop System Switch
- 2 Start/Stop System Switch Lamp

Start-Stop intelligent fuel saving system allows the engine to start or stop automatically under idle conditions (such as waiting for traffic lights), this helps to improve fuel

economy and allows the vehicle to start or stop stably and reliably.

After the START/STOP Switch is turned to ON position, The Start-Stop Intelligent Fuel Saving System is enabled by default. Pressing the start/stop system switch ( 1 ) will turn off the Start-Stop intelligent fuel saving system, and its switch indicator lamp ( 2 ) extinguishes. If in the off state, press the start/stop system switch ( 1 ) will turn on the Start-Stop intelligent fuel saving system, and the indicator light of the start/stop system switch ( 2 ) will light up.

**Note:** *If the vehicle is driving through deep water, please use the Start/Stop system switch (1) of Start-Stop intelligent fuel saving system to shut down Start-Stop intelligent fuel saving system.*

### Automatic Shutdown of Engine

**Although the engine is not running after an automatic stop, the vehicle is still operating, therefore the following actions could be dangerous:**

- 1 **Leaving the vehicle while the seat belt is still buckled, or there is a substitute seat belt buckle inserted.**

**2 Vehicles with automatic transmission: The driver leaves the vehicle, with the shift lever still in Drive position ( D ).**

**3 Stretch the body into the engine compartment.**

**4 Refuel the vehicle. (Even if the engine has been shut down, the key must be removed for refueling.)**

Under the condition that the Start-Stop intelligent fuel saving system is enabled, the engine will be automatically shut down when detecting the following operations of driver as well as the vehicle states after the vehicle is stopped, and the Start-Stop intelligent fuel saving system indicator lamp on the instrument pack ⓘ illuminates:

- With the gear in D position and the brake pedal pressed, it will automatically shift to P/N gear after the engine is automatically shut down, and the vehicle is still in automatic shutdown status when the brake pedal is released.
- The vehicle speed signal on the instrument shows normal, and the maximum vehicle speed before parking is more than 10 km/h ( MT model: 5 km/h ) .
- There is no significant steering operation after the speed is lower than 10 km/h.

- Close the bonnet and the driver door, wear the driver seat belt.

The Start-Stop intelligent fuel saving system will be disabled and the engine will not be stopped automatically when the followings occur:

- The adaptive cruise control system is active.
- The semi-automatic parking system is activated.
- Coolant temperature is below a preset limit.
- Front defrost is on.
- The comfort experience of air conditioning is not within the ideal range.
- Low battery or battery temperature not within the desired range.
- The vacuum in the braking system falls below a preset limit.
- Starter motor temperature is above a preset limit.
- Reverse gear selected or has been selected prior to parking.
- In high-altitude zones.
- On the hill.

### Automatic Engine Start

After the car is stopped, the engine will be automatically started when detecting one of the following operations of driver, and the Start-Stop system indicator lamp on the instrument pack (Ⓜ) extinguishes:

- Select D gear, and release the brake pedal.
- Depress the brake/accelerator pedal when P/N gear is selected.
- When in N gear, the gear shifts to driving gear.

**Note:** *When EPB system or Auto Hold system is enabled, release the brake pedal in D gear, the engine will not automatically start. The engine will trigger a start when the driver steps on the accelerator pedal to start.*

**Note:** *In individual situation, the malfunction indicator lamp on the instrument will illuminate in the process of automatic engine start. This occurs due to the low voltage during startup, not indicating actual faults. If the malfunction indicator lamp is still on for a long time after engine start-up, seek a local MG Authorised Repairer.*

Engine will start automatically upon demands of the vehicle after automatic stop:

- The semi-automatic parking function is activated.

- The defrost/fog function of the front windshield is activated.
- Activate the air conditioner, and the comfort experience of air conditioning is not within the ideal range.
- Battery power is below a preset limit.
- The vehicle speed exceeds its limits, for example, when slipping on slopes.
- The vacuum in the braking system falls below a preset limit.
- The Start/Stop System Switch ( I ) is pressed.

When one of the followings occurs after the engine is automatically stopped, the engine can only be manually started, and at this time, the Start-Stop system indicator lamp on the instrument pack extinguishes:

- The driver side seat belt is unbuckled.
- The driver door is open.
- Bonnet is open.

***In case of low battery, automatic engine start may fail after sudden flame-out, in this case, please refer to "Starter Inoperative, Serious Battery Capacity Loss".***

### Battery



*When charging/discharging the battery, or starting the car with an external power source or supplying power from the vehicle, the negative cable must be connected to vehicle body earth point, rather than the battery negative. Failure to do this will result in inaccurate battery power calculation which will effect the automatic engine start.*

**DO NOT disconnect the battery sensor unless absolutely necessary. Removal will result in inaccurate battery power calculation which will effect the automatic engine start.**

Failure to operate with the following instructions will effect the battery performance and the function of Start-Stop intelligent fuel saving system:

- 1 For vehicles with Start-Stop intelligent fuel saving system, following re-connection of the battery negative terminal, the battery needs to be left for at least 4 hours. Before this the automatic Start/Stop functionality of the engine will be disabled.

- 2 If the battery requires replacement, ALWAYS use the battery with the same type and same specifications. Failure to adhere to this can affect the automatic Start/Stop function.

### Start-Stop Intelligent Fuel Saving System Failure

If the Start-Stop intelligent fuel saving system failure occurs, seek a local Authorised Repairer.

When other MILs of the vehicle illuminate, such as engine MIL, transmission MIL, SCS MIL, etc., the Start-Stop intelligent fuel saving system may also stop operating. Please contact a local MG Authorised Repairer.

### Starter Inoperative, Serious Battery Capacity Loss

In the case of serious battery power loss, automatic engine start and key start may not be possible. In this case, the engine needs to be started by an external power supply, refer to "Emergency Starting" in "Emergency Information" chapter for the operating steps.

*Note: It is forbidden to connect the jumper cable to the battery negative! It will result in inaccurate battery power calculation which will effect the automatic engine start.*



## Economical and Environmental Driving

### Running-in

The engine, transmission, brakes and tyres need time to "bed-in" and adjust to the demands of everyday motoring. During the first 900 miles ( 1500 km) , it is essential that you drive with consideration for the running-in process and heed the following advice:

- Do not allow the engine to exceed 3000 rpm in any gear or the vehicle speed to exceed 75 mph ( 120 km/h) .
- Do not operate at full throttle or allow the engine to labour in any gear.
- Do not drive at a constant speed (either high speed or low speed).
- Avoid heavy braking where possible.

After 900 miles ( 1500 km), engine speeds can be gradually increased.

### Environmental Protection

Your vehicle has been designed with the latest technology in order to minimise the environmental impact of exhaust emissions.

## Economical Driving and Maintenance

The following are some suggestions on reducing fuel and energy consumption and extending the service life of the vehicle:

- Maintain the correct tyre pressure. Insufficient air pressure will accelerate tyre wear and waste fuel.
- Do not carry unnecessary weight. Heavy loads will increase the engine load resulting in higher fuel consumption.
- Avoid engine idling for extended periods.
- Maintain slow and smooth acceleration and avoid harsh acceleration; change to a higher gear as soon as possible.
- Avoid labouring the engine or over running. Choose appropriate driving styles according to the road conditions.
- Avoid continuous acceleration or deceleration.
- Avoid unnecessary stopping and braking, maintain steady speed and attempt to anticipate traffic lights.
- Avoid traffic congestion and jam areas as much as possible.
- Anticipating obstructions and slowing down well in advance, avoids the need for unnecessary acceleration

## DRIVING THE VEHICLE

---

and harsh braking. A smooth driving style not only reduces fuel consumption, but can reduce the emission of noxious gases.

- Do not ride the brake pedal, this can cause premature wear, overheating and increased fuel consumption.
- Maintain an appropriate speed on the highway. Appropriate speed can save fuel.
- Maintain the correct wheel alignment. Avoid collision with the kerb and reduce speed on uneven road surfaces. Out of specification wheel alignment will not only lead to excessive tyre wear, but also increases the engine load and fuel consumption.
- Avoid driving on mud or beaches. This will prevent corrosion of the vehicle underside.
- Maintain the vehicle in accordance with MG recommendations. Dirty air filters, oil etc., will reduce the engine's performance and raise fuel consumption.
- Do not stop the engine straight after high speed or long ascents or towing a trailer. Allow the engine to idle for 20 to 100 seconds depending upon driving loads and conditions. Avoid hard acceleration on a cold engine.

**Note:** *Keep an appropriate distance from other vehicles to avoid emergency braking. This also reduces wear on the brake discs and pads.*

**Note:** *To extend the life of all components and reduce operating costs, regular MG Approved maintenance is needed.*

## Driving in Special Environment

### Driving in Rain or Snow



*Emergency braking, accelerating and steering on slippery roads will reduce the vehicle's handling performance and grip.*

- If the window or windshield fogs up, please use the air conditioning defogging function; If there is water film on the rearview mirror or fog on the rear windshield, please use the external rearview mirror and rear windshield heating function.
- If the road surface is frozen or covered with snow, the friction between the tires and the road surface becomes very small, making it highly prone to accidents. Please stop driving; Or install a suitable anti-skid chain before driving, refer to "Tires" in the "Maintenance" section

### Driving through Water



*Do not venture into low-lying waterlogged roads or unknown water wading areas, as this may result in the failure of the power system, serious vehicle malfunctions (such as short circuits in electrical components), or damage to the power system due to water ingress! Any vehicle malfunction or damage resulting from this will no longer be covered by MG's warranty terms.*

When driving a vehicle, try to avoid passing through waterlogged roads or areas with puddles as much as possible. If you need to drive through water, please follow the following suggestions:

- Before entering the flooded section, the depth of the water must be clear, and the height of the water should not exceed the lower edge of the vehicle body;
- If you want to drive through water, you need to turn off the air conditioning before starting, lightly step on the accelerator pedal without releasing your foot, smoothly and slowly pass through the flooded road section, and control the speed within 10 kilometers per hour;

## DRIVING THE VEHICLE

---

- Do not reverse in water or park the vehicle in stagnant water. If driving through water causes the vehicle to stall, please do not attempt to start the vehicle again. Please contact an authorized after-sales service center for inspection;
- After passing through water, please lightly press the brake pedal continuously to confirm that the braking performance is normal and avoid emergency braking;
- After passing through water, please check if the lighting and horn functions are normal;
- After wading through water, it may affect the functionality and performance of the vehicle. It is recommended to contact an authorized after-sales service center for inspection in a timely manner.
- When there is water or mud on the surface of the brake disc, it may cause a decrease in braking performance and thus prolong the braking distance. Please drive carefully to prevent accidents.
- Wet brake pads may not brake properly. If only one side of the brake pad can brake properly, it can affect steering control and cause accidents.
- After water enters the interior of high-voltage components, it has a significant impact on their

insulation properties. Water contains a lot of conductive substances, which may cause internal short circuits in high-voltage components, seriously affecting vehicle safety and driving performance.

## Safety

---

Seat Belt	142	Multi-Collision Brake System (MCB)*	192
Airbag	153	Pedestrian Alert System*	193
Child Restraints	166	Tyre Pressure Monitoring System (TPMS)*	194
Child Proof Locks	178		
Body Stability Control System	179		
Anti-lock Brake System (ABS)	181		
Auxiliary Brake System	183		
Auto Hold*	184		
Hill Hold Control (HHC)	186		
Hill Descent Control (HDC)	187		
Active Rollover Protection (ARP)	190		
Emergency Braking Hazard Warning Strobe (HAZ)*	191		

## Seat Belt



*It is important that all seat belts are worn correctly. Always check that all passengers are wearing seat belts. DO NOT carry passengers that are unable to wear correctly positioned seat belts. Wearing seat belts incorrectly may cause serious injury or even death in the event of a collision.*



*Airbags can not replace seat belts. Airbags can only provide extra support when triggered, and not all traffic accidents will trigger airbags. Whether airbags are triggered or not, seat belts can reduce the risks of serious injury or death in accidents. Therefore, seat belts must be worn properly.*



*NEVER unfasten a seat belt whilst driving, serious injury or death may occur in the event of an accident or emergency braking.*



*Never fasten the driver seat belt or use a buckle replacement when the driver seat is vacant or when exiting the vehicle.*



This vehicle is equipped with a seat belt warning lamp to remind you to fasten your seat belt.

During driving, seat belts must be fastened, this is because:

- You can never predict if you will be involved in a collision/accident and how serious it may be.
- In many cases of collision accidents, passengers with seat belts properly fastened are well-protected, while passengers with seat belts not fastened suffer from serious injury or even death. Therefore, all passengers must wear seat belts correctly, even during short-distance journeys.

Therefore, all passengers must wear seat belts correctly, even during short-distance journeys.

## Protection Provided by Seat Belts

**Note:** *It is of equal importance for passengers in the rear seat to fasten their seat belts correctly. Otherwise, passengers with seat belts not correctly fastened will be thrown forward in accidents, and will endanger themselves as well as the driver and other passengers.*

When the vehicle is in motion, the travelling speed of the occupants is identical to that of the vehicle.

In the event of a 'head on collision' or emergency braking, the vehicle may stop, but the occupants will carry on travelling until they come into contact with a stationary object. This object may be the steering wheel, dashboard, windscreen or front seats.

A correctly fastened seat belt will eliminate this risk of injury. When the seat belt is worn correctly, it will lock automatically in collision accidents or emergency braking to reduce your speed together with the vehicle, so as to prevent the out-of-control movement which may cause serious injury to driver and passengers.



## Wearing Seat Belts



*Incorrectly worn seat belts could cause injury or death in the event of an accident. Seat belts are designed for one person, DO NOT share seat belts.*



*DO NOT wrap a seat belt around when holding a baby or child in your arms.*



*Remove any heavy coats or clothing when wearing a seat belt, failure to do so can affect protection provided by the seat belt.*



*Seat belts should not be wrapped around hard or sharp objects such as pens, spectacles or keys.*



*Seat belts can not function correctly when the seats are reclined excessively. DO NOT drive when the seats are excessively reclined.*

In order to maintain effective protection, the passengers must sit in the correct orientation, feet placed on the floor in front of them, with an upright body (no excessive recline) and the seat belt correctly fastened.


The seat belts fitted to your vehicle are designed for use by normal sized adults. This part of the literature refers to adult use. All seat belts are 3 point lap-diagonal belts.




## Fastening Seat Belts

Please follow the instructions below to fasten the seat belts correctly.

- 1 Adjust the seat correctly.



- 2 Hold the metal tab, pull the seat belt out steadily over the shoulder and across your chest. Ensure there are no twists on the belt.




- 3 Insert the metal tab into the buckle until you hear a 'click', this indicates the seat belt is securely locked.
- 4 Remove any slackness in the belt by pulling up on the diagonal section of the belt.
- 5 To release the seat belt, press the red button on the buckle. The seat belt will retract automatically to its original place.

### Correct Routing of the Seat Belts



**Ensure the seat belt is correctly positioned on the body, NEVER cross the neck or abdomen, NEVER pass the seat belt behind the back or under the arms.**



When wearing seat belts, the lap belt section should be positioned as low as possible across your hips, never across the abdomen. In the event of a collision, the lap belt can apply a force on the hips and reduce the possibility of you slipping under the lap belt. If you slip under the lap belt, the belt will apply force on your abdomen, which may cause serious or fatal injuries. The diagonal section of the belt should cross the middle of the shoulder and the chest. In the event of emergency braking or collision, the diagonal section of the belt will be locked.

To ensure that the seat belts always provide maximum protection, ensure the belt is flat, not loose and contacts the body.

### Seat Belts Use during Pregnancy

Wearing correctly positioned seat belts will provide protection for both mother and unborn child in the event of a collision or emergency braking. The diagonal section of the seat belt should pass across the chest as normal, the lap section of the belt should pass below the belly, low and snug on the hip bones. **NEVER** position the belt on or above the belly. Please consult your physician for further details.



Please consult your physician for further details.

## Seat Belts and Disabilities

It is a legal requirement that all occupants wear seat belts, this include people with disabilities.

Depending upon the disability, consult your physician for further details.

## Children and Seat Belts



*Only recommended child restraints suitable for the age, height and weight of the child should be used.*

For safety reasons, children must travel in a child restraint device fixed to the rear seat.

## Infants



**Only recommended child restraints suitable for the age, height and weight of the child should be used.**



**NEVER carry a child or infant with your arms during driving. When collision accidents occur, the weight of the child will produce so great of a force that you will not be able to hold on to the child. The child will be thrown forward and suffer serious injury or even death.**


The seat belts fitted to your vehicle are designed for adults, they are not suitable for children. In the event of an accident or collision the children are not secure, it could cause death or serious injury.

Infants **MUST** use a suitable child restraint device. Please consult the child seat manufacturer's guidelines when selecting the correct seat. Follow the manufacturer's instructions on installation. Please refer to "Child Restraints" in this chapter for more details.

## Older Children



**NEVER share a seat belt amongst children. In the event of an accident or collision, the children are not secure. It could cause death or serious injury.**



As children grow and become older/larger it will get to the stage when they no longer require child seat restraints, at this point they will require use of the vehicle standard seat belt. Please ensure the seat belt is correctly positioned on the body of the child.

When fastening a seat belt for a child always check it for correct positioning. Adjust the height of seat belt to

ensure the shoulder belt is kept away from the child's face and neck. Position the lap belt across the hips as low as possible, and tighten adequately. Correct positioning means that the seat belts can pass the applied force to the strongest part of child's body in accidents.

If the shoulder belt is too close to child's face or neck, it may be necessary to use a child booster cushion (always ensure that it meets any relevant laws or standards).

### Seat Belt Pre-tensioners



***The seat belt pre-tensioners will only be activated once and then MUST BE REPLACED. Failure to replace the pre-tensioners will reduce the efficiency of the vehicle's restraint system.***



***If the pre-tensioners have been activated, the seat belts will still function as restraints, and must be worn in the event that the vehicle remains in a drivable condition. The seatbelt pre-tensioners should be replaced at the earliest opportunity by an MG Authorised Repairer.***

The vehicle is fitted with seat belt pre-tensioners. These are designed to retract the seat belts and work in conjunction with the airbags in the event of a severe collision. They are designed to retract the seat belt and 'secure' the occupant in the seat.

The airbag warning light on the instrument pack will alert the driver to any malfunction of the seat belt pretensioners. see ('Warning Lights and Indicators' in the 'Instruments and Controls' chapter).

The seat belt pre-tensioners can only be activated once. After activation they must be replaced. This may also involve replacement of other SRS components. Please refer to 'Replacing Airbag System Parts'.

## IMPORTANT

- Seat belt pre-tensioners will not be activated by minor impacts.
- The removal or replacement of a pre-tensioner must be carried out by the technicians trained by the manufacturer.
- 10 years from the initial date of registration (or installation date of a replacement seat belt pre-tensioner), some components will need to be replaced. The appropriate page of the Service Records must be signed and stamped once the work has been completed.

## Seat Belt Checks, Maintenance and Replacement

### Seat Belt Checks



*Split, worn or frayed seat belts may not function correctly in the event of a collision, if there are any signs of damage, replace the belt immediately.*



*Always ensure the red release button on the seat belt buckle is pointing upwards ensure easy release in the event of an emergency.*

Please follow the instructions below to check the seat belt warning light, seat belt, metal tab, buckle, retractor and fixing device regularly:

- Insert the seat belt metal tab into the corresponding buckle and pull seat belt webbing close to the buckle quickly to check that the belt clasp locks.
- Hold the metal tab and pull the seat belt forward quickly to check that the seat belt reel locks automatically, preventing the webbing from extending.
- Fully extract the seat belt and visibly examine for twists, fraying, splits or worn areas.

- Fully extract the seat belt and allow to return slowly to ensure continual and complete smooth operation.
- Visibly examine the seat belt for missing or broken components or components that may affect the normal operation.
- Ensure the seat belt warning system is fully functional.

If the seat belt fails any of the above tests or inspections, contact an MG Authorised Repairer immediately for repairs.

## Seat Belt Maintenance



***DO NOT attempt to remove, install, modify, disassemble or dispose of the seat belts. Have any necessary repairs carried out by an MG Authorised Repairer. Inappropriate handling may lead to incorrect operation.***



***Ensure no foreign or sharp objects become lodged in the seat belt mechanisms. DO NOT allow liquids to contaminate the seat belt buckle, this could affect the buckle engagement.***

Seat belts should only be cleaned with warm soapy water. Never use any solvent to clean the seat belt. Never attempt to bleach or dye the seat belt, otherwise the strength of the seat belt will be severely weakened. After cleaning, wipe with a cloth and allow to dry. Never allow the seat belt to fully retract before it is completely dry. Keep seat belts clean and dry.

If there are contaminants accumulated in the retractor, the retraction of seat belt will be slow. Please use a clean and dry cloth to remove any contaminants.

## Seat Belt Replacement



***Collision accidents may damage the seat belt system. The seat belt system may not be able to protect users after damage, which may result in serious injury or even death. After an accident, seat belts should be checked and replaced as needed immediately.***

Seat belts should not require change after minor collisions, however, some other parts of the seat belt system may require attention. Please consult an MG Authorised Repairer for advice.



## Airbag

### Overview



*The airbag SRS provides ADDITIONAL protection in a severe frontal impact only. It does not replace the need or requirement to wear a seat belt.*




*The airbags together with the seat belts provide optimum protection for adults, but it is not the case for infants. The seat belt and airbag systems in the vehicle are not designed for protecting infants. The protection required by infants should be provided by child restraints.*

In the corresponding position where airbags are fitted, there is a warning sign stating ' AIRBAG '. Generally, SRS contains the following components (the components are not completely the same according to different model and configuration):

- Frontal airbags (fitted in the centre part of the steering wheel and the instrument panel above the glove box respectively)

- Side airbags (fitted in the outer seatback cushion of the two front seats)\*
- Side curtain airbags (fitted in the roof interior trim)\*



### Airbag Warning Lamp



The airbag warning light is located in the instrument pack. If this lamp does not extinguish or illuminates during driving, it indicates that there is a failure in the SRS or seat belt. Please seek an MG Authorised Repairer at the earliest opportunity. An SRS or seat belt

fault may mean the components may not be deployed in the event of an accident.

### Airbag Deployment



*Front seat passengers should not place feet, knees or any other part of the body in contact with, or in close proximity to a front airbag.*



*To minimise the risk of accidental injury from inflating airbags, seat belts should be worn correctly at all times. In addition, both driver and front passenger should adjust their seat to provide sufficient distance from the frontal airbags, so as to avoid severe or even fatal injury when the airbag is deployed. If side airbags and side head impact protection airbags are fitted, both driver and front seat passenger should be seated to maintain sufficient distance from the upper part of the body to the sides of the vehicle, this will ensure maximum protection when the side airbags/side head impact protection airbags are deployed.*



*An inflating airbag can cause facial abrasions and other injuries if the occupant is too close to the airbag at the time of its deployment.*



*When airbags are deployed, children without proper protection may suffer from serious injury or even death. DO NOT carry children in the arms or on the knees during traveling. Children should wear seat belts suitable to age. DO NOT lean out of windows.*



*After deployment, the relative airbag components will become very hot, such as the steering wheel, instrument panel and both sides of the roof rails . DO NOT touch any airbag related components after airbag deployment, it may cause burns or serious injury.*



*DO NOT knock or strike the position where any airbag related parts are located, so as to avoid accidental airbag deployment which may cause serious injury or even death.*



*DO NOT affix or place any objects on, or adjacent to the airbags. This may affect the airbag passage or create projectiles that may cause injury or serious harm in the event of airbag deployment*

In the event of a collision, the airbag control unit monitors the rate of deceleration or acceleration induced by the collision, to determine whether the airbags should be deployed. Airbag deployment is virtually instantaneous and occurs with considerable force, accompanied by a loud noise.

In the event of a severe frontal collision, a completely deployed airbag, along with a correctly worn seat belt, can limit the movement of the driver and front passenger, reducing the risk of head and chest injuries. For vehicles fitted with side airbags and side curtain airbags, when the vehicle encounters a serious side collision, the completely

deployed airbag will form a cushion of air between the occupant and the vehicle side to reduce the risk of body side injuries.

Provided the front seat occupants are correctly seated and with seat belts properly worn, the airbags will provide additional protection to the chest and facial areas in the event of the car receiving a severe frontal impact.

### IMPORTANT

- Airbags cannot protect lower body parts of passengers.
- Airbags are not designed for rear collision, minor frontal collision or if the vehicle rolls over, nor will it operate as a result of heavy braking.
- Deployment and deflation of the airbags takes place very quickly and will not protect against the effects of a secondary impact if it occurs.
- When an airbag inflates, a fine powder is released. This is not an indication of a malfunction. However, the powder may cause irritation to the skin and should be thoroughly flushed from the eyes and any cuts or abrasions of the skin. If your skin, eyes, nose or throat etc feels uncomfortable, please consult a doctor.
- After inflation, front and side airbags deflate immediately. This provides a gradual cushioning effect for the occupant and also ensures that the driver's forward vision is not obscured.

## Frontal Airbags



**NEVER use a rearward facing child restraint on a seat protected by an ACTIVE AIRBAG in front of it, DEATH or SERIOUS INJURY to the CHILD can occur. Refer to 'Disabling the Passenger Airbag'.**



**Front seat passengers should not place feet, knees or any other part of the body in contact with, or in close proximity to a front airbag.**




**In extreme cases driving on very uneven surfaces may cause airbag deployment. Please take extra care when driving on uneven roads.**


For some models, the passenger side airbag can be turned off through the switch on the entertainment display screen.

Airbags are designed to deploy during serious impacts, the following conditions may cause airbag deployment.

- A frontal collision with unmovable or non deformable solid objects at a high speed.



- Conditions that can cause serious chassis damage, such as a collision with kerbstones, road edges, deep ravines or holes.




## Side Airbags\* and Side Curtain Airbags\*



*The structure and material of the seat is critical to the correct operation of side airbags. Therefore, please DO NOT fit seat covers which may affect side airbag deployment.*

In the event of a serious side impact, the relevant side airbag will deploy from the seat cover and the side curtain airbags will deploy from the roof interior trim (only the affected side). The other side will not deploy. The conditions described below (or similar) may cause side airbag and side curtain airbag deployment.

- One side of the vehicle collides with high-speed ordinary passenger car.




## Conditions in Which Airbags Will Not Deploy

The deployment of airbags does not depend on the vehicle speed, but on the object that the vehicle hits, angle of impact and the rate at which the car changes speed as a result of a collision. When the impact force of collision is absorbed or dispersed to vehicle body, airbags may not deploy; however, airbags may sometimes deploy according to impact condition. Therefore, the deployment of airbags shall not be judged based on the severity of vehicle damage.





### Frontal Airbags

Under certain conditions the front airbags may not be deployed. Some examples are listed:

- The impact point is not central to the front of the vehicle.
- The impact is with a solid utility pole or traffic sign post.



- The impact area is high (collision with the tailgate of a truck).
- Frontal collision at an angle with guardrails.







### Side Airbags\* and Side Curtain Airbags\*

Under certain conditions the seat side and side head airbags may not be deployed. Some examples are listed:


- Side impacts at certain angles.
- Light side impacts such as with a motorcycle.





- Impacts that are not central to the side of the vehicle, either too far toward the front compartment or the loadspace.
- Side impact on boot.
- The vehicle rolling over.



- Frontal collision at an angle with guardrails.
- The angled impact is not of sufficient force (the impact is with an object that is not solid, such as a lamp post or central barriers)



- The impact is not of sufficient force (with another vehicle, stationary or moving).
- The impact is from the rear of the vehicle.



### Front Passenger Airbag Prohibition Switch\*





*This switch can be used to deactivate the front passenger side airbag only when a rearward-facing child restraint is installed on the front passenger side seat.*



*When an adult is seated in the front passenger side seat, please ensure that the front passenger side airbag is switched on.*

The airbag prohibition switch is in the intelligent display screen. The passengerside airbags can be activated or deactivated through the relevant buttons on this screen.

- 
 When the passenger airbag is disabled, the OFF indicator light illuminates.
- 
 When the passenger airbag is enabled, the ON indicator light illuminates for a period of time.

#### IMPORTANT

- If the OFF and ON indicator lights illuminate together, or the light is inconsistent with the passenger airbag switch position, Please contact an MG Authorised Repairer immediately.

## Service and Replacement of Airbags

### Service of SRS components



*DO NOT install or modify the airbag. Any changes to the vehicle structure or airbag system wiring harness are strictly prohibited.*



*Changes to vehicle structure is prohibited. This may affect the normal operation of the SRS.*



*DO NOT allow these areas to be flooded with liquid and DO NOT use petrol, detergent, furniture cream or polishes.*



*If water contaminates or enters the airbag system, it may cause damage and affect deployment. In this case, even if the collision does not occur, the airbag may accidentally deploy. Immediately shut down the power system and disconnect the battery cable; do not try to start the power system. In this case contact an MG Authorised Repairer immediately.*

If the airbag warning lamp fails to illuminate or remains on, or there is any damage in the front or side of the vehicle and the cover of airbag module has any sign of damage, contact an MG Authorised Repairer immediately.

## IMPORTANT

- The removal or replacement of an airbag module should be carried out by an MG Authorised Repairer.
- After 10 years from the initial date of registration (or installation date of a replacement airbag), some components will need to be replaced by an MG Authorised Repairer. The appropriate page of the Service Portfolio must be signed and stamped once the work has been completed.

## Replacing Airbag System Parts



***Even if the airbag does not deploy, collisions may cause damage to SRS in the vehicle. Airbags may not function properly after damage and can not protect you and other passengers when a second collision occurs, which may cause serious injury or even death. To ensure that SRS can function properly after collision, please go to an MG Authorised Repairer to check airbags and repair as necessary.***

Airbags are designed for using once only. Once the airbag has deployed, you must replace SRS parts. Please go to an MG Authorised Repairer for replacement.

## Disposal of Airbags

When your vehicle is sold, ensure that the new owner knows the vehicle is equipped with airbags and is aware of the replacement date of SRS.

If the vehicle is scrapped, the undeployed airbags may have potential risks, therefore, before the disposal, they must be

deployed safely in a certain environment by a professional agency or an MG Authorised Repairer.

## Child Restraints

### Important Safety Instructions about Using Child Restraints

Children under the age of 12 years are recommended to be seated in the rear seats. Compared with adults, children's muscles and bones do not fully develop, so you need to use dedicated child restraints to protect children. Use child restraints in rear seats to protect children based on the child's age, height and weight.

Only child restraints that comply with relevant regulations or standards (such as EU regulations ECE-R44 and ECE-R129 ) are permitted to be used in this vehicle. When choosing a child restraint, check relevant marks or instructions about the weight range applicable for the child restraint and the usage message on it.

When installing and using a child restraint, it is necessary to comply with relevant laws and regulations, the instructions supplied by the child restraint manufacturer and the instructions on children's safety in this Handbook.

The correct use of child restraints will greatly reduce injury risk in accidents or relieve the severity of any

potential injuries, and please pay attention to the following statements when you use child restraints:

- All children must use an appropriate child restraint.
- It is recommended that children shorter than 1.5 metres (or under 12 years of age) should use the appropriate child restraint and cannot use a regular seat belt, otherwise it may cause injury to the abdomen and neck .
- Never let your children ride in unprotected case. Care should not be neglected because of children sitting on the child restraint.
- Only one child may be carried in any one restraint.
- DO NOT put the child on the lap or in arms when sitting in any seat.
- Proper child restraint can provide protection for your children.
- The backrest angle of the 2nd-row seat is adjustable, so when you install the child restraint onto the 2nd-row seat, adjust the backrest angle to the appropriate position and lock it up.
- Relevant front seat may need to be adjusted frontward or the rear seat to be adjusted backward for installing the rear facing child restraint to the rear seats.

- The position of seat head restraints may need to be adjusted for installing the forward facing child restraint to the rear seats.
- Never let your child stand or kneel on the seat when driving, otherwise, your child may be tossed and thus injury to themselves and other people or even death may be caused when an accident occurs.
- If a child's body leans forward or the posture is not correct during driving, then the accident will increase the risk of injury.
- The method of using seat belts has a great influence on the maximum protection offered by the seat belt, and you must comply with the child restraint manufacturer's instructions on proper use of seat belts. If seat belts are not properly fastened, even a minor traffic accident may lead to injury.
- Child restraints that are not fitted correctly may move and injure other occupants in the event of an accident or emergency braking. Therefore, even if there is no infant or child in the child restraint, it should be fitted properly and securely in the vehicle.

## Warnings and Instructions on Use of Child Restraint on Front Passenger Seat



**NEVER** use a rearward facing child restraint on the front passenger seat with the front passenger airbag activated, otherwise **DEATH** or **SERIOUS INJURY** to the **CHILD** may occur.



**Use one child restraint per child.**

Please carefully read the safe driving warning label on the sun visor. Always install the child restraint in the rear seat

for security reasons. The above warning shall be noted in a special case when the child restraint must be used on front passenger seat.

## Important Instructions on Children's Safety and Side Airbags



**Children should not be allowed in areas where side airbags may be deployed, there is a risk of serious injury.**



**Only recommended child restraints suitable for the age, height and weight of the child should be used and firmly fixed in the vehicle.**



**DO NOT place any items in areas where side airbags may be deployed, there is a risk of serious injury.**

In the event of a side collision, the side airbags can provide better protection for the passenger. However, when the airbag is triggered, a very strong expansion force is generated, if the passenger's seating position is not correct, the airbags or items in the side airbag deployment area may cause injury.




Therefore, the correct child restraint shall be used to secure the child properly in the rear seat and ensure the child's seating position is correct and there is enough space between the child and the side airbag deployment area for the airbag to deploy without any hindrance in a traffic accident and thus provide the best protection.

## Fixing Child Restraints

### Secured Using Lap and Shoulder Belts



***Please DO NOT put the rearward facing child restraint on the front passenger seat with the front passenger airbag activated, this may cause serious injury or even death.***



The child restraint can be secured to the rear seat by the lap and shoulder belts.

## Secured with ISOFIX Device



### WARNING

*The ISOFIX anchorages in the rear seat are designed for use with ISOFIX systems only.*




### WARNING

*Child restraint anchorages are designed to withstand only those loads imposed by correctly fitted child restraints. Under no circumstances are they to be used for adult seat belts, harnesses, or for attaching other items or equipment to the vehicle.*

The 2nd-row seats of this vehicle on both sides are provided with ISOFIX interface (as indicated by the arrow in the figure below) connected to the ISOFIX child restraint. When installing and removing any child restraint system, always follow the manufacturer's instructions.



- Insert the tapered plastic sleeve into ISOFIX anchor between the seat cushion and backrest.
- Push the ISOFIX attachment of the child restraint into the tapered plastic sleeve already fitted and snag it in the ISOFIX anchor.



- After the installation, push or shake the child restraint with moderate force to confirm it is properly secured.

- The Top-tether (as arrowed in the figure above) for auxiliary fixation of the child restraint is provided at the back of the rear seat backrest. The single top-tether of the child restraint must pass through space between the rods of the rear seat headrest and dual tether must pass from both sides of the rear seat headrest.

**Note:** *When using seat mounted, universally approved child restraint systems, the top tether must be used.*

## Child Restraint Groups and Installation Position

Only approved child restraints suitable for children are allowed. Children taller than 1.5 metres may directly use the seat belts in the vehicle. Child restraints shall comply with relevant regulations or standards, such as EU regulations ECE-R44 and ECE-R129 .

### Approved Child Restraint Positions

Only approved child restraints suitable for children are allowed. Children higher than 1.5m may directly use the seat belts in the vehicle. It is recommended that a child restraint system that complies with UN ECE-R44, ECE-R129 is fitted in this vehicle.

Mass Group	Seating Position		
	Front Passenger	2nd-row Outboard	2nd-row Centre
Group 0 (up to 10 kg)	X	U	U
Group 0+ (up to 13 kg)	X	U	U
Group I ( 9 to 18 kg)	X	U <sup>1</sup>	U <sup>1</sup>
Group II ( 15 to 25 kg)	X	U <sup>1</sup>	U <sup>1</sup>
Group III ( 22 to 36 kg)	X	U <sup>1</sup>	U <sup>1</sup>

Note: Description of letters in the table: U = Suitable for universal child restraint systems approved for this mass group; X = Seat position not suitable for child restraint systems in this mass group.

<sup>1</sup> If the child restraint interferes with the headrest during the installation, please adjust the headrest to the highest position. If the interference persists, please remove and store the headrest properly.

## Approved Child Restraint Positions (for ISOFIX Child Restraints)

Fixing Position		Mass Group					
		Group 0	Group 0+	Group I <sup>1</sup>		Group II <sup>1</sup>	Group III <sup>1</sup>
		Rear-facing		Forward-facing	Rear-facing	Forward-facing	Forward-facing
		Up to 13 kg		9~18 kg		15~25 kg	22~36 kg
Front Passenger	Size Class	No ISOFIX Equipped					
	Type of Child Restraint						
ISOFIX on both sides of the 2nd row	Size Class	C, D, E <sup>2</sup>	A, B, BI <sup>2</sup>	C, D <sup>2</sup>	-	-	
	Type of Child Restraint	IL	IL, IUF	IL	IL	IL	
2nd-row Centre	Size Class	No ISOFIX Equipped					
	Type of Child Restraint						

Note: IL = suitable for particular ISOFIX child restraints of the semi-universal category in the list. Please refer to the vehicle list recommended by child restraints manufacturer;

IUF = suitable for forward-facing ISOFIX child restraints of universal category approved for use in this mass group and ISOFIX size class;

<sup>1</sup> If the child restraint interferes with the headrest during the installation, please adjust the headrest to the highest position. If the interference persists, please remove and store the headrest properly;

<sup>2</sup> The ISOFIX size class for both universal and semi-universal child restraints is defined by the capital letters A to G . These identification letters are displayed on the ISOFIX child restraints.

### I-Size Child Restraint Table

This table provides recommendations for the installation position of I-Size child restraint and the suitability of the corresponding child's size.

Type of Child Restraint	Front Passenger Seat	Rear Outboard	Rear Centre
I-Size Child Restraint	X	I-U	X
Booster Child Restraint	X	I-B	X

Note: I-U means it is suitable for forward-facing or rear-facing I-Size child restraint;

I-B means it is suitable for the following: forward-facing Group II/III ISOFIX Booster child restraint and forward-facing I-Size child restraint for the child with height of 100-150 cm (about 39-59 inches);


X means it is not suitable for I-Size child restraint.

**Note:** It is recommended that children at the age of 18 months should use Britax Baby Safe child restraint, children at the age of 3 use Duo Plus child restraint, and children at the age of 6 use Kidfix III S child restraint. The seat belt guide (safety protective device) and side connector extension piece shall be used. The side connector extension piece shall be extended to the outermost side when in use. Children at the age of 10 are recommended to use Nania Dream child restraint.

## Group 0/0+ Child Restraint



*Never place a rearward facing child restraint on the front passenger seat with the front passenger airbag activated.*



Child restraint that can be adjusted to lying position are the optimum selection for infants with a weight below 10 kg (usually corresponding to the infants younger than 9 months) or the infants with a weight below 13 kg (usually corresponding to the infants younger than 24 months).

## Group I Child Restraint



*Never place a rearward facing child restraint on the front passenger seat with the front passenger airbag activated.*



Rear-facing child restraints are most suitable for infants whose weight is 9 ~ 18 kg (normally for those older than 9 months and younger than 4 years old). Forward-facing child restraints may also be used.



### Group II Child Restraint



*The diagonal section of the seat belt should pass across the shoulder and upper body, away from the neck. The lap section of the belt should pass across the hips, away from the abdomen.*



The combination of child restraint and lap-shoulder belt is most suitable for children whose weight is 15 ~ 25 kg (normally for those older than 3 years old and younger than 7 years old).

### Group III Child Restraint



*The diagonal section of the seat belt should pass across the shoulder and upper body, away from the neck. The lap section of the belt should pass across the hips, away from the abdomen.*




The combination of child booster seat and lap-shoulder seat belt is most suitable for children whose weight is 22 - 36 kg and whose height is below 1.5 m (normally for those about 7 years old or those older than 7 years old).

## Child Proof Locks



**NEVER leave children unsupervised in the car.**



### Steps for enabling or disabling the child proof locks are as follows:

- Open the relevant rear door, move the lever in the direction of the arrow to engage the childproof lock.

- Move the lever to the unlock position in the reverse direction of the arrow to disable the child proof lock. With the child proof lock engaged, the rear door on the corresponding side cannot be opened from inside the car, but can be opened from outside the car.

## Body Stability Control System

### Body Stability Control System


The body stability control system includes Dynamic Stability Control System ( SCS ) and Traction Control System ( TCS )

SCS is designed to assist the driver in control of driving direction. When SCS detects that the vehicle is not moving in the intended direction, it will intervene by applying brake force to selected wheels or through the drive system to prevent sliding and stabilise the driving direction by correcting the under-steering or over-steering.

TCS contributes to maintaining the control to the vehicle by improving the vehicle's traction trafficability and driving stability. TCS monitors the driving speed of each wheel individually. If spin is detected on one wheel, the system will automatically brake that wheel, transferring torque to the opposite, non-spinning wheel. If both wheels are spinning, the output torque of the drive system will be reduced in order to regulate wheel rotation until traction is regained.

SCS and TCS are automatically switched on when the vehicle is powered on. For CVT model, they can be switched off by using the switch located on the entertainment display. For MT model, they can be switched off by using the switch located on central armrest box.

If the switch locates on the central armrest box, the position as shown:



**Note:** *Disabling SCS and TCS will not affect the operation of ABS . Always disable SCS and TCS when driving with snow chains fitted.*

**Resuming the body stability control system**

After a battery disconnection/reconnection, the body stability control warning lamps will illuminate and the dynamic stability control/traction control system will not work correctly.

In this case, the electric power steering (EPS) will require initialisation, i.e., move the steering wheel from lock to lock. The electric power steering (EPS) warning lamps and the body stability control warning extinguish, and the dynamic stability control/traction control system will be reinstated.

## Anti-lock Brake System (ABS)



*When travelling at high speed or there is a danger of aquaplaning, i.e. where a layer of water prevents adequate contact between the tyres and the road surface, ABS cannot overcome the physical limitations of stopping the car in a short distance. In these cases, it is the responsibility of the driver to maintain a safe distance from other vehicles.*



*When travelling at high speed or there is a danger of aquaplaning, i.e. where a layer of water prevents adequate contact between the tyres and the road surface, ABS cannot overcome the physical limitations of stopping the car in a short distance. In these cases, it is the responsibility of the driver to maintain a safe distance from other vehicles.*



*DO NOT pump the brake pedal at any time, this will interrupt the operation of ABS and may increase the braking distance.*

The ABS is mainly used to automatically adjust the braking force of each brake to prevent the wheels from being locked, thus avoiding dangerous situations such as loss of direction or side slip during emergency braking.

This system enables the driver to maintain control over the steering in case of emergency braking, keeping the vehicle stable, and improving safety.

Under normal braking conditions, ABS will not be activated. However, if the braking force exceeds the adhesion between the tyres and the road surface, causing the wheels to lock, the ABS will automatically come into operation. This will be recognisable by a rapid pulsation felt through the brake pedal.

If an emergency situation occurs, the driver should apply full braking effort to trigger the ABS even when the road surface is slippery.

**Note:** *On soft surfaces such as powdery snow, sand or gravel, vehicles equipped with ABS may have a braking distance greater than those without ABS. This is because the natural action of locked wheels on soft surfaces is to build up a wedge of material in front of (or to the side of, if steering) the tyre contact patch. This effect assists the car to stop when braking or to change direction when steering.*

### IMPORTANT

- Although ABS can greatly improve driving safety, the real safety still depends on the driver's own standard driving behavior.
- The normal braking system remains fully operational and is not affected by partial or full loss of anti-lock braking system ( ABS ).

---

## **Auxiliary Brake System**

The auxiliary brake system consists of Electronic Brake Force Distribution System ( EBD )<sup>\*</sup>and Electronic Brake Assistance System ( EBA ).

The EBD <sup>\*</sup>automatically distributes the braking force between the front and rear wheels, so that the vehicle can have optimum braking performance under different load conditions.

The EBA increases the braking force applied on each wheel during emergency braking to assist the driver in quickly triggering ABS , thereby reducing the braking distance.

## Auto Hold\*



*The auto hold function cannot guarantee the stability of the vehicle when starting off or braking on hills especially on slippery or icy surfaces.*



*When auto hold stops the vehicle, for reasons such as engine shut-down, releasing the seat belt or pressing the auto hold switch, the electronic parking brake is applied. It cannot be guaranteed that the vehicle will be stabilised in all cases. For example, the rear wheels are on a slippery road surface, or the vehicle incline is too great (larger than 20%). Please make sure that the vehicle is safely stabilised prior to exiting.*



*DO NOT leave the vehicle when the engine is operating and the auto hold is active.*



*Auto hold cannot guarantee the electronic parking brake operation in all cases where the ignition system is shut down. Please ensure the electronic parking brake is applied and the vehicle is stabilised prior to exiting the vehicle.*



*The auto hold function should be switched off during the use of automatic car washes, the electronic parking brake may suddenly apply and cause vehicle damage.*

If the vehicle is required to stop frequently for long periods while driving (such as wait at the traffic lights, stop on a slope or in urban stop-and-go conditions), the Auto Hold function can assist you in stabilising the vehicle, enabling you to remove your foot from the brake pedal when the vehicle is stationary and the Auto Hold is active.

Auto Hold has 3 states as follows:

The Auto Hold Switch is located on the entertainment display screen.

I Standby:



With the driver's seat belt fastened, the door closed and the power system running, press the Auto Hold switch to switch the function from Off to Standby state. The indicator of Auto Hold Switch illuminates.

## 2 Operating:

When the vehicle is moving forward, depress the brake pedal to a certain depth. After the vehicle is fully stopped, the Auto Hold function is switched from Standby to Parking state. In this state, the green indicator (P) on the instrument panel illuminates.

When the Auto Hold is in the Parking state, engaging D gear and depressing the accelerator pedal will automatically release the Auto Hold function based on the slope.

The Auto Hold will release from the Parking state if R gear is selected.

## 3 OFF:

Press Auto Hold switch again to disable the function.

The Auto Hold will exit the parking state under some circumstances such as releasing the seat belt, turning off the power system, remaining static for a length of time or

pressing the Auto Hold switch. At this time, the EPB will be applied.

**Note: With the brake pedal pressed, operating the switch to turn the auto hold off, the system will NOT apply the parking brake.**

**Note: When the vehicle is in P gear, the auto hold function will not be engaged.**

## Hill Hold Control (HHC)



*It is impossible for HHC to keep the vehicle in a standstill state under all circumstances (e.g. slippery ground, snow and ice, etc.) when going uphill and the driver must constantly pay attention to the vehicle condition.*



*With the HHC in service, the driver is strictly prohibited from leaving the vehicle, otherwise serious accidents may occur.*



*During hill start under a stop-and-go road condition, please step on the brake pedal deeply for several seconds before each start.*

HHC assists the driver by 'holding' the vehicle during hill starts. If the driver releases the brake pedal, the HHC will hold the vehicle stationary for a short time.

The HHC will be activated when the following conditions are met simultaneously:

- The driver's seat belt has been fastened and the driver's door is closed.
- The vehicle is stopped steadily on a slope.
- SCS is fault free.
- EPB / manual parking brake is fault free and released.
- The power system is started.
- In D or R gear.
- Sufficient force has been applied on the brake pedal before start.

**Note:** *The HHC can also work when the vehicle is reversing uphill.*

## Hill Descent Control (HDC)



*HDC is just an auxiliary function, which cannot ensure that the vehicle is driven down a steep slope at low speed under all circumstances (such as slippery ground, snowy road surface or excessive slope, etc.).*



*Even when HDC is in use, the driver shall still pay close attention to the driving state of the vehicle and take active control when necessary. In certain cases, HDC may remove itself from the operating state temporarily.*




*Under some driving conditions on downhill surfaces (e.g. driving down a slope with high speed, small slope, etc.), HDC is inoperative, so the driver shall be required to control the speed by depressing the brake pedal to ensure the safe driving.*

*Note: When the HDC is working, it is normal for the brake system to generate slight vibration or working noise.*



*Note: When the HDC is working, do not shift to N gear, since this operation will deactivate the HDC function.*

HDC system is an auxiliary function designed for vehicles running on acute downhill surface. It reduces the speed by applying the brake force, thus assists the driver to drive on acute downhill surface smoothly.

HDC is disabled by default. After the vehicle is powered on, for the CVT model, HDC can be turned on by setting it on the entertainment display screen\*. For the MT model, the function can be enabled by operating the switch as shown in the figure.



HDC system has four states as follows:

- 1 Standby:  
Press HDC switch to enable the function and enter into standby state. In this state, the indicator  on the instrument pack illuminates in green.
- 2 Parking:  
In Standby mode, when the vehicle drives on the acute downhill surface at low speed, if the driver does not depress the brake pedal or the accelerator pedal, HDC automatically enters the Operating state. Meanwhile, when the indicator  on the instrument pack flashes in green, which may be accompanied by the working noise of the brake system and the vehicle drives down the acute downhill surface smoothly.
- 3 Temporary Deactivation:  
Depress the accelerator pedal or brake pedal to a certain extent in Operating state, HDC will temporarily remove itself from the parking state.
- 4 OFF:  
Press HDC switch again to disable the function.

**Note:** *When the vehicle makes a sharp turn on a certain slope, HDC may switch from Standby to Operating.*

**Note:** *With HDC operative, the brake system will automatically pressurise and hold. You will be responded with a certain pressure feedback when depressing the brake pedal at this time which is normal.*

## **Active Rollover Protection (ARP)**

### **Active Rollover Protection ( ARP )**

The ARP system is a driver aid to assist the stability of the vehicle. It is not a guarantee that the vehicle will not roll over.

When the vehicle is at risk of a rollover during dynamic driving (such as lane change) or steady driving (such as loop driving), the ARP will automatically brake the outside wheels to cause the vehicle to understeer and prevent rollover.

***Note: With ARP in use, the vehicle under-steers and it is normal if it fails to steer in accordance to driver expectations.***

## Emergency Braking Hazard Warning Strobe (HAZ)\*

If the driver makes an emergency braking manoeuvre and certain conditions are met while driving, the brake lamps will automatically flash to alert the drivers behind, thereby reducing the risk of rear-end collision accidents.

**Note:** *If the hazard warning lamps are being operated manually, this suspends the HAZ function.*

When the emergency braking manoeuvre is exited, the HAZ function will be switched off after a few seconds.

**Note:** *As the car speed drops to below 6 mph (10 km/h) and the system no longer flashes the brake lamps, the hazard warning lamps will illuminate automatically. Short press the hazard warning lamp switch or increase your speed to above 12 mph (20 km/h) for 5 s to switch off the hazard warning lamps.*

---

## **Multi-Collision Brake System (MCB)\***

The MCB function will automatically apply the brake to reduce the vehicle speed and improve the vehicle stability after a collision. It is designed to reduce the risk of a secondary collision caused by the uncontrolled movement of the vehicle after a collision.

The MCB will be activated when the following conditions are all met at the same time:

- A vehicle collision where airbags are deployed;
- The vehicle speed is less than 32 miles/h ( 60 km/h);
- The steering wheel has not been turned in excess of 180° ;
- SCS is fault free.

If the driver firmly presses the accelerator pedal after the MCB function is triggered, the system will exit the braking state.

***Note: The MCB function cannot decelerate the vehicle in all cases of collision due to the fact that the collision process may cause some parts to malfunction or fail and affect the normal operation of the function.***



---

## **Pedestrian Alert System\***

In order to improve the safety, your car is fitted with a Pedestrian Alert System. When the vehicle is travelling at a low speed, on electrical power, the system controls a speaker that sounds to remind pedestrians in the vicinity of your presence.

### **Strategies of sounding warnings**

The speaker sounds when all of the following conditions are met:

- 1 The vehicle is Ready;
- 2 The pedestrian alert system is fault free;
- 3 During acceleration, the vehicle speed is less than 18 mph (30 km/h); during deceleration, the vehicle speed is less than or equal to 15 mph (25 km/h).

## Tyre Pressure Monitoring System (TPMS)\*



***TPMS can not replace routine maintenance and checks of the tyre condition and pressure.***



***Using equipment that transmits on frequencies similar to that of the TPMS may interfere with the operation of the Tyre Pressure Monitoring System, this may illuminate a warning or register a temporary fault.***

TPMS uses pressure sensors built into tyre valves to continuously monitor pressure and transmit data to the ECU inside the vehicle using RF signals. If it deduces that the pressure of that tyre has fallen below the predefined limit of the system, the warning light in the instrument pack will illuminate (always yellow). For more information, please refer to 'Instrument Pack' in the 'Instruments and Controls' section. TPMS can remind you of low tyre pressure, but it can not replace normal tyre

maintenance. For tyre maintenance, please refer to 'Tyres' in 'Maintenance' chapter.

***Note: TPMS only gives the driver a warning when the tyre pressure is low, and it will not inflate the tyre.***



If the TPMS malfunction indicator lamp illuminates and the warning message such as 'XX Tyre Pressure Insufficient' or 'XX Tyre Pressure Low' is displayed, it is advised that you should stop the vehicle as soon as possible, check the tyre pressure and inflate the tyre to the standard pressure value. The tyre pressure label attached to the B pillar indicates the standard pressure value required by your vehicle tyres when they are cold.

Driving with under-inflated tyres may overheat and cause damage to the tyre. Over or under-inflated tyres wear out more rapidly and also have a detrimental effect on the car's handling characteristics. Under-inflated tyres increase the rolling resistance of the car which, in turn, increases power.

### TPMS Self-learning

When replacing a TPMS sensor or receiver, or performing tyre rotation, TPMS self-learning is required, some

vehicles can perform the following operations to complete self-learning:

- 1 Power off and lock the vehicle for 25 minutes.
- 2 Drive continuously for 15 minutes at a speed greater than 25 mph ( 40 km/h ) , and make more turns while driving.

**Note:** *Ensure that the TPMS sensor is an original factory component.*

**Note:** *If self-learning fails, the TPMS malfunction indicator lamp will illuminate, please try repeating the above operations.*

If you have any questions during the self-learning, please consult an MG Authorised Repairer for assistance.



## **Comfort Systems**

---


<i>Seat Adjustment</i>	<i>198</i>
<i>Ventilation System</i>	<i>202</i>
<i>A/C Control Panel-1*</i>	<i>205</i>
<i>A/C Control Panel-2*</i>	<i>206</i>
<i>A/C Control Interface</i>	<i>208</i>
<i>Radio*</i>	<i>211</i>
<i>Intelligent Display Interface*</i>	<i>214</i>

### Seat Adjustment

#### Front Seats

*Note: Due to different model configurations, the function of the front seats are not completely identical.*


#### Electric Adjustment (driver side)\*



- Forward/Rearward Adjustment  
Push the switch 1 along the direction of A to move the seat forward/rearward.
- Cushion Height Adjustment  
Pull or push the switch 1 along the direction of B to raise or lower the seat cushion.
- Backrest Angle Adjustment  
Move the switch 2 forward/backward to adjust the backrest until it reaches the desired angle.

### Manual Adjustment (With the driver side as an example)\*


Lift the handle (2) repeatedly to raise the seat cushion; and press the handle (2) repeatedly downward to lower the seat cushion.



- Forward/Rearward Adjustment  
Lift the lever (1) under the seat cushion, slide the seat into an appropriate position and release the lever. Make sure that the seat is locked in place.
- Cushion Height Adjustment\*

- **Backrest Angle Adjustment**  
Lift the handle (3) to adjust the backrest to an appropriate angle; and release the handle ensuring that the backrest is locked in position.

### Rear Seats



- **Folding Rear Seats**  
If you want to increase the luggage space, first fully lower (or remove) all the rear seat headrests, pull up

the control handle respectively on both sides and fold the seat backs forward.

**Note:** *When the rear seat headrests are not fully lowered or the front seat backrest is inclined backward excessively, the folding of the rear seat is very likely to damage the back of the front seat or the rear seat headrest.*

- **Unfolding and Locking Rear Seat Backrests**  
When unfolding the rear seat back again, pull up the back control handle to release the seats back from the locked state, push the back until it reaches the locked position, the back is locked when you hear a click.

**Note:** *When returning the rear seat backrest to the desired position, make sure that the rear seat belt is not trapped.*

### Head Restraint Operation




**Adjust the height of the head restraint so that the top of it is in line with the top of the occupant's head. This location may reduce the risk of neck injuries in the event of a collision. Do not adjust or remove the head restraints while the car is moving.**





***Do not hang anything on any head restraint or head restraint rod.***

The head restraint is designed to prevent rearward movement of the head in the event of a collision or emergency braking, thereby reducing the risk of head and neck injuries. The height of split type head restraint can be manually adjusted.




When adjusting a head restraint from a low to high position, pull the head restraint directly upward and gently press it downward after it reaches the desired height to make sure that it is locked in position. To remove the head restraint, press and hold the guide sleeve button (as

indicated by the arrow) on the left of the head restraint, then pull the head restraint upward to remove it.

When adjusting a head restraint from a high to low position, press the guide sleeve button (as indicated by the arrow) on the left of the head restraint, and press the head restraint downward; release the button after it reaches the desired height, and gently press the head restraint downward to make sure that it is locked in position.

## Ventilation System



- 1 Side Vents
- 2 Windscreen Vents
- 3 Centre Vents
- 4 Front Footwell Vents
- 5 Front Side Window Vents
- 6 Rear Vents\*


The A/C system is used to adjust the temperature, speed, humidity and cleanness of the air inside the vehicle. Fresh air is drawn in through the air intake grille under the windscreen and the A/C filter element. Always keep the air intake grille clear of obstructions such as leaves, snow or ice.

### A/C Filter Element

An A/C filter element is used to filter the air. To remain fully effective, the filter element should be replaced at the recommended service interval.


### Vents

#### Regulation of Centre Vents




Move the knob in the centre of the louvres from side to side to open or close the vent. Direct the air flow by moving the knob up and down or from side to side.

### Regulation of Side Vents




Move the knob in the centre of the louvres from side to side to open or close the vent. Direct the air flow by moving the knob up and down or from side to side.

### Regulation of Rear Vents\*




Move the knob in the centre of the louvres from side to side to open or close the vent. Direct the air flow by moving the knob up and down or from side to side.

## A/C Control Panel-I\*



- 1 A/C switch button and temperature adjustment knob
- 2 Air regulation knob
- 3 Air circulation mode adjustment button
- 4 'Face+feet' ventilation mode
- 5 'Feet' ventilation mode
- 6 'Window+feet' ventilation mode
- 7 'Face' ventilation mode
- 8 Heated rear window and exterior rearview mirror button\*
- 9 Front window Defrost/Demist mode

## A/C Control Panel-2\*



- 1 Shortcut Key to A/C On/Off
- 2 Defrost/Demist Button
- 3 Heated Rear Window Button

## Shortcut Key of A/C On/Off



Touch the A/C On/Off shortcut key to turn the A/C system on/off.

**Note:** All functions will revert to the state prior to switching off if you operate the A/C system using the A/C Control Shortcut.

## Defrost/Demist Button



Touch the Defrost/Demist button, the button indicator lamp will illuminate, and the system will enable Defrost/Demist function to clear the mist or frost on the windscreen and front windows.

Touch the Defrost/Demist button again to exit the defrost/demist function, and the system will return to the previous state.

In the defrost/demist mode, turning the cooling function on/off and switching the air circulation mode will not exit the defrost/demist mode; operating the air distribution mode will exit the defrost/demist mode.

## Heated Rear Window Button



**The heating elements on the inside of the rear window are easily damaged. DO NOT scrape or scratch the inside of the glass. DO NOT stick labels over the heating elements.**



Enable/disable the heated rear window function by touching the illustrated button. The function is enabled when the indicator illuminates and is disabled when the indicator goes out. The heated rear window function will be automatically disabled after it has been enabled for a certain period.

**Note:** *The heated rear window function will only operate when the vehicle is in the READY/RUNNING state.*

## A/C Control Interface

### System On/Off



Touch the System On/Off Button on the control interface to switch the system ON/OFF.

### AUTO A/C mode\*



Click the AUTO A/C mode button to activate the automatic air conditioning function. The system automatically adjusts the air distribution mode, air volume, etc. to achieve and maintain the set temperature.

To exit the automatic air conditioning mode, manually adjust the air distribution mode or air volume and the AUTO indicator light will turn off.

## Heat Pump Heating On/Off





Touch the A/C On/Off Touch Button to turn the A/C ON/OFF.

## Air Distribution Mode

Select the corresponding Air Distribution Mode Touch Button as required to regulate the air distribution mode.

Touch Button	Air Distribution Mode
A black square button with a white icon of a person sitting with an arrow pointing to the right, indicating air blowing towards the face.	Face Mode
A black square button with two white icons: a person sitting with an arrow pointing right (face) and a person sitting with an arrow pointing down (feet).	Face and Feet Mode
A black square button with a white icon of a person sitting with an arrow pointing down, indicating air blowing towards the feet.	Feet Mode



	Windscreen and Feet Mode
	Windscreen Mode

### Air Recirculation Mode

Touch the air recirculation mode touch button as needed to adjust the air recirculation mode.



During internal recirculation mode, the A/C system circulates the air inside the vehicle to meet the requirements of rapid cooling or heating, and at the same time, it can prevent the outside dirty air from entering the vehicle.



During the external circulation, the A/C system draws air from outside the vehicle to ensure fresh air enters the vehicle.



During the automatic circulation, the A/C system automatically adjusts the internal or external circulation according to the actual situation.

**Note:** Leaving the system in internal recirculation mode can cause the windscreen to mist. If this happens, turn on the defrost/demist mode.

### Defrost/Demist Mode\*



Touch the Defrost/Demist Mode button, the cooling switch will light up. The system will enter Defrost/Demist mode, which is used to remove fog or frost from the front windshield and front window glass.

Touch the Defrost/Demist Mode button again to exit the Defrost/Demist mode and return the system to the previous state.

In automatic Defrost/Demist mode, operating the air distribution mode will exit the automatic defrost/fog mode function.

## A/C Settings\*



Touch the A/C settings button to enter the A/C settings page, where you can customise preferred or suitable A/C operating modes.

The specific options in the air conditioning settings shall be based on the actual vehicle configuration.

## Blower Speed Control

Touch and Slide the blower speed control bar to regulate the blower speed.

## Temperature Control


Touch and Slide the temperature control bar to regulate the temperature of the air supplied by the vents.

## Radio\*

### MOGI Screen

MOGI screen can display Radio, Music, Phone, Time, Emoticons, Volume, etc.

### Steering Wheel Entertainment Control Buttons



#### 1 Infotainment/Instrument Display Button

The function adjustment button ( 1 ) is a dual-purpose button, which when pressed will switch control between the Instrument display and the Infotainment system.

FM / AM mode: Long press the Infotainment/Instrument Display Button to open or close favorites list.

#### 2 BT Phone Button

Short press to answer an incoming call, long press to end the call. The vehicle does not support direct phone calls initiated by the vehicle terminal.

On the radio AM Mode and Bluetooth phone not in use: long press to switch the radio's step length to 9KHz or 10KHz .

#### 3 Function Adjustment Button

FM / AM mode: Swipe left to switch to the previous radio station; Swipe left and keep it unchanged to search for the previous radio station; Swipe to the right to switch to the next radio station; Swipe to the right and keep it unchanged to search for the next radio station; Move upwards; Increase volume; Swipe

down to decrease volume; Short press to play/pause; Long press to save or cancel the collection.

USB Music mode: Move to the left and move to the previous track; Swipe to the left and keep it unchanged, rewind quickly; Swipe to the right for the next song; Swipe to the right and keep it unchanged, fast forward; Move upwards; Increase volume; Swipe down to decrease volume; Short press to play/pause.

BT Music mode: Move to the left and move to the previous track; Swipe to the right for the next song; Move upwards; Increase volume; Swipe down to decrease volume; Short press to play/pause.

#### 4 SRC Button

Short press to cycle through switching in sequence FM/AM, USB Music, Bluetooth music.

FM / AM mode: Long press to perform a global radio search, and the radio stations found will be updated to the radio station list.

USB Music: Long press to switch USB Music mode.

### Notes On Playing Storage Media Mode For USB Music

- Connect USB Storage device, the system will automatically load audio from the storage device.
- This system supports USB format FAT , FAT32 , and the supported song formats are MP3, AAC, WAV, APE, and FLAC.
- If the USB device media is not in use, DO NOT leave the device connected. This may result in connection deterioration.
- Do not remove USB device whilst media is playing. Failure to follow these instructions could result in corrupted data.
- Keep the USB port dry and free from debris. The port will become unusable if it is blocked.
- Due to differences in the compression ratio and bitrate of the multimedia formats downloaded from the Internet and other factors, the actual situation of the decoding result shall prevail.

## USB Storage Device

### Inserting a USB Storage Device

Insert the USB device into the interface to connect.

### Removing the USB Storage Device

Check and confirm that there is no data being accessed, then pull out the USB storage device.

**Note: If any data loss or breach occurs whilst the USB storage device is inserted or being used, it will generally be unrecoverable. MG Motor accepts no responsibility for any data loss or breach.**

**Note: Some USB storage devices may be unidentifiable.**

**Note: Using a USB hub or extension cable may result in the USB device not being recognised.**

## Bluetooth Pairing and Connection

The steps of Bluetooth pairing and connection are as follows:

- 1 Enable Bluetooth function on your phone and search for the entertainment host for pairing.
- 2 The car will receive a Bluetooth pairing request, and the instrument pack will display a Bluetooth pairing


request. Short press the Function Adjustment Button to agree to pairing, long press the Function Adjustment Button to refuse pairing.

- 3 After successful pairing, the instrument panel will prompt "Connection successful". If pairing fails, please try repeating the above steps.

When the vehicle restarts, the car will automatically connect to the previously connected Bluetooth device.

### Intelligent Display Interface\*

#### Steering Wheel Entertainment Control Buttons



- 1 Speech Recognition Function Button
- 2 Infotainment/Instrument Display Button
- 3 BT Phone Button
- 4 Function Adjustment Button

Consider displaying this in form of bullet points: -Move up to increase the volume-Move down to decrease the volume-Move to the left to change to the previous track- Move to the right for the next track-Short press to mute or unmute .

- 5 Right custom button  
This function button can be customised in the vehicle settings on the entertainment screen.
- 6 Left custom button  
This function button can be customized in the vehicle settings on the entertainment screen.

## Basic Operations


### Control Panel



- 1 HOME Button  
Short press to return to the main interface; long press to restart the system.
- 2 Volume Down Button
- 3 Volume Up Button

## Main System Interface

Swipe left and right to display all system function icons, such as Music, Bluetooth phone, A/C, etc.




- 1 Status Bar  
Display Bluetooth, time, external temperature, weather etc.
- 2 Sound source information  
Display music/radio status information, including song name, play/pause, and other information.
- 3 Homepage Card  
Including Music, Mobile Internet, etc.  
Click to enter the relevant function interface.
- 4 Menu Bar  
Display function icons: HOME, Navigation\*, Bluetooth Music, AC, Phone, My Car. Long press on the menu bar icons (except for the HOME icon) can be edited on the menu bar.

**Note:** *The images in this chapter are for reference only. According to different vehicle configurations, software versions, and market regions, the content displayed on the interface may vary. Please refer to the actual vehicle interface diagram for accuracy.*

## Bluetooth Pairing and Connection

The steps of Bluetooth pairing and connection are as follows:

- 1 Touch [Bluetooth] in the Settings interface to enter the Bluetooth Connection interface, and turn on the Bluetooth switch.
- 2 Open Bluetooth function on your phone and search for this entertainment console to pair.
- 3 Your phone will receive a Bluetooth pairing request, confirm and click 'Pair'.
- 4 After successful pairing, the intelligent display status bar will display . If pairing fails, please try repeating the above steps.



## Vehicle-Mobile Phone Interconnection

**Note:** *Due to the differences of mobile phone models and system versions, some mobile phones may not be able to use the vehicle-mobile phone interconnection function normally.*

### General functions


Long press the floating ball on the interconnection projection screen interface, which can be dragged as needed. Once release, the edge of the hovering ball will be displayed.

When the Vehicle-Mobile Phone Interconnection is interconnected, enter interface again and display the face before exiting the screen.

### CarPlay

Apple CarPlay enables information interaction between the mobile phone and the on-board infotainment system, including map, music, telephone, voice recognition and soon.

### Connection Method


- 1 Confirm that your iPhone has the Carplay function and that it is turned on.
- 2 Connect the mobile phone to the infotainment system mainframe using an approved USB cable.
- 3 In the main interface, touch [Apple CarPlay] area to enter the Apple CarPlay interface.
- 4 After the vehicle and mobile phone are successfully connected, you can operate the iPhone using the infotainment system screen.
- 5 Press the HOME button on the control panel to return to the main system interface. Or click on the icon  on the screen homepage to return to the car homepage.

### Android Auto

Android Auto enables information interaction between the android mobile phone and the on-board infotainment system, including map, music, telephone, voice commands and so on.

**Note:** *When using Android Auto, make sure Bluetooth is on and not connected to the phone.*

### **Connection Method**

- 1 Connect the mobile phone to the infotainment system using an approved USB cable.
- 2 In the main interface, touch the [Android Auto] areato enter the Android Auto interface.
- 3 After the vehicle and mobile phone are successfully connected, you can operate the Android using the infotainment system screen.
- 4 Press the HOME button on the control panel to return to the main system interface. Or click on the icon  on the screen homepage to return to the car homepage.


## ***Intelligent Driver Assistance***

---

<i>Constant Speed Cruise Control*</i>	220	<i>Ultrasonic Sensor Parking Aid*</i>	260
<i>Instructions for Intelligent Driver Assistance</i>	224	<i>Parking Camera*</i>	262
<i>Camera and Radar</i>	226	<i>360 Around View Monitor System*</i>	263
<i>Adaptive Cruise Control (ACC) *</i>	230	<i>Drive Fatigue Monitoring System*</i>	264
<i>Intelligent Cruise Assist (ICA)*</i>	238		
<i>Intelligent Overspeed Warning*</i>	241		
<i>Speed Limit Assistance System*</i>	243		
<i>Lane Departure Assist</i>	247		
<i>Front Collision Assist (FCA)</i>	250		
<i>Blind Zone Safety Assist(BSD, LCA)*</i>	253		
<i>Rear Cross Traffic Alert ( RCTA)*</i>	255		
<i>Door opening warning (DOW ) *</i>	257		
<i>Rear Collision Warning ( RCW ) *</i>	259		

# INTELLIGENT DRIVER ASSISTANCE

## Constant Speed Cruise Control\*



1 Speed Adjustment Knob

2 Pilot Switch

Cruise control enables the driver to maintain a constant road speed without using the accelerator pedal. This is particularly useful for motorway cruising, or for any

journey where a constant speed can be maintained for a lengthy period.

### Cruise Control System Activation

The cruise control system is operated using the cruise switch located on the left side of the steering wheel.

- 1 When the ignition/Start/Stop switch is in the ON/READY/RUNNING position and the speed is greater than 25 mph ( 40 km/h), short press the Pilot switch ( 2 ) to activate the Cruise Control system. The constant speed cruise indicator lamp in the instrument pack will illuminate blue. The target speed of the cruise system will be set at the actual speed the vehicle is traveling when it is activated and the target speed is displayed below constant speed cruise control indicator lamp. After activation, the cruise control system will maintain the target speed without pressing the accelerator pedal.
- 2 If the cruise control system is in the Standby state and the current speed is greater than 25 mph ( 40 km/h ) , the cruise control system can also be activated by pressing the speed adjustment knob ( 1 ). The target speed of the cruise system will be set at the

## INTELLIGENT DRIVER ASSISTANCE

actual speed the vehicle is traveling when it is activated, the target speed is displayed below the constant speed cruise control indicator lamp.

**Note: The adjustment knob can be operated in various ways such as being moved up/down or being pressed. Pressing the adjustment knob when the constant speed cruise control system is activated will update the vehicle speed to the current speed.**

### Target Cruise Speed Adjustment

When the cruise control is active:

The vehicle can still be accelerated by pressing the accelerator pedal (such as overtaking). When the new desired speed is achieved, press the speed adjustment knob ( 1 ) to update the target cruise speed to the current speed.

Push the knob ( 1 ) upwards/downwards and hold to accelerate or decelerate automatically, then release the switch when the desired speed is reached.

In addition, pushing the knob upwards/downwards and releasing immediately can adjust the speed. Each push will increase or decrease the speed appr. 1 mph ( 1 km/h ) .

When the cruise control system is in operation, the vehicle can still be accelerated by pressing the accelerator pedal (such as overtaking). Releasing the accelerator pedal will return the vehicle to the set cruise speed.

### Pause

Cruise control will drop from active to Standby, and the constant cruise control indicator lamp in the instrument panel will illuminate white if:

- Short press Pilot Switch ( 2 ).
- Brake pedal is applied.
- The shift control knob is moved to N position.
- Poor road conditions may lead to the activation of the Stability Control System ( SCS ). For safety reasons, the cruise control system will automatically exit to Standby state.
- Undulating roads or hills may cause the vehicle's speed to drop or rise excessively and the cruise control system will automatically exit to the Standby state.
- The electronic parking brake ( EPB ) is activated.

# INTELLIGENT DRIVER ASSISTANCE

## Resume

When the cruise control remains in Standby after the disengagement, move the speed adjustment knob ( 1 ) upwards once to activate it again. The target cruise speed will return to the target speed before exiting the cruise control system.

## OFF

Long press the Pilot switch ( 2 ) to turn off the cruise control system.

### Note:

- **Do not use the constant speed cruise control system in unsuitable conditions, such as in rainy days, on slippery surfaces, or in traffic conditions that do not allow to maintain a constant speed.**
- **ALWAYS turn off the constant speed cruise control system when it is not in use.**
- **When the vehicle is in 'Sport' mode, it is not recommended to use the constant speed cruise control system.**
- **During the operation of cruise control system, the actual speed may deviate from the target speed**

**to some extent due to control precision or road conditions.**

- **Excessive deviation of the actual vehicle speed from the target speed due to a slope or road surface, etc., or triggering the SCS to operate may cause the constant speed cruise control system to automatically exit to the 'Standby' mode.**
- **Do not press a switch for excessively long periods, or press multiple switches simultaneously, this may cause the constant speed cruise control system to fail. If this situation occurs, when it is safe to do so, please restart the vehicle.**

### Note:

- **Do not use the constant speed cruise control system in unsuitable conditions, such as in rainy days, on slippery surfaces, or in traffic conditions that do not allow to maintain a constant speed.**
- **ALWAYS turn off the constant speed cruise control system when it is not in use.**
- **When the vehicle is in "Sport" mode, it is not recommended to use the constant speed cruise control system.**

## INTELLIGENT DRIVER ASSISTANCE

---

- *During the operation of cruise control system, the actual speed may deviate from the target speed to some extent due to control precision or road conditions.*
- *Excessive deviation of the actual vehicle speed from the target speed due to a slope or road surface, etc., or triggering the SCS to operate may cause the constant speed cruise control system to automatically exit to the "Standby" mode.*
- *Do not press a switch for excessively long periods, or press multiple switches simultaneously, this may cause the constant speed cruise control system to fail. If this situation occurs, when it is safe to do so, please restart the vehicle.*

# INTELLIGENT DRIVER ASSISTANCE

## Instructions for Intelligent Driver Assistance

### Disclaimers for Intelligent Driver Assistance Function

**Before using the Driver Assistance functions, the user should read, accept, understand and pay particular attention to the following:**

- 1 At present, all available Intelligent Driver Assistance functions require the driver to maintain full control during the entire driving process, the vehicle is NOT to be considered as full autonomous driving.
- 2 The user and driver should carefully read, learn, understand and implement the relevant content in the Owner's Handbook of this vehicle, and use these functions (and any related functions) in accordance with the requirements herein (in particular, the functional module instructions and use restrictions for intelligent driver assistance and intelligent cockpit). The user and the driver must always ensure they maintain full control and responsibility, observing all local Road Traffic Safety Laws and Regulations, and

always be in a state of readiness to resume control of the steering wheel and braking of the vehicle. In the event of any personal or property damage caused by the user or the driver (for example, failure to use the vehicle in accordance with the requirements set out in the Owner's Handbook, or failure to retake control of the steering wheel and/or brakes at any time as required by the Road Traffic Safety Law), the user or the driver shall bear all responsibilities and consequences.

- 3 The Intelligent Driver Assistance function can only play an auxiliary role under certain conditions, and CANNOT replace the driver's observation of the road environment. The driver should drive cautiously and MUST NOT rely on the function. The Owner's Handbook has stated clearly in its obligation the various restrictions on the use of auxiliary functions (i.e. the circumstances under which certain functions may not be enabled, become impaired or may stop working).
- 4 The Intelligent Driver Assistance function has requirements for complete and successful operation, these include conditions such as weather, road



## INTELLIGENT DRIVER ASSISTANCE

---

surfaces and driver operations, operation may become impaired, fail or become limited due to several factors, which are not related to the design and application defects of the product. If the user and the driver cannot understand or accept the above disclaimers, do not use the Intelligent Driver Assistance functions. If the functions are enabled, please exit immediately.



***Camera and radar operation may be impaired in certain driving situations, weather and road conditions. In areas where there are complex traffic conditions such as intersections road junctions with congestion, or poor general conditions, the driver MUST take full control of the vehicle.***

The Intelligent Driver Assistance system can detect the road and environmental information ahead of the vehicle using the camera. It can provide warning messages or intervene when certain conditions are met in order to assist the driver in controlling the vehicle in a more safe and reliable manner.

***Note: DO NOT operate any infotainment switches whilst driving. If you wish to make any settings changes, please pull over when it is safe and legal to do so.***

# INTELLIGENT DRIVER ASSISTANCE


## Camera and Radar

### Driver Assistance Camera

The following cameras are installed on the vehicle: 360° surround view cameras, front view camera module, parking camera (subject to the specification of the vehicle purchased).

The camera carries out target identification in the form of vision, and provides identification information for related functions after identifying the target in the surrounding area of the vehicle.

### Camera Installation Position



- 1 360° Surround View Camera
- 2 Front View Camera Module
- 3 Parking Camera

**Note:** The configuration of cameras are subject to the specification of the vehicle purchased.

**Note:** To ensure that the front view camera works properly, always keep it clean and free of ice, snow, water, dust, etc.

**Note:** To ensure the camera works properly, always keep the windshield in front of the camera clean with no objects blocking the view between the camera and the windshield.

**Note:** Please wipe camera lenses with a soft cloth or wash with water (of low pressure) when foreign objects are found on the camera surface. Do not use a high pressure water jet to flush the camera, and do not use abrasive or sharp objects to clean the camera.

## Camera Calibration

The calibration of front view camera requires professional knowledge and tools. If calibration is required, please seek an MG Authorised Repairer. Recalibration of the front view camera module is necessary in the following situations:

- The module has a maladjustment failure, for example the position of the camera has changed;
- Remove/refit the camera or its bracket;
- Remove/refit the windscreen;
- The four-wheel alignment parameters have changed.

**Note:** If the front detection radar is subject to strong vibration or slight impact, the mounting position of the front detection radar needs to be checked and re-calibrated as necessary.

**Note:** Please consult an MG Authorised Repairer for more details about camera calibration.

In the following situations, the detection performance of front view camera will be affected:

- Driving in poor weather conditions where visibility is reduced or impaired due to thick fog, heavy rain, snow, dust etc.
- Affected by ambient light, for example low light levels at night, poor auxiliary lighting, excessive light from the rear lights of the vehicle ahead, light from oncoming vehicles, abrupt changes in brightness with a quick bright/dark change (tunnel entrance/exit), driving on surfaces with strong reflective properties (road surface covered with water or snow), tunnels, inside a building etc.
- The front view camera view is partially or fully blocked by obstacles, e.g. dust, foreign objects, dirt/mud, snow, excessive water (rain), frost or water spray from the road on the windscreen.
- The windscreen viewing area is damaged.

# INTELLIGENT DRIVER ASSISTANCE


- Not calibrated after removing/refitting the front view camera or the windscreen.
- The front view camera is not secured in place.

## Driver Assistance Radar

Depending upon specification, the vehicle may feature ultrasonic radars.

These are only used to provide identification information for related functions after identifying the target in the surrounding area of the vehicle.

## Radar Installation Position



I Ultrasonic Radar

## INTELLIGENT DRIVER ASSISTANCE

**Note:** *The configuration of the radars is subject to the vehicle purchased.*

**Note:** *To ensure that the radars work correctly, always keep them clean and free of ice, snow, water, dust, etc.*

**Note:** *Please wipe with soft cloth or wash with water (of low pressure) when foreign objects are found on the radar surface. Do not use a high pressure water jet to flush the radar, and do not use abrasive or sharp objects to clean the radar.*

**In the following situations, the detection performance of the radars will be affected:**

- The radar or bumper is covered by foreign objects such as ice, snow, mud, stickers, tape or trims, etc.
- Unauthorised paint and spray processes are used for the bumper.
- The radar or bumper is damaged or their installation positions changed.
- The radar is affected by electromagnetic interference from other equipment.
- Small and enclosed environments such as small garages etc.
- The vehicle is towing a trailer.

- The radar may not work correctly due to limited detection performance in an open field (such as an open parking lot) or on an open road.

**Note:** *Any snow on the radar should be removed with a brush, while any ice is preferably removed with a deicing spray.*

### Adaptive Cruise Control (ACC) \*



*The adaptive cruise control system is designed as a comfort system. It provides assistance to the driver, but DOES NOT replace any of the driver's responsibilities. When using the adaptive cruise control system, it is important that the driver maintains concentration at ALL times and is prepared to take action. Otherwise, accidents or personal injuries may occur.*

Depending on whether there is vehicle ahead, the adaptive cruise control system can also conduct automatic switching between constant speed cruise and car-following cruise. With the adaptive cruise control system, the vehicle is allowed to conduct constant speed cruise within a certain speed range, or conduct car-following cruise by setting the distance between the vehicle and vehicles ahead. If a vehicle is detected in your driving path, the ACC system may apply moderate brakes or acceleration to maintain the selected following distance.

*Note: The adaptive cruise control system is designed for highways and roads in good condition. It is recommended that it is NOT used on urban roads and mountain roads.*

### Adaptive Cruise Activation



*After following the vehicle ahead to a stop, the driver must ensure that there are no obstacles or other traffic participants, such as pedestrians directly in front of the vehicle before starting off to follow the vehicle ahead again.*



*Whilst using the car following cruise function, it is strongly recommended that the driver does not touch the accelerator pedal. Any activation of the accelerator will not allow the adaptive cruise control system to automatically apply the brakes. The vehicle is only controlled by the driver's manipulation of the accelerator pedal.*

## INTELLIGENT DRIVER ASSISTANCE




**DO NOT** exit the vehicle when the adaptive cruise control system is keeping the car stationary. Before exiting the car, the shift control knob should be in the P position and the ignition/Start/Stop switch should be OFF.



If the adaptive cruise control system is keeping the car stationary, the driver still needs to pay full attention and be ready to apply the brakes manually. Note that if the system is disabled, turned off or cancelled, the vehicle will no longer stay still, it may move forward or slip backward.



When driving on a bend, the adaptive cruise control may actively reduce the vehicle speed to maintain vehicle stability and safety.



- 1 Adjustment Knob
- 2 Pilot Switch

The adaptive cruise control system can be set using a combination of switches in the entertainment display and the left side of steering wheel.

- 1 If the switch in the entertainment display is in the "OFF" state, the adaptive cruise control system is in the "OFF" state.
- 2 Move the switch in the entertainment display to the "ON" state, and short press the Pilot switch (2) . The indicator light for the adaptive cruise control system in

## INTELLIGENT DRIVER ASSISTANCE

the instrument pack will illuminate blue, the adaptive cruise control system will be activated. The speed must be above 3 mph (5km/h) for the first activation. The target speed is the actual speed when activated, if your vehicle speed is less than 20 mph (30km/h), the target speed of the system will be set to 20 mph (30km/h). If the speed of the vehicle ahead is greater than the target cruise speed of your vehicle, your vehicle will maintain the target speed and conduct constant speed cruise; if the speed of the vehicle ahead is lower than the target cruise speed of your vehicle, it will enter the car-following cruise, a tail schematic of the vehicle ahead is displayed in instrument pack. In the car-following cruise, you can follow the vehicle ahead to a stop. If the stop time is below a certain time, your vehicle may automatically start off to follow the vehicle ahead, if this is not the case, then the driver will need to re-activate the adaptive cruise control system according to the instrument prompt.

**Note: Manual deactivation of the Electronic Stability Control (ESC) will inhibit the operation of the adaptive cruise control system.**

### Adaptive Cruise Target Following Distance Adjustment

When the adaptive cruise control system is activated, move the adjustment knob to the right (to increase the following distance) or left (to decrease the following distance). There are 3 distance settings, there will be displayed on the instrument pack.

Select an appropriate following distance according to the difference in relative speed with the vehicle ahead, the higher the relative speed, the longer the following distance that should be selected. Always consider the traffic and weather conditions, the optional following distance range may not be suitable for all drivers and driving conditions.

### Adaptive Cruise Control Target Speed Adjustment

When the adaptive cruise control system is active:

- Use the accelerator pedal to reach the desired speed, press the adjustment knob (1), then release the adjustment knob and accelerator pedal. The vehicle will cruise at the desired speed.



## INTELLIGENT DRIVER ASSISTANCE

- Move the adjustment knob upward or hold, the target speed will increase until the desired set speed appears on the instrument pack, then release the knob. When it is confirmed that there is no vehicle ahead or the vehicle ahead is beyond the pre-selected following distance, the vehicle speed can be increased to the set speed.
- Move the adjustment knob downward or hold, the target speed will decrease until the desired set speed appears in the instrument pack, then release the knob, and the speed will decrease to the set speed.

**Note:** *If the vehicle ahead continually makes hard acceleration or deceleration manoeuvres the adaptive cruise control may not be able to accurately maintain the required distance between vehicles. It is important that the driver always concentrates and pays attention to the current vehicle position and situation in case they need to make a braking or avoidance manoeuvre.*

### Adaptive Cruise Control Pause

When the adaptive cruise control system is activated, short press the Pilot switch to cancel the function, the system will exit to the Standby state.

### Automatic Deactivation of Adaptive Cruise Control

In the following situations, the adaptive cruise control system may be automatically suspended transferring full control of the vehicle to the driver:

- Operating the switch to turn off the ACC;
- Pressing the brake pedal whilst the vehicle is in motion;
- Moving the shift control knob to either R or N position;
- The driver unfastens his/her seat belt;
- Pressing and holding the accelerator pedal beyond a preset time period;
- Opening any door, bonnet or tailgate;
- Pulling the EPB switch up to apply the parking brake;
- Following the vehicle ahead to a stop and the stop time exceeds a certain period of time.
- The camera or radar view is blocked, the surrounding environment triggers the preset safe exit mechanism of the sensors, or the system fails.

# INTELLIGENT DRIVER ASSISTANCE

---

**Note:** *If following the vehicle ahead to a stop with the adaptive cruise control system enabled, if any of the following conditions occur whilst the vehicle is in a stopped state, the EPB will automatically be applied:*

- *The driver unfastens the seat belt;*
- *The driver door is opened;*
- *The stationary time exceeds the preset time period.*

## **Adaptive Cruise Override**

If the driver has cause to use the accelerator pedal when the adaptive cruise control system is activated, the vehicle will remain in Cruise mode while the vehicle speed increases. When the accelerator pedal is released, the adaptive cruise control system will resume to operate at previously set cruise speed.

## **Adaptive Cruise Resume**

If the adaptive cruise control system has reverted to, or been switched to, the Standby mode it can be reactivated by moving the adjustment knob upwards. The target cruise speed will automatically be set to the target speed before exiting the adaptive cruise control system.

## **Clearing Target Speed Memory**

Switching the adaptive cruise control off in the entertainment display will turn off the adaptive cruise control system, synchronously clearing the system's set speed in the memory. Switching the ignition off will also clear the set speed stored.

## **Adaptive Cruise Control System**

### **Impairment and Ineffectiveness:**

- Your vehicle encounters a vehicle or object which is stationary or traversing the lanes;
- Approaching the vehicle ahead too fast, and the system cannot apply sufficient braking force;
- The vehicle ahead is an oncoming vehicle, or it is making an emergency braking manoeuvre;
- The vehicle ahead is reversing;
- A vehicle suddenly cuts into the lane in front;
- Your vehicle encounters a vehicle driving at a low speed;
- Your vehicle encounters a vehicle with loaded items protruding from the body profile of the vehicle;
- Encounters a vehicle with a higher chassis (e.g., a truck);

# INTELLIGENT DRIVER ASSISTANCE



- Your vehicle encounters pedestrians, non-motor vehicles or animals;
- The vehicle is driving on an uneven road or a complex traffic road section;
- The vehicle makes a sharp turn;
- Entering, leaving or driving in a tunnel;
- Driving in the shadow of mottled trees;
- Excessive weight being carried in the boot space or cargo area causing the front of the car to point upwards.

## Special Driving Environments

The adaptive cruise control system has its limitations. Listed below are some conditions that may be beyond the safe operating limits. The driver should maintain control of the vehicle and must remain alert at all times. They must pay special attention to the traffic conditions and surroundings, select the appropriate speed and be ready to take any required actions.


- I When turning at the intersection or driving into or out of the curve following the vehicle ahead, the adaptive cruise control system may be unable to detect the vehicle ahead on the same lane, or may respond to the vehicles in another lane.

**Note: DO NOT use the adaptive cruise control system on entrance/exit ramps or sharp curves.**




## INTELLIGENT DRIVER ASSISTANCE

- 2 If the vehicle ahead changes the lane, but does not drive into the new lane completely, the adaptive cruise control system may be unable to detect the vehicle. If the vehicle ahead changes lanes but does not exit the lane completely, the adaptive cruise control system may determine that the vehicle ahead has already left and accelerates.




- 3 When driving on uneven roads that may include steep climbs or dips please DO NOT use the adaptive cruise control system..



- 4 When driving behind a vehicle that is only partially overlapping your vehicle, (A) in the graphic, the adaptive cruise control system may be unable to detect anything.

## INTELLIGENT DRIVER ASSISTANCE




**Note:** Please **DO NOT** use the adaptive cruise control system in the following situations:

- **Driving in bad weather conditions;**
- **When the ambient light is insufficient, the light is too bright, or the forward lighting of the vehicle is poor;**
- **Driving on rough or poor road surfaces;**
- **Driving through roadworks or construction sites;**
- **Driving on low friction roads (the rapid change of the tyre traction may result in the excessive wheel slip).**

## INTELLIGENT DRIVER ASSISTANCE

### Intelligent Cruise Assist (ICA)\*

*Intelligent cruise assist is an auxiliary function that provides driver assistance. It provides assistance to the driver, it DOES NOT replace any of the drivers responsibilities. Due to the limitations of system detection and control when using the intelligent cruise assist, the driver must always hold the steering wheel, pay attention to the surrounding environment of the vehicle and correct or take over the steering wheel control when necessary, otherwise accidents or personal injuries may be caused.*



- Adjustment Knob (1) ;
- Pilot Switch (2) ;

The system switch is located in the entertainment display, and the system can be turned on/off in the appropriate Driver Assistance interface.

When the following conditions are met:

- The traffic jam assist system switch on the entertainment display is on;
- The system detects the lane lines on both sides of the vehicle;
- The vehicle is in Drive gear.

Short press the Pilot switch to activate the traffic jam assist system. The traffic jam assist system works on the same basis of the adaptive cruise control system. If the lane lines ahead on both sides are clear, the system will assist the vehicle in driving within the lane; if there is a vehicle ahead and the lane lines are not clear when driving at a low speed, the system can assist the vehicle in following the track of the vehicle ahead.

**Note:** With the ACC system activated, the traffic jam assist system can be activated without pressing the MG Pilot switch when the above conditions are met.

## INTELLIGENT DRIVER ASSISTANCE

When the system detects that the driver has not controlled the steering wheel in a certain period of time, it will give warnings to prompt the driver.

**Note: Drivers should adjust their vehicle speed and distance from the vehicle ahead based on road visibility, weather and road traffic conditions. The intelligent cruise assist system will not respond to pedestrians, animals, stationary vehicles, vehicles crossing the lane, or oncoming vehicles on the same lane. If the intelligent cruise assist system cannot fully reduce the speed, braking should be carried out by pressing the brake pedal. In congested conditions, if other vehicles enter this lane due to congestion, the braking may not be timely due to the vehicles not entering the system detection range. Therefore, the driver should take the initiative to brake.**

**The traffic jam assist system will be impaired or ineffective in the following conditions:**

- The driver turns on the turn signal lamps;
- The driver turns on the hazard warning lamp;
- The driver applies the accelerator rapidly, carries out an emergency manoeuvre or makes a hard brake pedal application;

- The system detects that the driver has not moved the steering wheel for a preset time period;
- During system intervention, the steering wheel is being manipulated by the driver;
- The lane line is too thin, damaged or fuzzy;
- The vehicle is being driven on a bend with a small curvature radius, the road is too narrow or too wide;
- The vehicle has just entered a road section with lanelines or is being driven on a road section without lanelines;
- The vehicle is in R gear;
- The vehicle changes lanes or sways laterally too fast;
- The turning radius of the car using the traffic jam assist system to track in front is too small;
- The anti-lock brake system (ABS) and the dynamic stability control system (SCS) are activated;
- Faults exist in the anti-lock brake system (ABS) , dynamic stability control system (SCS) , electric power steering system (EPS) , etc.

It is recommended to turn off the traffic jam assist system in the following situations:

- Driving in a sports style or manner;

## INTELLIGENT DRIVER ASSISTANCE

---

- Driving in bad weather conditions;
- Driving on rough or poor road surfaces;
- Driving through roadworks or construction sites;
- Driving on steep, winding or slippery roads (such as snow covered and icy roads, wet roads and roads covered with water);
- Driving on grass tracks or unpaved roads.

### IMPORTANT

- In cases where the number of lanes increase or lanes merge the driver **MUST** take full control of the vehicle.
- In areas where there are complex traffic conditions such as intersections or road junctions with congestion, the driver **MUST** take full control.
- The driver **MUST** be aware of the surroundings and be able to assume full control of the vehicle when using the traffic jam assist system to track the car in front should the need arise.




## Intelligent Overspeed Warning\*



*The intelligent speed assist system is an auxiliary function. It may display an incorrect speed limit value or no speed limit value in the instrument pack due to various factors. As a result, the vehicle speed is not restricted within the correct range. The driver still needs to observe the speed limit of the road traffic and speeding is strictly prohibited.*



*The front view camera cannot recognise speed limit signs painted on the road surface. The driver **MUST** observe these speed limits and adjust the speed accordingly.*

The setting interface for the intelligent overspeed warning is in the entertainment display. The driver can operate the intelligent overspeed warning system using the soft switch in this display. The vehicle detects the speed limit sign (such as ) at the roadside with the front view camera. When the vehicle speed exceeds the speed limit indicated by the

speed limit sign speed indicator, the indicator flashes to remind the driver to control the vehicle speed.

The speed limit sign speed indicator illuminates when the intelligent overspeed warning is active. When the vehicle passes the first speed limit sign identified, the speed sign speed indicator displays the real-time speed limit value. If a speed limit sign with the same limit value is detected, the limit value displayed in their speed sign speed indicator remains.

**Note:** *If the vehicle changes lane, makes a turn, turns around in the intersection, or identifies the speed limit cancellation, the original speed limit value on the instrument pack may be reset and displayed as “-” till a new speed limit sign is detected. If the conditions are not met, the original speed limit value will maintain and not be reset. The driver **MUST** observe the speed limits and adjust their speed accordingly.*

### The intelligent overspeed warning system function may be impaired if:

- 1 The detection performance of front view camera is affected;
- 2 The vehicle is driven at a high speed;

## INTELLIGENT DRIVER ASSISTANCE

- 3 The speed limit signs are obscured by trees at the roadside, ice/frost, snows, dust, etc; or the speed limit signs are placed improperly or damaged;
- 4 When there are several speed limit signs set up over the road or at the roadside, the overspeed warning will be carried out according to the maximum speed limit value.

### IMPORTANT

- The camera may not correctly recognise speed limit signs during poor lighting conditions, bad weather, non-standardized or sheltered speed limit signs or the camera's own restrictions which include the recognition of similar signs (e.g., recognise a weight limit sign as a speed limit sign or recognise a minimum speed sign as the maximum speed sign).
- The camera cannot identify the text provided below the speed limit sign, such as Auxiliary Lane, 100 m Ahead, School Section, 7:00-10:00, etc. The camera will identify the speed limit sign with text as a normal speed limit sign.
- Some drastic and rapid steering operations of the driver may be judged as changing lane or turning around in the intersection by the system, resulting in the identified speed limit signs being cleared.
- In cases where a speed limit sign contains multiple speed limits. The camera may not identify all the speed limits.

## Speed Limit Assistance System\*

### Speed Limit Assistance System



*The speed limit assistance system is only an auxiliary function. In cases where the speed limit sign is not standardized or the front view camera is blocked, the wrong speed limit value or no speed limit value may be displayed on the instrument pack, and the vehicle is not restricted in the correct speed range, so the driver still needs to be responsible for real-time evaluation of the speed limit on the road.*



*The front view camera cannot recognise speed limit signs painted on the road surface. The driver MUST observe these speed limits and adjust their speed accordingly.*

The setting interface of the speed limit assistance system is located in the entertainment display. Enter the Vehicle Settings - Speed Limit Assistance System interface to select from the following modes: Smart, Manual and Off.

- 1 Smart: i.e. smart speed limit. The vehicle detects the speed limit sign (such as  $\text{⑩}$ ) at the roadside with the front view camera, and intervenes using the speed control to keep the vehicle speed in the permitted maximum speed limit;
- 2 Manual : i.e. manual speed limit. The driver sets the maximum speed with the button on the left side of the steering wheel and uses the speed control system to keep the speed in the permitted maximum speed limit. Refer to “Speed Settings of Manual Speed Limit” for the description;
- 3 Off: Turn off the speed limit assistance system.

**Note:** *If the mode selection cannot be performed, please confirm that the cruise function in the entertainment display is OFF and try again.*

### Speed Settings of Manual Speed Limit

After the manual speed limit function is enabled, the speed limit can be set by using the button on the left side of the steering wheel, as follows:

## INTELLIGENT DRIVER ASSISTANCE



- 1 The manual speed limit function will enter the standby state once enabled, the indicator lamp of the speed limit assistance system in the instrument pack will illuminate white. Press the Pilot switch ( 2 ) to activate the manual speed limit function, the indicator lamp of the speed limit assistance system will illuminate white blue. After the first press of the Pilot switch, if the actual speed is below 20 mph( 30 km/h), the target speed limit value displayed on the speed limit assistance system indicator is 20 mph( 30 km/h); if the actual speed is above 20 mph( 30 km/h), the current speed is rounded up to the nearest multiple of 5 as the target speed limit value. Move the speed adjustment knob ( 1 ) upward/downward to change the target speed limit value of the manual speed limit. The target speed limit value will be increased/decreased by 5 mph( 5 km/h) every time the adjustment control is moved upwards/downwards. The speed limit value will change continuously by 5 mph( 5 km/h) when the adjustment control is moved upwards/downwards and held.

- 2 With the manual speed limit activated, the system will limit the vehicle speed within the target limit speed; if the vehicle speed is greater than the driver inputted target speed, the system will gradually slow the vehicle to below the inputted target limit value.
- 3 After the manual speed limit is activated, the driver can briefly press the Pilot switch ( 2 in the figure below) to reinstate the system to the Standby state. Press the Pilot switch ( 2 in the figure below) again to restore the manual speed limit function.
- 4 Fully apply the accelerator pedal to temporarily exceed the speed limit value when the manual speed limit is active. At this time, the indicator lamp of the speed limit assistance system in the instrument pack will illuminate in blue and will flash.

1 Adjustment Knob

2 Pilot Switch



The state indicator for the speed limit assistance system will illuminate in blue when the smart speed limit is enabled. When the vehicle passes the first

speed limit sign identified, the speed sign speed indicator displays the real-time speed limit value. If a speed limit sign with the same limit value is detected, the limit value displayed in the speed sign speed indicator remains.

**Note: If the vehicle changes lane, makes a turn, turns around in the intersection or identifies the speed limit cancellation, the original speed limit value on the instrument pack may be reset and displayed as ‘-’ till a new speed limit sign is detected. If the conditions are not met, the original speed limit value will remain and not be reset. The driver MUST observe the speed limits and adjust their speed accordingly.**

The driver can temporarily exit the speed limit assistance system by the following operations:

- 1 Fully apply the accelerator pedal to temporarily exceed the speed limit value. At this time, the indicator lamp of speed limit assistance system in the instrument pack will illuminate in blue and flash;
- 2 Briefly pressing the Pilot switch ( 2 in the figure above) can temporarily exit the speed limit assistance system functions. In this case, the indicator lamp of the speed limit assistance system in the instrument pack changes into white (into dark colour in daylight

mode); press the Pilot switch again to resume the speed limit assistance system functions.

## The smart speed limit may be impaired if:

- 1 The detection performance of the front view camera is affected;
- 2 The vehicle is driven at a high speed;
- 3 The speed limit signs are obscured by trees at the roadside, ice/frost, snows, dust, etc; or the speed limit signs are placed improperly or damaged;
- 4 There are multiple speed limit signs set up over the road or at the roadside; Currently, the front view camera can only identify the speed limit signs for the lane the vehicle is being driven in;
- 5 The speed limit signs set up at the forks in the road, the curves and the on-ramp/off-ramp;
- 6 Lane change, etc.

### IMPORTANT

- The camera may not correctly recognise speed limit signs during poor lighting conditions, bad weather, non-standardized or sheltered speed limit signs or the camera's own restrictions which include the recognition of similar signs (e.g., recognise a weight limit sign as a speed limit sign, or recognise a minimum speed sign as the maximum speed sign).
- The camera cannot identify the text provided below the speed limit sign, such as Auxiliary Lane, 100 m Ahead, School Section, 7:00-10:00 , etc. The camera will identify the speed limit sign with text as a normal speed limit sign.
- Some drastic and rapid steering operations of the driver may be judged as changing lane or turning around in the intersection by the system, resulting in the identified speed limit signs being cleared.
- In cases where a speed limit sign contains multiple speed limits. The camera may not identify all the speed limits.

## Lane Departure Assist



*The lane departure assist system is an auxiliary system, which can provide assistance to the driver. It does NOT remove the responsibility of safe driving from the driver. When choosing to use the lane keeping assist system, the driver MUST always pay attention to the surroundings, hold the steering wheel and be prepared to make manoeuvres at any time. Failure to maintain overall control of the vehicle may result in an accident or personal injury.*



*The lane departure assist system does not always recognise the lane lines or kerbs. Sometimes poor road surfaces, certain road structures or objects may be mistaken for lane lines or kerbs. When such situations occur, the lane departure assist system must be turned off immediately.*

The lane departure assist system switch is located on the entertainment display. The system can be turned on/off in

the appropriate Intelligent Driver Assistance interface, and the mode can be selected.

### Alert

The system detects the lane lines ahead when the following detection conditions are met:

- The function is in "ON" state;
- The vehicle speed is above 37 mph (60 km/h) ;
- The lane lines are clear, and the system detects at least one lane line;

When the wheel is about to cross the lane line or has already crossed the lane line, the system will give warnings to remind the driver to take action and correct the direction in time to keep the vehicle running within the lane lines. The function will exit when the speed is less than 33 mph (55 km/h) .

### Assist

The system uses the front view camera to detect the lane lines ahead of the vehicle. The system will be activated when the following detection conditions are met:

- The function is switched ON.

# INTELLIGENT DRIVER ASSISTANCE

- Vehicle speed is above 37 mph (60 km/h) .
- Lane line markings are clear and the system recognises at least one lane line.

When a wheel is about to cross the lane line, or has already crossed the line, the system will provide assistance to the driver by keeping the vehicle in between the lane lines by applying corrective steering intervention and simultaneously displaying a prompt. The function will automatically exit when the vehicle speed drops below 33 mph (55 km/h) .

## Emergency Lane Keeping (ELK)

The system uses the front view camera to detect lane lines, kerb and adjacent lanes of oncoming traffic ahead. The system will be activated when the following detection conditions are met:

- The function is switched ON.
- Vehicle speed is above 37 mph (60 km/h) .
- Lane line markings are clear and the system recognises at least one lane line.

When a wheel is about to cross the lane line or kerb, or the vehicle is approaching oncoming traffic in the adjacent lane and there is the possibility of a collision, the system will

provide assistance to the driver by keeping the vehicle in between the lane lines or kerbs, or applying a sharp steering intervention and simultaneously displaying a prompt. The function will automatically exit when the vehicle speed drops below 33 mph (55 km/h) .

In cases of several interventions within a certain period of time and in the absence of detecting any steering input by the driver during the interventions, the system will provide warnings.

### IMPORTANT

- In cases where the number of lanes increase or lanes merge, the driver **MUST** take full control of the vehicle.
- In areas where there are complex traffic conditions such as intersections or road junctions with congestion, the driver **MUST** take full control of the vehicle.



## INTELLIGENT DRIVER ASSISTANCE

### **The lane departure assist system will be impaired or ineffective in the following conditions:**

- The driver indicates in the direction of the lane line about to be crossed.
- The hazard lamps are activated.
- The driver applies the accelerator rapidly, carries out an emergency manoeuvre or makes a hard brake pedal application.
- The system detects that the driver has not moved the steering wheel for a preset time period (in the mode of assist or emergency lane keeping).
- During system intervention the steering wheel is operated (in the mode of assist or emergency lane keeping).
- The lane line is too thin, damaged or unclear.
- Irregular or damaged kerbs.
- The vehicle is driven on the bend with a small curvature radius, the road is too narrow or too wide.
- The vehicle has just entered a road section with lane lines or is driven on a road section without lane lines.
- The vehicle changes lanes or sways laterally too fast.

- The vehicle is not in D.
- The vehicle speed is below 33 mph (55 km/h) , or too high.
- The anti-lock brake system (ABS) and the dynamic stability control system (SCS) are activated.
- Faults exist in the anti-lock brake system (ABS), dynamic stability control system (SCS), electric power steering system (EPS), etc.

It is recommended to turn off the lane assist system in the following situations:

- Driving in a sports style or manner.
- Driving in bad weather conditions.
- Driving on a poor road surface.
- Driving through roadworks or construction sites.

# INTELLIGENT DRIVER ASSISTANCE

## Front Collision Assist (FCA)



*The driver remains responsible for the safety of the entire driving process, even if the vehicle is equipped with a forward collision system. The driver **MUST** pay full attention and drive carefully. As with all the driver assist systems, the forward collision system cannot prevent accidents or avoid collisions in all situations. The driver **MUST** always remain in control to avoid accidents or emergency situations.*



*Emergency braking whilst under the control of forward collision system may cause injuries to the passengers. Therefore, drive carefully and all passengers **MUST** wear seat belts at all times.*



*Ensure that the forward collision system or ignition/vehicle power system is switched off when being towed. If the forward collision system is enabled when the vehicle is being towed, adverse effects may affect the safety of your vehicle, the towing vehicle and the people around.*



*To avoid the occurrence of accidents, never specially test the functions of forward collision system.*

The front collision assist switch is located on the infotainment display. Enter the corresponding interface for driving assistance to turn the system ON/OFF, and make mode selection.

### Alarm

When the system detects that there is a risk of collision between the vehicle and the vehicle in front in the same lane, warnings will be provided to prompt the driver to slow down in time and maintain a relatively safe distance from the vehicle ahead.

## Auto Emergency Braking

When the system detects that there is a risk of collision between the vehicle and the vehicle directly in front, the brake system will automatically intervene to decelerate the vehicle, so as to avoid collision accidents or mitigate damage from collision accidents. If the vehicle has braked and stopped under the system control, it will remain stationary for a short time. Full control of the vehicle will then be returned to the driver.

## The system will only slow the vehicle down automatically if the following conditions are met:

- The dynamic stability control system (SCS) and traction control system (TCS) are fault-free and ON.
- The vehicle is in D or N.
- The airbags have not deployed.

**Note:** *In some cases, the driver may not have anticipated any braking intervention and does not want to apply the brakes whilst the front collision assist is braking heavily, the driver can temporarily cancel this operation by heavily pressing the accelerator pedal after ensuring that it is safe to do so.*

## The front collision assist system operation may be impaired if:

- The vehicle ahead approaches head-on, crosses the intersection or jumps the queue rapidly in a short distance;
- The vehicle ahead does not follow the rules of driving and parking (such as drives on the lane lines);
- The vehicle ahead is not in the same lane as your vehicle or the vehicle ahead is partially obscured;
- The vehicle ahead is an abnormal vehicle (modified or abnormal shape);
- The vehicle ahead is a vehicle with a higher chassis;
- The vehicle ahead is a large vehicle at close range (such as a tractor, trailer, towing vehicle etc.);
- The vehicle ahead is an unusual transportation (such as a horse, cart, carriages etc.);
- The system detects the side of a vehicle;
- The contour of the vehicle ahead is unclear (such as water being sprayed by the wheels of the front and surrounding vehicles);
- The vehicle ahead does not have or has obscured tail lamps when driving at night or in a tunnel;

## INTELLIGENT DRIVER ASSISTANCE

---

- The tail lamps of the vehicle ahead are all LED strip lights or other homemade coloured lamps;
- The street lights are inconsistent or flickering when driving at night;
- The pedestrian is not directly in front of the vehicle or the pedestrian is not fully visible;
- The pedestrian is not standing upright or it is a child under a certain height;
- There is a group of pedestrians in front of the vehicle that is over-shadowed or in the dark;
- There are animals in front of the vehicle;
- Objects such as special-shaped ground obstacles (e.g. roadblocks, isolation piles, isolation strips, large stones, other scattered objects etc.) are detected in front of the vehicle;
- Objects such as signs, guardrails, bridges, buildings or other are detected in front of the vehicle;
- The vehicle is being driven on a hillside road, upper and lower bridge section or tight bends;
- The vehicle is in R;
- The vehicle is in a state of braking or rapid acceleration.


# INTELLIGENT DRIVER ASSISTANCE

## Blind Zone Safety Assit(BSD, LCA)\*

### System Overview


Blind Zone Safety Assit consists of two active safety assist functions: Blind Spot Detection (BSD) and Lane Change Assist (LCA) , these are designed to alert the driver to vehicles that may be hidden or obscured from their sight when carrying out a maneuver such as lane changing.

Blind Spot Detection (BSD) detects any vehicles in the vehicle's blind spot (1 as shown), Lane Change Assist (LCA) detects any rapidly approaching vehicles on the adjacent left or right lane (2 as shown).



## INTELLIGENT DRIVER ASSISTANCE

### Alarm Mode





**Note:** *The warning lamps will not illuminate whilst you are overtaking another vehicle and your speed is greater than that of the vehicle you are passing, even though it is in the blind zone.*

When the system detects that there is a vehicle in the blind zone of the exterior rearview mirror or a vehicle approaching behind in the adjacent lane while driving (the vehicle speed is above 10 mph (15 km/h) , the warning lamp on the corresponding side will illuminate. If the corresponding indicator is selected at this time, the warning lamp will flash to remind the driver that it is dangerous to continue changing lanes.


## Rear Cross Traffic Alert ( RCTA)\*

### System Overview

When reversing, the Rear Cross Traffic Alert (RCTA ) monitors any approaching vehicles from the left/right rear by using sensors and issues an alarm when the vehicle is at risk.



## Alarm Mode



If there is a risk while reversing, the warning lamp on the corresponding side will illuminate and a warning triangle is displayed in the infotainment display.




### Door opening warning (DOW ) \*


#### Function Description

The door opening warning can be turned on or off on the rear driving assistance system setting interface on the entertainment display screen.

When the vehicle is stationary, the Door Opening Warning (DOW) function monitors targets such as vehicles, cyclists or pedestrians approaching the vehicle from behind through sensors on the side and rear. When there is a risk of opening the door, it will sound an alarm to avoid the risk of collision between the door and the target.



## Alarm Mode




When there is a risk of collision, the corresponding warning light on the side will light up. If the car door continues to be opened at this time, the warning light will flash and be accompanied by an alarm sound.

### Rear Collision Warning ( RCW ) \*

#### System Overview

The rear collision warning can be turned on or off on the entertainment display screens rear driving assistance system settings interface.

During the driving process, when other vehicles or targets in this lane approach the vehicle and there is a risk of collision, the rear collision warning function (RCW) will sound an alarm to remind the driver that there is a dangerous target approaching and at the same time, it can remind the vehicle behind to drive safely.



#### Alarm Mode

When there is a risk of collision, the hazard warning lights of this vehicle flash to alert the vehicles behind.

## Ultrasonic Sensor Parking Aid\*



*The purpose of the parking assist system is only to assist the driver during parking! The ultrasonic sensors may not be able to detect certain types of obstruction, e.g. narrow posts, small objects close to the ground, objects above the tailgate and some objects with nonreflective surfaces.*



*Keep the ultrasonic sensors free of dirt, ice and snow. If deposits build up on the surface of an ultrasonic sensor, its performance may be impaired. When washing the car, avoid aiming high pressure water jets directly at the ultrasonic sensors from close range.*

## Rear Parking Aid

The ultrasonic sensors on the rear bumper monitor the area behind the vehicle to search for obstacles. If an obstacle is detected, the system will calculate its distance from the rear of the vehicle and communicates the message to the driver by sounding warning chimes.

*Note: The PDC system and rearward driver assistance system are unavailable when tow mode is enabled.*

## Parking Aid Operation

### Rear Parking Aid


The rear parking aid is enabled automatically when the R gear is selected; and when it is moved out of the R gear, the system will be immediately shut off. A short beep is given by the parking aid after selecting R gear to indicate that the system is operating normally. If an obstacle is detected at the rear, the system will prompt the driver with warning alarms.

*Note: If a longer, higher pitched sound is emitted for 3 seconds when the R gear is selected, this indicates a fault in the system. In this case seek assistance from an MG Authorised Repairer.*

### Rear Parking Aid

With the parking aid function enabled, if an obstacle is detected, the audible sounds in different frequencies are transmitted (there might be blind zones).

## INTELLIGENT DRIVER ASSISTANCE




- If an obstacle is located within 1.5 m range of the rear or within 0.6 m range of the corner, the warning sound commences. As the car moves closer to the obstacle, the warning sounds are transmitted more rapidly.
- Once the obstacle is within 0.3 m range of the rear bumper, the warning sounds will merge into a continuous warning.

## INTELLIGENT DRIVER ASSISTANCE

### Parking Camera\*



*The purpose of the parking camera system is to assist the driver during parking! The camera has a limited field of view and cannot detect obstructions outside the field of view.*



Some models feature a rear parking camera fitted between the rear license plate lamps.

When R gear is selected, the camera will provide an image of what is immediately behind the vehicle. This image will be shown on the entertainment display.

### 360 Around View Monitor System\*



*The purpose of the 360 around view system is to assist the driver during parking! The cameras have a limited field of view and cannot detect obstructions outside the field of view.*



*Although the infotainment display can provide images around the vehicle, please still pay attention to the current actual road conditions for your driving safety.*

With the 360 around view system working, the entertainment display interface will show a 360 around view of the vehicle to facilitate the observation of surrounding environment and make the driving environment much safer. You can touch buttons on the display to view images from different perspectives around the vehicle.

You can enter the 360 around view system using the following operations:

- Select R gear.
- Click 360 icon.

- Using the 'Setting' interface to select low speed switching of corner lights/indicators, this will automatically open the 360 around view system when the indicators are used at low speeds and exit when the indicators are cancelled.
- After setting the shortcut button on the steering wheel to 360 function, press this button.

In the 360 around view system display interface, select the settings icon to enable personal settings for system functions.

**Note:** *When the shift control knob is placed in D , the 360 around view system is inhibited at speeds above or equal to 20 mph( 35 km/h) .*

## Drive Fatigue Monitoring System\*



*The driver should always ensure that their physical state is suitable for driving, even if the vehicle is equipped with an indirect driver fatigue reminder system. NEVER drive the vehicle when fatigued.*



*The indirect driver fatigue reminder system cannot always identify the driver's fatigue level accurately. It calculates the fatigue level through the driver's operational control status instead of monitoring the driver's actual physical characteristics such as distraction, it cannot provide an emergency reminder to the driver who has just become fatigued.*

The driver attention warning system calculates the driver's fatigue level by comparing information such as vehicle speed and steering wheel angle with basic data obtained based on mass data statistics. The system will constantly compare the calculated fatigue level with the current

operational state of the driver. If the system recognizes that the driver is becoming fatigued, a warning will be issued.

When the indirect driver fatigue reminder system is active, the vehicle speed is over 37 mph ( 60 km/h). When the driver performs any of the following operations, system operation will be suspended and it will stop monitoring the driver's fatigue level:

- 1 The driver removes the seat belt and opens the driver door;
- 2 The stop time exceeds 15 minutes;
- 3 The ignition or power system is turned off.

### System Settings

After the vehicle is started, the indirect driver fatigue reminder system is enabled by default, it can be turned off/on and the sensitivity can be set in the entertainment display screen.

**Note: The indirect driver fatigue reminder system is not easily triggered if the vehicle is passing through low-quality road sections, continuous bends, or sections with large amounts of traffic lights.**




## **Road Emergency Response**

---

<i>Hazard Warning Devices</i>	266
<i>Emergency Starting</i>	267
<i>eCall-SOS Emergency Assistance*</i>	271
<i>Vehicle Recovery</i>	274
<i>Tyre Repair*</i>	278
<i>Wheel replacement*</i>	281

## Hazard Warning Devices

### Warning Triangle



The warning triangle is stowed in the loadspace. .

If you have to stop your car on the road in an emergency, you must place a warning triangle approximately 50 ~ 150 metres behind the car, if possible, and press the hazard warning lamp button to warn other road users of your position.

### Emergency Starting



***NEVER attempt to power the vehicle by pushing or towing.***



***Make sure that both batteries are of the same rated voltage (12 volts), and that the booster cables are approved for use with 12 volt car batteries.***



***Ensure sparks and open flames are kept well away from the front compartment.***



***When HEV models start with a jump start, try to use the positive terminal of the battery as the positive jump point when the tailgate is allowed to open. If the tailgate cannot be opened, open the front compartment fuse box, and the terminal shown in the figure can serve as the positive terminal jumper.***


***When starting fuel vehicles with a jump start, try to use the positive terminal of the battery as the positive jump point. If the positive terminal of the battery cannot be used, open the front compartment fuse box, and the terminal shown in the figure can serve as the positive jump point.***



***Ensure that booster cables are firmly connected and do not touch each other or other moving parts, otherwise, sparks may be caused, resulting in fire or explosion.***


In case of low battery, the vehicle can be started by using a booster cable to connect the battery of another vehicle or to connect the battery externally.

## ROAD EMERGENCY RESPONSE




### I Positive pole crossover point

Turn off the vehicle power and all electrical appliances of the vehicle, then follow the instructions below:



## ROAD EMERGENCY RESPONSE



- 1 Connect a RED booster cable between the positive (+) terminals of donor vehicle (A) and the positive pole crossover point of disabled vehicle (B). Connect the black booster cable from the negative (-) terminal of the donor vehicle (A) to a good earth point (an engine mounting or other unpainted surface, for example) on the disabled vehicle (B), and try to keep it well away from the battery and bypass the fuel and brake lines.

- 2 Start the donor vehicle and allow it to idle for several minutes.
- 3 Start the disabled vehicle. If the disabled vehicle will not start after several attempts, it may need to be repaired. Please contact the local MG Authorised Repairer for an overhaul.
- 4 After both vehicles are started normally, turn off the donor vehicle power.
- 5 Disconnect the booster cables. Disconnecting the booster cables must be an exact reversal of the procedure used to connect them, i.e. disconnect the BLACK negative cable from the earth point on the disabled vehicle FIRST.

### IMPORTANT

DO NOT switch on any electrical appliance in the disabled vehicle until the booster cables have been disconnected.

## ROAD EMERGENCY RESPONSE

---

**Note:** *It is recommended to turn off the lights, air conditioner and other comfort appliances after starting the vehicle with power loss and keep the vehicle running for 1~2 hours to restore the battery power. If the battery is fully charged and the vehicle still cannot be normally started, please contact an MG Authorised Repairer for service.*

**Note:** *If the vehicle still cannot be started by connecting the booster cables, please consult an MG Authorised Repairer for service.*

### eCall-SOS Emergency Assistance\*

The eCall service is a public service of general interest and is accessible free of charge. The emergency call centre will establish verbal communication with the vehicle occupants in order to understand the extent of the emergency and the level of assistance required. If verbal communication is not achievable an attempt will be made to send the following vehicle information message to the emergency call centre. The appropriate emergency services will be deployed to the vehicle's current location if known.

- Current time, location and direction of travel
- Vehicle Type
- Vehicle Identification Number (VIN)
- Whether the call was automatically or manually initiated
- Vehicle Category
- Number of passengers


This system will ensure that your personal data is securely protected. It is designed to ensure that it is not traceable and other external systems are not able to gain access. When the eCall triggers, the system will only transmit the data information to the relevant public safety answering points designated by the respective public authorities of

the country on which territory they are located, which will receive and process your emergency call request. The system will retain data locally within 13 hours of triggering.

You have the right to access the data information stored in this system, and to request the rectification, erasure or blocking of data information that does not meet the requirements of the regulations. When you think your personal data is infringed, you have the right to complain to the competent data protection authority.

For manual activation, press and release the SOS button in the overhead console for about 1 second to activate an emergency services call. A single beep will be heard when the eCall is triggered and a message will be displayed on the vehicle's message centre and entertainment player. The entertainment player will be muted whilst the emergency services call is active. Manually triggered emergency services calls may be cancelled by pressing and releasing the SOS button again within about 5 seconds of the initial press, and the messages will be removed.

## ROAD EMERGENCY RESPONSE



The emergency services call (eCall) system will perform a self-test when the vehicle is powered ON. During a Self-Test the emergency services call (eCall) LED status indicator on the SOS button will flash quickly until completion. The LED status indicator will illuminate permanently if no system faults are present. The LED status indicator will be extinguished or flash slowly if a fault is detected. Faults detected during the self-test will be displayed on the vehicles message centre.



**Note:** *The operation of eCall - SOS Emergency Assistance relies on cellular coverage and may be affected by signal outages or low signal strength.*

**Note:** *The automatic emergency services call (eCall) function may be disabled by a local MG Authorised Repairer upon request.*

**Note:** *It is strongly recommended the eCall function is not disabled, any action requested by the owner must be accompanied by a signed request.*

## Vehicle Recovery

### Towing Vehicle



*Do not tow the vehicle with any of the driven wheels in contact with the road surface, this will avoid electric drive transmission damage. When it is necessary to temporarily push or tow the vehicle from a dangerous situation or onto the transporter, the speed must remain below 3 mph (5 km/h) and be completed within 3 minutes.*




*When pushing or towing the vehicle for temporary situation, the driver's side seat belt should be inserted into the lock and maintained in the inserted state, the transmission placed in Neutral and the parking brake must be OFF, otherwise the vehicle may be damaged.*

### Towing Hook



*Do not use a tow rope that is twisted, the towing eye may become unscrewed.*

## ROAD EMERGENCY RESPONSE



The towing hook is in the tool kit. The tool kit is placed beneath the loadspace carpet. To fit the towing hook, remove the small cover on bumper. To fit the towing hook, remove the small cover set into the bumper, first press one end of the small cover plate, then open the small cover plate after the other end is lifted, then screw in the towing hook via the small hole into the threaded hole in the bumper beam (see illustration). Ensure the towing hook is fully tightened!

Some models do not have rear towing function

## ROAD EMERGENCY RESPONSE

**Note:** *The removable cover is secured to the bumper by a plastic cord.*




The towing point is intended for use by qualified recovery specialists to assist in the recovery of your vehicle when a breakdown or accident occurs. But it is not designed for towing other vehicles. The vehicle can be towed using a tow rope but a towing bar is recommended.

### Towing for Recovery



**When towing, DO NOT accelerate or brake suddenly, this can cause accidents.**


### Suspended Towing



Suspended towing is the best method for recovering a vehicle that needs to be towed. The drive wheels should be suspended above the ground, or the transmission may be damaged. Release the parking brake, turn on the hazard warning lamps and ensure there are no passengers. If towing the vehicle with rear wheels on the ground, please release the parking brake.

### Transporting the Vehicle

If your vehicle needs to be transported, a special transporter is recommended. Secure the vehicle on the transporter as follows:



- 1 Apply the parking brake and engage in P gear.
- 2 Fit wheel chocks ( 1 ) as shown, then position the anti slip rubber blocks ( 2 ) around the circumference of the tyre.

- 3 Fit the lashing straps ( 3 ) around the wheels and secure to the trailer. Tighten the straps until the vehicle is securely held.


# ROAD EMERGENCY RESPONSE

## Tyre Repair\*

### Tire repair tool

The tire repair tool is placed under the carpet in the trunk of the vehicle.


### Tool recognition



- 1 Towing Hook
- 2 Wheel Bolt Cap Removal Tool
- 3 Repair Fluid
- 4 Electric Air Pump

## Tyre Repair


- 1 Remove the label at the bottom of the repair fluid reservoir and attach it to the steering wheel to remind the driver not to exceed 80 km/h ( 50 mph ) .



- 2 Connect the air hose of the electric air pump to the repair fluid reservoir, fit the repair fluid reservoir bottle (upright) into the slot on the compressor. Remove the valve dust cap of the flat tyre and connect the filler hose from the repair fluid reservoir bottle to the tyre valve. Ensure that the power switch of the

## ROAD EMERGENCY RESPONSE

electric air pump is in switched off (i.e., press 'O'), then insert the plug from the electric air pump into the centre console power socket, and turn the vehicle power system on.



**Note:** To avoid battery discharge, it is recommended to keep the vehicle in P and READY mode.

- 3 Switch on the power switch of the electric compressor (i.e., press '—'), to start pumping sealant into the tyre. The repair fluid reservoir bottle will become empty

after approximately 30 seconds. The tyre should reach the specified pressure within 5 or 10 minutes.

**Note:** The pressure gauge may briefly reach 600 kPa (i.e. 6 bar), the pressure will then return to normal.

- 4 When the required pressure is reached, switch off the electric air pump (i.e., press 'o').

**Note:** If the required pressure cannot be reached within 10 minutes, please disconnect the compressor, drive the vehicle 10 metres approx forward or backward to allow the sealant to spread within the tyre. If the required pressure can still not be reached, the tyre is severely damaged and you should seek assistance from the Roadside Assistance company or an MG Authorised Repairer.

**Note:** Continual operation of electric air pump for more than 10 minutes may result in damage to the compressor.

- 5 Remove the tyre sealant bottle from the slot and disconnect the hose of the tyre sealant bottle from the tyre valve. Then remove the plug of the electric air pump from the centre console power socket, return the tyre repair kit to its stowage tray.

## ROAD EMERGENCY RESPONSE

- 6 After successfully adding sealant to the tyre, drive immediately for a short time (around one minute). This will allow the sealant to distribute evenly inside the tyre. Continue driving and do not exceed 50 mph ( 80 km/h), driving distance not exceeding 3 miles ( 5 km ) , find a safe place to stop and recheck the tyre pressure.


Please follow different guidelines based on the tyre pressure measured:

If the tyre pressure has dropped to less than 80 kPa ( 0.8 bar), do not continue driving, seek assistance instead.

If the tyre pressure is between 80 kPa ( 0.8 bar) and the specified pressure, connect the hose of the electric air pump to the tyre valve, and inflate the tyre until it reaches the specified pressure. Repeat Step 6 .

If the tyre pressure has not dropped, you may continue driving, but the vehicle speed must not exceed 50 mph( 80 km/h), and the driving mileage must not exceed 120 miles( 200 km).

**Note: DO NOT remove foreign objects (eg. screws, nails etc) from the tyre. The tyre repair system must only be used when the foreign object is in the tread pattern ( A ), DO NOT attempt a repair when the damage is in the sidewall of the tyre ( B ).**






## Wheel replacement\*

### Spare tire and tools

Open the luggage carpet, remove the spare tire fixing nut, and take out the spare tire and spare tire tool.

### Replace spare tire tool



- 1 Towing hook
- 2 Wheel bolt cap removal tool
- 3 Jack
- 4 Jack handle
- 5 Wheel bolt spanner

## Wheel Replacement

If you need to change the wheel during the journey, choose a safe place to stop away from the main road if possible. Always ask your passengers to get out of the car and wait in a safe area away from other traffic.

Switch on hazard warning lamps. If available, position a warning triangle about 50 ~ 150 metres behind your vehicle to warn approaching traffic.

Before changing a wheel, ensure the front wheels are in the straight ahead position. Apply the parking brake and place the shift lever in P position. Place the Ignition/START/STOP switch in ' OFF ' position.

### Positioning the Jack




**DO NOT work underneath the car with a wheel changing jack as the only means of support. The jack is designed for wheel changing only!**



**NEVER jack the car using any positions other than the jacking points, otherwise serious damage may be caused.**

## ROAD EMERGENCY RESPONSE

Position the jack on firm level ground under the jacking point nearest the wheel to be removed. Turning the jack screw handle by hand, adjust the jack until the jack head fits snugly onto the flanging of the body.



Ensure that the base of the jack is in full contact with the level ground.

### IMPORTANT

- Ensure the jack is positioned on firm, level ground.
- If the vehicle must be parked on the hill, place chocks in front of and behind other 3 wheels to prevent the vehicle moving.

### Fitting the Spare Wheel



*Regularly check the spare wheel tyre pressure, it may be under pressure due to being unused for long periods of time. Always check the tyre pressure after changing a wheel.*



*The wheel bolts must be tightened to the specified torque after changing a wheel (120 ~ 130 Nm).*

- 1 Before raising the car, use the special tool supplied to remove each wheel bolt cap. Use the wheel bolt spanner to slacken each bolt half a turn anti-clockwise.
- 2 With the jack correctly positioned, rotate the handle in a clockwise direction until the tyre is clear of the ground.  
**Note:** *For your safety, place the spare tyre under the body flange near the jack, and avoid placing wheels face down on the ground - the surface may be scratched.*
- 3 Remove the wheel bolts and store to prevent them from being lost. Make sure the vehicle is steady and

there is no risk of slip or movement before removing wheel bolts.

- 4 Remove the wheel.

**Note:** *Place the removed wheel under the body flange near the jack, and avoid placing wheels face down on the ground - the surface may be scratched.*

- 5 Fit the spare wheel and tighten the wheel bolts until the wheel is seated firmly against the hub.
- 6 Lower the vehicle and remove the jack, then FULLY tighten the wheel bolts in a diagonal sequence.
- 7 Return the tools to the storage assembly and place the wheel in the loadspace.

**Note:** *DO NOT stand on the handle of the wheel bolt spanner or use extension tube on the handle of the spanner.*

**Note:** *When replacing the wheel, please fully tighten the bolts in the diagonal sequence twice.*

**Note:** *Consult an MG Authorised Repairer or tyre specialist for a replacement tyre as soon as possible.*

### Spacesaver Spare Wheel



*Only one spacesaver spare wheel can be used at any one time, otherwise the operational performance and brake performance may be reduced, thereby leading to accident or injury to yourself and others.*



*When driving on snow covered or icy roads, it is advised to fit the spacesaver wheel to the rear wheels of the vehicle to maintain adequate stability. If the front wheel tyre is damaged, a rear wheel should be moved to the position of a front wheel, and then fit the spacesaver spare wheel in the position of the rear wheel.*



*Snow chains can not be used on the spacesaver spare wheel, this can cause damage to the car and snow chain.*

When the spacesaver spare wheel is fitted, drive the car with care, and the speed should not exceed 50 mph ( 80 km/h). Please have the full sized tyre repaired and replace

the spare wheel as soon as possible. This will extend the life span of the spare wheel for other emergencies.

**Note: DO NOT use an automatic car wash when the spacesaver wheel is fitted, the guide rails of the car wash may conflict with the wheel/tyre and cause damage.**

## Maintenance

---

<i>Maintenance Instructions</i>	286	<i>Replacing the Smart Key Battery</i>	330
<i>High Voltage Battery Pack*</i>	290	<i>Tyres</i>	333
<i>Bonnet</i>	292	<i>Cleaning and Caring</i>	339
<i>Front Compartment</i>	294		
<i>Engine Oil</i>	297		
<i>Catalytic Converters and Particulate Filters *</i>	300		
<i>Cooling System</i>	302		
<i>Brake</i>	305		
<i>Fuse Replacement</i>	308		
<i>12V Battery</i>	316		
<i>Bulb Replacement</i>	318		
<i>Washer</i>	325		
<i>Wipers</i>	327		

## Maintenance Instructions

### Regular Maintenance

The safety, reliability and performance of your vehicle will depend partly on how well it is maintained. You must ensure that maintenance is carried out when required and according to the information contained in the Warranty and Maintenance Handbook.

### Servicing

For next service information, please refer to 'Instrument Pack' in 'Brief Introduction to Vehicle Functions' section or information related to the entertainment system. After the completion of each service, the next service display will be reset by your MG Authorised Repairer.

**Note:** *If the maintenance is not carried out (or the display is not reset by an MG Authorised Repairer after maintenance), the maintenance display will not be able to provide correct information.*

### Maintenance History

After each maintenance, always ask your local Authorised Dealer to register the maintenance.

### Fluid

Please use the fluid recommended and certified by SAIC Motor. Refer to 'Recommended Fluids and Capacities' in the 'Technical Data' section.

#### IMPORTANT

Using fluids or additives inapplicable to this vehicle may damage the components or devices; please consult a local MG Authorised Repairer for details.

### Emission Control

Your car is fitted with exhaust emission and evaporative control equipment designed to meet specific territorial and legal requirements. Incorrect engine settings may adversely affect exhaust emissions, engine performance and fuel consumption, as well as cause high temperatures, which could result in damage to the catalytic converters and engine.

## IMPORTANT

You should be aware that unauthorised replacement, modification or tampering with this equipment by an owner or motor vehicle repairer could result in the manufacturer's warranty being deemed as invalid. In addition, no adjustment can be made to the engine settings. Otherwise, the vehicle emission indexes could be affected.

### Owner Maintenance



*Any significant or sudden drop in fluid levels, or uneven tyre wear, should be reported without delay to an MG Authorised Repairer.*

In addition to the maintenance referred to previously, some simple checks must be carried out more frequently.

#### Daily Check

- Operation of lights, horn, wipers, washers and warning lights.
- Operation of seat belts and brakes.

- Look for fluid deposits underneath the car that might indicate a leak.
- Check tyre appearance.

#### Weekly Check

- Engine oil level.
- Coolant level.
- Brake fluid level.
- Windscreen washer fluid level.
- Tyre pressure.
- Operate air conditioning.

**Note:** *The engine oil level should be checked more frequently if the car is driven for prolonged periods at high speeds.*

## Special Operating Conditions

If your vehicle is frequently used in dusty conditions, or operated in extreme climates where sub-zero or very high ambient temperatures are normal, more frequent attention may need to be paid to maintenance requirements. You need to carry out special maintenance operations (refer to Warranty and Maintenance Handbook) or contact the local MG Authorised Repairer.

## Safety in the Garage



***Cooling fans may commence operating after the engine is switched off, and continue operating for a number of minutes. Keep clear of all fans while working in the engine compartment.***

If you need to carry out maintenance, observe the following safety precautions at all times:

- Keep your hands and clothing away from drive belts and pulleys.
- If the car has been driven recently, **DO NOT TOUCH** exhaust and cooling system components until the engine has cooled.

- **DO NOT TOUCH** electrical leads or components while the engine is running, or with the Start switch on.
- **NEVER** leave the engine running in an unventilated area - poisonous exhaust gases are extremely dangerous.
- **DO NOT** work underneath the vehicle with a jack as the means of support.
- Ensure that sparks and naked lights are far away from the engine compartment.
- Wear protective clothing and work gloves.
- Remove watches and jewelry before working in the engine compartment.
- **DO NOT** allow tools or metal parts of the vehicle to make contact with the battery leads or terminals.

## Toxic Fluids

Fluids used in motor vehicles are poisonous and should not be consumed or brought into contact with open wounds. These include: battery acid, coolant, brake fluid, fuel, engine oil and windscreen washer fluid.

For your own safety, **ALWAYS** read and obey all instructions on labels and containers.



### **Used Engine Oil**

Prolonged contact with engine oil may cause serious skin disorders such as dermatitis and cancer of the skin. Wash thoroughly after contact. Used engine oil should be disposed of correctly. Incorrect disposal can cause a threat to the environment.

### High Voltage Battery Pack\*

#### Precautions and restricted conditions for use of battery



*If the vehicle is not going to be used, parked, or stored for a long time it is necessary to use the vehicle at least once every two months for more than 30 minutes each time (the power of high-voltage battery pack shall be maintained at 50% charge (or 4 gauge blocks) or more). It is strictly prohibited to park or store a vehicle fitted with a high-voltage battery pack for more than 7 days if the power of the high-voltage battery pack is low, failure to follow these guidelines may effect the high voltage battery warranty.*



**DO NOT attempt to dismantle the battery pack or any High Voltage components - THESE ARE DANGEROUS. Any signs of dismantling or damage caused by attempts to dismantle will invalidate the warranty.**

- 1 DO NOT park the vehicle in conditions where the ambient temperature exceeds 45°C for more than 15 days. This will effect the performance and service life of the high voltage battery.
- 2 In order to better extend the service life of the high-voltage battery pack, it is recommended to use the vehicle at least once a month for more than 30 minutes each time to facilitate the vehicle to charge and maintain the high-voltage battery pack.
- 3 When the vehicle is used for the first time or after a long period of storage, the SOC displayed in the instrument pack may not be accurate. It is recommended to drive at a low speed of 19~30 mph (30~50 km/h) for 20~30 minutes before normal use.
- 4 The cooling system of high-voltage battery pack is equipped with air filter element, please replace it as per manufacturers maintenance schedule.
- 5 In the event of an accident, damage to the high voltage battery or any of its related components, or any repairs made to the high voltage system the car must be inspected by qualified personel at an MG Authorised Repairer.

- 6 In the event of any accident or body repairs being required please consult the qualified personnel at an MG Authorised Repairer. The repair may require high voltage battery isolation or specialist HV component removal.

### IMPORTANT



Only fully trained and qualified personnel are allowed to work on the high voltage systems and components of this vehicle. Any disassembly of such systems or components is strictly prohibited.

## Bonnet

### Opening the Bonnet



**DO NOT drive when the bonnet is not closed or retained only by the safety catch.**



- 1 Pull the bonnet release handle ( A ) from the inside of the vehicle.

- 2 Move the safety catch release handle on the bonnet lock body in the direction of the arrow ( B ) to release the bonnet safety catch.
- 3 After unlocking the bonnet, go to the front of the vehicle to lift the bonnet and hold it up with the support rod.

### Closing the Bonnet

Support the bonnet using one hand, release the support rod using the other hand, and place it firmly into the support rod base. Hold the bonnet using both hands and lower it. When the bonnet drops for about the last 20 ~ 30 cm, apply a downward force to fully close the bonnet.

By attempting to lift the front edge of the bonnet, check if the lock is fully engaged after closing the bonnet. If it is not fully engaged, you must repeat the operation.

### Bonnet Open Alarm\*

If the bonnet is not fully locked, the corresponding alarm icon will be shown on the message centre display. If it is found that the bonnet is not fully locked while driving, an audible warning will sound.

## IMPORTANT


- For safety reasons, the bonnet should always be closed well when driving. Therefore you must check after closing the bonnet that the bonnet is securely latched, e.g. the bonnet edge is flush with the body of the vehicle.
- You should stop the vehicle immediately when safety permits and close the bonnet if it is not fully closed when driving.
- Beware of hands being pinched while fully closing the bonnet with a downward force.

## Front Compartment




*While operating the components in the engine compartment, always observe the safety precautions listed under "Safety in the Garage". Refer to "Maintenance" of this section.*

### Gasoline model-1.5L




- 1 Washer Fluid Reservoir
- 2 Engine Coolant Expansion Tank
- 3 Brake Fluid Reservoir
- 4 Oil Dipstick
- 5 Oil Filler Cap

## Gasoline model-I.5T



- 1 Washer Fluid Reservoir
- 2 Engine Intercooler Coolant Expansion Tank
- 3 Engine Coolant Expansion Tank
- 4 Brake Fluid Reservoir
- 5 Oil Dipstick
- 6 Oil Filler Cap

## HEV model



- 1 Washer Fluid Reservoir
- 2 Brake Fluid Reservoir
- 3 Oil Filler Cap
- 4 Oil Dipstick
- 5 Engine Coolant Reservoir
- 6 Hybrid Drive Coolant Reservoir



## Engine Oil


### Engine Oil

#### Engine Oil ACEA/API Category

European Automobile Manufacturers' Association ( ACEA ) and American Petroleum Institute ( API ) classify the engine oils based on performance and quality. To ensure the best performance of the vehicle, please use 0W-20 engine oil recommended by SAIC Motor that complies with ACEA C5 and API SP specifications. 0W-20 engine oil is suitable for low temperature and normal temperature environments, and is all-purpose engine oil for all seasons.

#### IMPORTANT

Do not allow the engine to run at low coolant temperature for a long time. If you have made several short drives and have not reached normal engine operating temperature each time, please extend the engine running time to bring the engine up to normal operating temperature.




### Engine Oil Check and Refill



**Driving the vehicle with the engine oil level ABOVE the upper mark, or BELOW the lower mark on the dipstick, will damage the engine.**



**Do not spill engine oil onto a hot engine, otherwise it may cause fire.**



Check the oil level weekly and refill as necessary. Ideally, the oil level should be checked with the engine cold and the car resting on level ground. If the engine is running and already getting warm, wait for at least five minutes after switching off the Start switch before checking the oil level.

- 1 Withdraw the dipstick and wipe off the oil on it.
- 2 Slowly insert the oil dipstick and pull it out again to check the oil level; the oil level shall not be lower than the " MIN " mark on the oil dipstick.
- 3 Unscrew the engine oil filler cap and refill the oil to maintain the oil level between " MAX " mark and " MIN " mark on the oil dipstick.
- 4 Please wait for 5 minutes and then recheck the oil level; add an appropriate amount of oil if necessary - **DO NOT OVERFILL!**
- 5 Finally, ensure the dipstick is inserted and oil filler cap is fully secured.

## Engine Oil Specification

Use the engine oil recommended and certified by the SAIC Motor. Refer to "Recommended Fluids and Capacities" in the "Technical Data" section.

***Note: Any engine misfire, loss of engine performance or engine run-on, could seriously damage the catalytic converter and particulate filter. Regular maintenance must be carried out in accordance with the maintenance schedule specified by the manufacturer. Any modifications to the engine without manufacturer authorisation is prohibited.***

### IMPORTANT

Check the engine oil level more frequently if the vehicle is driven at high speeds for prolonged periods.

### Catalytic Converters and Particulate Filters \*



*The temperatures of exhaust systems that contain particulate filters and catalytic converters can be extremely high. DO NOT park on ground where combustible materials such as dry grass or leaves could come into contact with the exhaust system - thus could result in a fire.*

The exhaust system incorporates a catalytic converter and particulate filter (model dependent), these process possible harmful exhaust emissions from the engine into more environmentally friendly gases. Exhaust system layouts differ between engine derivatives.

Catalytic converters and gasoline particulate filters are easily damaged through improper use, please observe the following precautions to minimise the chance of accidental damage.

#### **Fuel**

- Use ONLY fuel recommended for your vehicle.

- Never allow the vehicle to run out of fuel – this could cause engine misfire and serious damage to the catalytic converter and particulate filter.

#### **Engine Oil**

- Use ONLY engine oil recommended for your vehicle. If a non-recommended oil is used, the catalytic converter and particulate filter may be damaged.

**Note:** Carry out scheduled servicing according to the maintenance schedule in the "Warranty & Maintenance Handbook".

#### **Starting**

Pay attention to the following when starting the engine:

- Do not continue to operate the starter after a few failed attempts; seek an MG Authorised Repairer.
- Do not operate the starter if an engine misfire is suspected and do not attempt to clear a misfire by pressing the accelerator pedal.
- Do not attempt to push or tow start the vehicle.

#### **Regeneration**

The particulate filters equipped on the vehicle has regeneration function. When the vehicle reaches certain running conditions (such as the speed is greater than 80

km/h), the vehicle will automatically burn away the carbon particulate matter adsorbed in the particulate filters.

### **Driving**

Please pay attention to the following conditions:

- Do not overload or excessively 'rev' the engine.
- Do not stop the engine when the car is in motion with a gear selected.
- Consult an MG Authorised Repairer immediately if you think your vehicle's engine oil consumption is abnormal or the engine performance will be reduced.
- If the engine is shaking abnormally, or the vehicle lacks power while driving, consult an MG Authorised Repairer immediately.
- Do not drive on terrain likely to subject the underside of the car to heavy impacts.

**Note: Any engine misfire, loss of engine performance or engine run-on, could seriously damage the catalytic converter and particulate filter. Regular maintenance must be carried out in accordance with the maintenance schedule specified by the manufacturer. Any modifications to the engine without manufacturer authorisation is prohibited.**

## Cooling System




*Do not remove the coolant expansion reservoir cap when the cooling system is hot - escaping steam or hot coolant could cause serious injury.*


**Note:** *Prevent coolant coming into contact with the vehicle body in adding. Coolant will damage paint.*

## Coolant Check and Top Up


**Coolant expansion reservoir - 1.5T Gasoline Only**



## Coolant expansion reservoir - 1.5L Gasoline Only



## Coolant expansion reservoir - 1.5L HEV



- 1 Transmission expansion reservoir
- 2 Engine expansion reservoir

It is recommended that the cooling system should be checked weekly when the cooling system is cold and with the vehicle resting on level ground. If the coolant level is below 'MIN' mark, remove the coolant expansion tank

cap and add coolant, but ensure the level does not surpass the ' MAX ' mark.

### Coolant Specification



*Coolant is poisonous and can be fatal if swallowed - keep coolant containers sealed and out of the reach of children. If accidental contact of coolant by children is suspected, seek medical assistance immediately.*



*Prevent the coolant from coming into contact with the skin or eyes. If this occurs, rinse immediately with plenty of water. If eyes are still red, painful or uncomfortable, seek medical attention immediately.*

Please use the coolant recommended and certified by the manufacturer. Refer to 'Recommended Fluids and Capacities' in the 'Technical Data' section.

**Note:** *The addition of corrosion inhibitors or other additives to the cooling system of this car may severely disrupt the efficiency of the system and cause parts damage. For cooling system issues please consult an MG Authorised Repairer.*



### Brake



***DO NOT rest your foot on the brake pedal while driving; this may overheat the brakes and reduce their efficiency, causing excessive wear to the brake components.***

The free stroke of brake pedal is in the range of 0 ~ 30 mm.

Reasonable usage scope of brake friction pair: not less than 2 mm for thickness of brake pads. For the MT model , 20 ~ 22 mm for front brake disc, and 8 ~ 10 mm for rear brake disc\*; MAX 231.5mm for the rear brake drum\*. For CVT or the HEV model , 23 ~ 25 mm for front brake disc and 8 ~ 10 mm for the rear brake disc.

For the first 900 miles( 1500 km), you should avoid situations where heavy braking is required.

Note that regular maintenance is vital to ensure that all the brake components are examined for wear at the correct intervals and replaced when necessary to ensure long-term safety during the interval prescribed in the Warranty and Maintenance Handbook.

The vehicle needs to run in for 500 miles( 800 km) after the brake pad or disc is replaced.

## Brake Fluid Check and Top Up



*Brake fluid is highly toxic, keep the brake fluid sealed and stored out of reach of children. If accidental contact of brake fluid is suspected, seek medical attention immediately.*



*Prevent brake fluid coming into contact with the skin or eyes. If this occurs, rinse immediately with plenty of water. If eyes are still red, painful or uncomfortable, seek medical attention immediately.*

The brake fluid level should be checked weekly when the system is cold and with the car on level ground. Clean the cover first before opening the brake fluid reservoir.


The brake fluid level can be seen through the reservoir and should be maintained between the 'MAX' and 'MIN' marks.

**Note:** Do not allow the brake fluid level to drop below the 'MIN' mark or rise above the 'MAX' mark.



## Brake Fluid Specification

Use the brake fluid recommended and approved by the manufacturer. Refer to 'Recommended Fluids and Capacities' in the 'Technical Data' section.



### IMPORTANT

Replace brake fluid regularly according to service schedule.

**Note:** Brake fluid will damage painted surfaces. If you accidentally spill the brake fluid on the painted surface, soak up any spillage with an absorbent cloth immediately and wash the area with water or car shampoo.

## Fuse Replacement

### Fuse

Fuses are simple circuit breakers which protect the car's electrical equipment by preventing the electrical circuits from being overloaded. A blown fuse indicates that the circuit under its protection fails and stops working.

If you suspect a fuse is faulty, you can take it out of the fuse box and inspect it to see if the wire in the fuse is blown.


***Do not attempt to repair or replace blown fuses with fuses with inconsistent ampere values, as this may cause damage to the electrical system or lead to a fire due to wire overload.***

***If the replaced fuse immediately blows, please contact the local authorized after-sales service center for maintenance as soon as possible.***

It is recommended to have spare fuses in the vehicle, which can be obtained from MG Authorised Repairer.


### Fuse Box

The vehicle is equipped with 2 fuse boxes:



- 1 Passenger compartment fuse box (behind the driver side knee trim panel)
- 2 Front compartment fuse box (left of the front compartment)

## Passenger Compartment Fuse Box



### Check or Replace a Fuse

- 1 Turn off the Start switch and all electrical appliances, and disconnect the negative battery cable.
- 2 Remove the driver side knee trim panel to access the fuse box.

- 3 Clamp the fuse head with a fuse extraction tool in the fuse box cover of the front compartment, pull and remove the fuse, and check whether the fuse is blown.
- 4 If a fuse is blown, replace it with another fuse of the same type and same ampere value.

### Fuse Specification

Code	Spec.	Function
F1	40A	Blower Relay , Temperature Controller
F2	5A	Instrument Cluster, Data Link Connector (DLC)
F3	10A	Gateway
F4	5A	Ignition Switch , Front View Camera Module , Rear Drive Assist Module


## MAINTENANCE

Code	Spec.	Function
F5	5A	EPB Switch、 PRND Gear Display Module , Light Switch , Driver's Side Door Combination Switch
F6	5A	Instrument Panel Irregular Display Screen , Infotainment Faceplate Switch , Clock Spring
F7	5A	Alcohol Interlock Control Module
F8-F9	-	-
F10	10A	Left Front Seat Heat Relay;Right Front Seat Heat Relay
F11	25A	Driver Seat Adjustment Switch
F12	-	-
F13	5A	Shifter Control Unit
F14	10A	Airbag Control Module

Code	Spec.	Function
F15-F16	-	-
F17	20A	Front Passenger Side Seat Control Module
F18	15A	Steer Wheel Heated Relay
F19	-	-
F20	30A	Sunroof
F21	20A	Radio , Front Infotainment ControlModule (FICM)
F22	-	-
F23	5A	Heating Ventilation And Air Conditioning
F24	-	-
F25	5A	Telematics Box
F26	-	-
F27	5A	Super Lock Relay

Code	Spec.	Function
F28	-	-
F29	10A	Electronic Steering Column Lock
F30-F43	-	-
F44	15A	Front Console Power Socket
F45	5A	Master Light Switch , Left Headlamp Assembly , Right Headlamp Assembly , Pedestrian Alert Control Module , Blower Relay
F46	5A	Mobile Phone WirelessCharger, Rear Row USB Port,Interior Mirror USB Interface

## Front Compartment Fuse Box



### Check or Replace a Fuse

- 1 Turn off the Start switch and all electrical appliances, and disconnect the negative battery cable.
- 2 Press the lock catch to open the upper cover of front compartment fuse box.
- 3 Clamp the fuse head with a fuse extraction tool in the upper cover, pull and remove the fuse, and check whether the fuse is blown.

## MAINTENANCE

- 4 If a fuse is blown, replace it with another fuse of the same type and same ampere value.

### Fuse Specification

Code	Spec.	Function
F1	-	-
F2	30A	Direct Current Direct Current Converter
F3	40A	Rear Windshield Heat Relay
F4	10A	Exterior Mirror , Electric Heated Washing Nozzles
F5	40A	Stability Control System
	60A	Integrated Brake System
F6	30A	Body Control Module
F7	40A	Stability Control System
	60A	Integrated Brake System
F8	30A	Electric Vacuum Pump

Code	Spec.	Function
F9	-	-
F10	30A	Starter Motor
F11	30A	Body Control Module
F12	30A	Body Control Module
F13	5A	Heating Ventilation And Air Conditioning , Body Control Module , Shifter Control Unit , Instrument Cluster , Gateway , Direct Current Direct Current Converter
F14	10A	Alcohol Interlock Control Module
F15	20A	Engine Control Module
F16	20A	Transmission Control Unit
F17	5A	Battery Current Sensor



## MAINTENANCE

Code	Spec.	Function
F18	5A	Rear Parking Distance Sensor , Sensing Diagnostic Module
F19	10A	Engine Control Module , Transmission Control Unit , Stability Control System , Integrated Brake System , Actuator Control Unit , Power Electric Unit
F20-F21	-	-
F22	15A	Electric Vacuum Pump Relay , Air Conditioning Three Status Pressure Switch , Two Level Resistive Cooling Fan Relay Pack , Rear Oxygen Sensor , Clutch Master Cylinder Sensor , Front Oxygen Sensor , Engine Oil Pump Flow Control Solenoid Valve , Canister Purge Valve

Code	Spec.	Function
F23-F24	-	-
F25	10A	Hybrid Electric Vehicle Battery Management System
F26	-	-
F27	15A	Engine Electronic Water Pimp Auxiliary System
F28	15A	Ignition Coil , Engine Control Module
F29	15A	Engine Control Module , Transmission Control Unit
F30	10A	Engine Control Module
F31	15A	Rear Wiper Relay
F32	10A	Electric Air Conditioning Compressor , Air Conditioning Compressor
F33	15A	Fuel Injector

## MAINTENANCE

Code	Spec.	Function
F34	5A	Brake Switch
F35	25A	Heated Rear Window Relay
F36	30A	Body Control Module
F37	15A	Horn Relay , Front Windscreen Washer Relay , Rear Windscreen Washer Relay
F38	5A	PEB Coolant Pump Power Relay , Front windshield relay
F39	-	-
F40	20A	Constant Supply Fuel Pump
F41	5A	Starter Motor
	15A	PEB Coolant Pump Power Relay

Code	Spec.	Function
F42	30A	Driver Side Window Combination Switch , Driver's Side Window Lifting Motor , Left Rear Window Switch
F43	30A	Body Control Module
F44	30A	Front Passenger Side Window Switch , Right Rear Window Switch
F45	30A	Body Control Module
F46	20A	Trailer Device Module
F47	15A	Trailer Device Module
F48	30A	Actuator Control Unit , Power Electric Unit
F49	30A	Belt Actuation Electric Oil Pump
	25A	Stability Control System

Code	Spec.	Function
F50	25A	Front Wiper Relay
FUSE A-FUSE B	-	-
FUSE C	100A	Passenger Side Fuse Box
FUSE D	60A	Electric Power Steering
FUSE E-FUSE I	-	-
FUSE J	60A	PWM Cooling Fan
	40A	Two Level Resistive Cooling Fan Motor
FUSE K	60A	Engine Electrical Main Water Pump

## 12V Battery

### Battery Maintenance



**DO NOT use on-board electrical appliances for an extended period of time when the vehicle is not started, otherwise the battery may become flat, resulting in the failure to start the vehicle and the reduction of battery life.**



**Always store batteries upright, and never attempt to dismantle a battery.**




**Please note the following:**

- **Keep away from inflammables.**
- **Wear goggles during maintenance.**
- **Keep away from children.**
- **It contains acid liquid.**
- **It is explosive.**
- **Read the user manual for details.**

The battery is located in the front compartment and designed to be maintenance free, so topping-up is unnecessary.

According to the current load condition and the status of the battery, the system may limit the power of some electrical appliances, please start the vehicle as soon as possible to charge the battery.



### Note:

*When the vehicle will not be used for an extended period, it is recommended that the battery negative terminal clamping pile head should be disconnected.*

*Make sure that the vehicle is powered off before connecting or disconnecting the negative battery cable.*

*When reconnecting the negative battery cable, ensure that the clamping pile head and the negative battery cable are properly secured.*

*When the vehicle will not be used for a long period of time without disconnecting the negative battery cable, it is recommended that the vehicle be driven or idled for more than half an hour per week to help prolong the life of the battery.*

### Battery Replacement



*The battery contains sulphuric acid, which is corrosive.*

Please contact a local MG Authorised Repairer to remove and install the battery. Only fit a replacement battery of

the same type and specification as the original to maintain the correct vehicle functionality.



Used batteries can be harmful to the environment, so they must be disposed of using an approved method and be recycled by a professional company. Please consult a local MG Authorised Repairer for more details.

## Bulb Replacement

### Bulb Specification

Bulb	Specification
Front Reading Lamp*	W5W 5W
High and low beams*	HB3 60W
Front Turn Signal Bulb	PY21W 21W
License Plate Lamp	W5W 5W
Rear Turn Signal Bulb	WY16W 16W
Reverse Lamp	W16W 16W
Rear Fog Lamp	H21W 21W

**Note:** Other light sources not listed are LED , which cannot be replaced separately.

## Bulb Replacement


Before replacing any bulb, turn off the vehicle's power supply to avoid any possibility of a short circuit.

**Note:** *The replacement bulb must be identical to the original one in type and specification.*

If the bulb glass is scratched or contaminated, it may cause the bulb to not concentrate the light. Take care NOT to touch the glass with your fingers; If necessary, clean the glass with methylated spirits to remove fingerprints.

For other bulbs not listed and to be replaced, ask an MG Authorised Repairer for guidance.

### Front Reading Lamp\*




- 1 Disconnect the negative terminal of the battery.
- 2 Use a small flat-bladed screwdriver to gently prise the lens from the light unit.
- 3 Pull the bulb from its mounting to remove.
- 4 Install the new bulb to the lamp holder.
- 5 Install the lens, locate the two prongs at the front of the lens and then carefully flex the lens to locate the two prongs at the rear of the lens into the lamp

assembly. Push the lens upwards until it 'clicks' into position

- 6 Connect the negative terminal of the battery.
- 7 Check front reading lamp operation.

### High and Low Beam\* and Front Turn Signal Bulb

- 1 Open the bonnet, refer to "Bonnet" in the "Maintenance" section.
- 2 Disconnect the negative terminal of the battery.
- 3 Rotate the high and low beam bulb cover 1 or front turn signal 2 counterclockwise to the appropriate position and remove the bulb cover.




- 4 Rotate the bulb assembly counterclockwise, disconnect the wiring harness connector, and remove the damaged high and low beam bulb.
- 5 Connect the wiring harness connector, position the new bulb assembly at the installation location, and rotate clockwise until it is fully secured.
- 6 Install the high and low beam bulb cover or front turn signal lights and rotate it clockwise to install it in place.
- 7 Connect the negative terminal of the battery and check if the high and low beam lights or front turn signal lights are working properly.
- 8 Close the bonnet, refer to "Bonnet" in the "Maintenance" section.



## Rear Fog Lamp


- 1 Disconnect the negative terminal of the battery and keep the vehicle stationary for at least 1 minute.
- 2 Use appropriate support equipment to safely lift and support the rear of the vehicle. Do not work under vehicles supported solely by scissor jacks or trolley level jacks.
- 3 Rotate the rear fog lamp socket counterclockwise, remove the socket, and remove the damaged rear fog lamp bulb.



- 4 Install the new light bulb onto the lamp holder.
- 5 Reinstall the lamp holder onto the rear fog lamp assembly and rotate clockwise until fully secured.
- 6 Connect the negative terminal of the battery.
- 7 Check if the rear fog lamp are working correctly.

### Reverse Lamp


- 1 Open the tailgate, refer to "Tailgate" in the "Preparations for trip" section.
- 2 Disconnect the negative terminal of the battery and keep the vehicle stationary for at least 1 minute.
- 3 Using a "one" screwdriver, pry open the right maintenance access cover of the tailgate interior panel to expose the reverse lamp socket.
- 4 Rotate the reverse lamp socket counterclockwise, remove the socket, and remove the damaged reverse lamp bulb.



- 5 Install the new light bulb onto the lamp holder.
- 6 Install the right maintenance access cover of the tailgate interior panel.
- 7 Connect the negative terminal of the battery.
- 8 Check if the reverse lamp is working correctly.
- 9 Close the tailgate.

## License Plate Lamp

- 1 Disconnect the negative terminal of the battery.
- 2 Gently push the license plate light from the left to the right using a pry blade.
- 3 Carefully pry down the license plate light using the pry tool.



- 4 Remove the damaged bulb and install a new one to the bulb holder.

- 5 When installing the license plate light, first fit the left side of the license plate light into the groove.
- 6 Push the right side of the license plate lamp upwards with your fingers and hear a "click" sound.
- 7 Connect the negative terminal of the battery.
- 8 Check if the rear license plate light is working correctly.


### IMPORTANT

Take extra care so as not to damage the paint surface and clips around the license plate light.

## Rear Turn Signal Bulb

- 1 Open the bonnet, refer to "Bonnet" in the "Maintenance" section.
- 2 Disconnect the negative terminal of the battery and keep the vehicle stationary for at least 1 minute.
- 3 Remove the taillight panel.
- 4 Remove the taillight assembly (side panel side).

- 5 Rotate the lamp holder counterclockwise and remove the bulb.



- 6 Install the new light bulb onto the lamp holder.
- 7 Reinstall the lamp holder onto the tail light assembly (side panel) and rotate clockwise until fully secured.
- 8 Connect the negative terminal of the battery.
- 9 Check if the rear fog lamp are working correctly.

## Washer

### Washer Fluid Check and Top Up




*Windscreen washer fluid is flammable. DO NOT allow windscreen washer fluid to come into contact with naked flames or sources of ignition.*



*When filling the washer fluid, do not let the washer fluid spill around the powertrain or on the paint surface of vehicle body. In case the washer fluid is spilled on hands or other parts of the body, please immediately wash with clean water.*

Check the washer fluid level regularly. When the level of washer fluid is low, please top up the washer fluid as instructed. Use the washer fluid recommended and certified by the manufacturer. Refer to 'Recommended Fluids and Capacities' in the 'Technical Data' section.




**Note:** *DO NOT use an anti-freeze or vinegar/water solution in the washer reservoir-anti-freeze will damage paintwork while vinegar will damage the washer pump.*

## IMPORTANT

- Use the washer fluid recommended and certified by the manufacturer. Misuse of washer fluid in winter may cause damage to the washer motor due to freezing.
- Operating on the washer switch when there is no washer fluid may cause damage to the washer motor.
- Operating the wipers when the windscreen is dry and there is no washer fluid may cause damage to the windscreen and wiper blades. Please spray the washer fluid and start the wipers when there is adequate washer fluid.

## Washer Nozzles

The windscreen washer nozzles are located on the A/C air intake grille panel in the front compartment, and is configured during the factory settings, so generally there are no need for adjustments. To adjust a washer nozzle, you can insert a small flat-bladed screwdriver in the gap (the black area indicated by the arrow) between the housing ( 1 ) and the nozzle ( 2 ) and turn the nozzle downward or upward slightly to obtain an appropriate ejection angle.



Operate the washer to spray water periodically to check if the washer nozzles are clean and in the correct direction. If the nozzle is obstructed, insert a needle or thin metal wire into the hole to remove the obstruction.


## Wipers

### Wiper Blades

#### IMPORTANT

- Grease, silicon and petroleum products impair the blade's wiping capability. Clean the wiper blades in warm soap water, and check their status periodically.
- Clean the windscreen frequently. DO NOT use wiper blades to remove stubborn or ingrained dirt, it will reduce their effect and their life span.
- If signs of hardness or cracking in the rubber are found, or if the wipers leave streaks or unwiped areas on the windscreen, then the wiper blades should be replaced.
- Clean the windscreen regularly with an approved glass cleaner and ensure the windscreen is thoroughly cleaned before the replacement of wiper blades.
- Only fit the wiper blades that are identical to the original specification.
- Clean ice and snow from the wipers and ensure they are not frozen or otherwise, sticking to the windscreen before attempting to operate them.


### Windscreen Wiper Blade Replacement



- 1 With the bonnet closed, and within 20 seconds of switching the ignition/vehicle power system to the OFF position, operate the wiper stalk switch by pressing down and releasing, the wipers will sweep and stop in the 'service position' on the windscreen.
- 2 Lift the wiper arm away from the windscreen.
- 3 Press the button on the wiper arm (as illustrated), and pull the upper end of the wiper blade outward to disengage from the wiper arm.
- 4 Unhook the blade from the wiper arm and discard.
- 5 Locate the new wiper into the slot of the wiper arm.
- 6 Push the wiper blade towards the wiper arm until the wiper blade is fully embedded.
- 7 Put the wiper assembly back onto the windscreen, and check whether the wiper blade is fixed correctly onto the wiper arm.
- 8 To exit the service mode and return the wipers to the park position, operate the wiper stalk switch again by pressing down and releasing, alternatively, switch the vehicle power system to the ON position.



## Rear Window Wiper Blade Replacement




- 1 Lift the wiper arm away from the rear window.
- 2 Rotate the wiper blade as shown in the figure, to remove it from the wiper arm and discard.
- 3 Put the fitting of the new wiper blade into the slot of the wiper arm. Ensure the wiper blade is properly secured on the wiper arm.
- 4 Place the wiper assembly back on the rear window.

### Replacing the Smart Key Battery

Please replace the smart key battery if you experience any of the following conditions:

- The smart key operational range is significantly reduced.
- The screen displays 'Remote Key Low Battery, Please Replace'.

#### Replacing the Smart Key Battery - Type A\*




- 1 Gently insert a suitable tool into the key removal hole ( A ).
- 2 Securely hold the key and pry the tool until the cover of the casing is partially separated.
- 3 Carefully separate the cover from the key, remove the waterproof pad ( B ), and take out the used battery from the slot ( C ).

**Note: Make sure that the polarity of battery is correct when installing a new battery.**

**Note: It is recommended to use a CR2032 battery for the remote control.**

- 4 Put the new battery in the slot, make sure it is in full contact with the slot and refit the waterproof pad.
- 5 Refit the cover and press tightly ( D ), ensure the gap around the cover is even.
- 6 Start the power system to resynchronise the key with the vehicle.

## Replacing the Smart Key Battery - Type B\*



- 1 Press the button ( A ) on the smart key to eject the decorative trim.
- 2 Remove the backup mechanical key ( B ) in the arrowed direction.
- 3 Remove the screw by using a cross flat headscrewdriver if there is a screw on your key (As shown in C2 ). This step only for Australian vehicles.

- 4 Using a suitable flat bladed tool, insert the tool into the side of the key ( C1 ), carefully prise off the battery cover and separate the upper and lower casings ( D ).

**Note: Make sure that the polarity of battery is correct when installing a new battery.**

**Note: It is recommended to use a CR2032 battery for the remote control.**

- 5 Remove the used battery from the slot.
- 6 Put the new battery in the slot, and make sure it is in full contact with the slot.
- 7 Refit the cover and press tightly, ensure the gap around the cover is even.
- 8 Use a cross flat head screwdriver to lock the screw if there is a screw on your key (As shown in C2 ). This step only for Australian vehicles.
- 9 Refit the mechanical key, and close the decorative trim.
- 10 Start the power system to resynchronise the key with the vehicle.

### IMPORTANT

- Use of an incorrect or inappropriate battery may damage the smart key. The new replacement's rated voltage, sizes and specifications must be the same as the old one.
- Incorrect fitting of the battery may damage the key.
- Disposal of the used battery must be strictly in accordance with relevant environmental protection acts.

## Tyres

tyres/wheels must always be fitted with indication arrow showing the correct 'DOR'.

### Overview

- Take extra care when using new tyres for the first 300 miles ( 500 km)
- Avoid excessive cornering at speed.
- Where possible, do not allow wheels to bump on/off kerbs, always take extra care when crossing kerbs/driveways.
- Regularly check tyres for damage (cuts, scratches, cracks and pits) and remove any foreign objects from the tread.
- Prevent the tyre from contacting oil, grease and fuel.
- Ensure valve caps are always fitted.
- If the tyre is to be removed always mark the tyre/wheel orientation to ensure correct re-installation.
- Wheels or tyres that have been disassembled should be kept in a cool, dry and light-free place.

### Directional Tyres

Directional tyres are marked with "direction of rotation" (DOR). To maintain handling characteristics, tyre performance, low road noise and extend tyre life,

## **Service Life of Tyres**

Correct tyre pressure and moderate driving styles can extend tyre life. Recommendations:

- Check the tyre pressures at least once a month when the tyre is cold;
- Avoid cornering at excessive speeds;
- Regularly check tyres for abnormal wear patterns.
- When the vehicle is to be parked for a long time, the vehicle should be moved at least once every two weeks to prevent permanent deformation of the tyres due to long-term stress.

The following factors affect the tyre life:

### ***Tyre Pressure***

Over or under-inflated tyres will cause the abnormal wear of the tyre, greatly shorten the service life, and have an adverse effect on the driving characteristics of the vehicle.

### ***Driving Style***

Excessively harsh acceleration and braking whilst cornering will reduce tyre life.

### ***Wheel Balance***

The wheels of a new vehicle are subject to dynamic balance testing, but out-of-balance wheels may still be caused due to the effects of various factors in operation.

If wheels are out of balance, shaking or vibration of the steering mechanism may occur and the tyres may start to wear excessively. It is important to restore wheel balance as quick as possible. Each wheel should be rebalanced after installing a new tyre or having a tyre repair.

### ***Wheel Alignment Defect***

Incorrect wheel alignment can cause excessive tyre wear and affect vehicle safety. If the tyres show signs of abnormal wear, check the wheel alignment and seek advice from an MG Authorised repairer.

## Caring for Your Tyres



**USE OF DEFECTIVE TYRES ARE DANGEROUS! DO NOT drive if any tyre is damaged, excessively worn, or inflated to an incorrect pressure.**



**When replacing tyres it is strongly recommended that the new tyres are of the same specification as the original tyres. DO NOT replace the tyres with tyres of any other type. Alternative tyres, of a different specification, may adversely affect the vehicle's driving characteristics and safety. In order to maintain driving characteristics and safety, it is suggested that you consult an MG Authorised Repairer.**

Always drive with consideration for the condition of the tyres, and regularly inspect the tread and side walls for any sign of distortion (bulges), cuts or wear.

**Note: Prevent tyres from coming into contact with oil, grease and fuel.**

## Tyre Pressure



**Before a long distance journey, the tyre pressure must be checked.**

Check the pressures at least every month, when the tyres are cold.

If it is necessary to check the tyres when they are warm, you should expect the pressures to have increased by 30 ~ 40 kPa (i.e. 0.3 ~ 0.4 bar). In this circumstance, NEVER let air out of the tyres in order to match the recommended pressures (cold) in the technical data.

## Valves

Keep the valve caps firmly secured to prevent dirt from entering the valve. Check the valve for leaks (listen for a tell-tale hissing) when you check the tyre pressure.


## Punctured Tyres

Your vehicle is fitted with tyres which may not leak if penetrated by a sharp object, provided the object remains in the tyre. If you are aware of this occurring, reduce speed immediately and drive with caution until the spare wheel can be fitted, or repairs undertaken.

**Note:** *If the sidewall of the tyre is damaged or distorted, replace the tyre immediately, do not attempt to repair it.*

### Tyre Wear Indicators

The tyres fitted as original equipment have about 2.0 mm-high wear indicators at their tread pattern bottom, vertical with the wheel rolling direction and evenly distributed around the circumference. The mark on the tyre side such as capital letters TWI or triangular symbol shows the location of wear indicator.



When the tread has worn down to 2.0 mm or below, the indicators will come to the surface of the tread pattern, producing the effect of a continuous band of rubber across the width of the tyre.

#### IMPORTANT

A tyre **MUST** be replaced as soon as a wear mark becomes visible. Otherwise there may be a risk of accidents.




## Wheel Fitment Rotation

It is recommended that you swap wheels at irregular intervals in order to equalise tyre wear.

When the tyres are worn seriously, it is recommended to swap the front and rear wheels as shown in illustration. This can prevent tyres from uneven wear, prolong the life span and balance tyre fatigue.

It is favorable to swap the driving wheels from front to rear and exchange non-driving wheels across.



**Note:** Directional tyres (identified from the arrow on the tyre side) **CANNOT** be swapped from side to side.

**Note:** TPMS self-learning is required after the wheel fitment rotation. Please consult an MG Authorised Repairer for details.

## Tyre/Snow Chains

Unsuitable tyre/snow chains may damage the tyres, wheels, suspension, brakes or bodywork of your vehicle.

Please pay attention to the following requirements in the usage:

- The tyre/snow chains can only be fitted on the front wheels;
- The thickness of tyre/snow chains must not exceed 7 mm;
- Please always observe the installation and tension instructions for the tyre/snow chains, as well as the speed limitations of different roads;
- Please avoid driving styles where heavy braking, sharp turns, etc are required with tyre/snow chains installed.
- If there are abnormal sounds during the use of tyre/snow chains, please park the vehicle in a safe area as soon as possible to check the chassis.
- Do not drive faster than 25 mph ( 40 km/h);
- To avoid the tyre damage and excessive wear of the tyre/snow chains, the tyre/snow chains must be removed while driving on the road without snow.

### Size and Specifications of Wheels and Tyres Supporting Tyre/Snow Chains for This Vehicle

Wheel Rim Size	6.5J×16
Tyre Size	215/60 R16 95H

**Note:** Please ensure the specifications of tyres and rims of the vehicle are the same as those listed in the above table prior to purchasing tyre/snow chains, otherwise tyre/snow chains cannot be fitted.

**Note:** If you often drive on snow covered and icy roads, it is recommended to use winter tyres. Please consult an MG Authorised Repairer for details.

## Cleaning and Caring



*Observe all safety precautions on cleaning products; Do Not drink fluids and keep them away from the eyes.*

## Exterior

### Washing Your Car



*In order to prevent accidents you should only clean your car when the power system is OFF.*



*Do not clean the front compartment with high pressure water since it may damage the electrical system of the vehicle.*



*Some high pressure cleaning systems will penetrate door, window and sunroof seals, and damage lock mechanisms. DO NOT aim water jets directly at components that might be easily damaged.*

In order to preserve the paint finish on your car, please observe the following care points:

- DO NOT use hot water to wash the car.
- DO NOT use detergents or washing up liquid.

- In hot weather, DO NOT wash the car in direct sunlight.
- When using a hose, DO NOT aim the water directly at window, door or sunroof seals, or through wheel apertures onto the brake components.

If the car is particularly dirty, use a hose to flush grime and grit from the bodywork, prior to washing. Then, wash the car using cold or lukewarm water containing a good quality wash and wax shampoo. Always use plenty of water to ensure that grit is flushed from the surface and not ground into the paintwork. After washing, rinse the bodywork with clean water and dry off with a chamois leather.

**Note:** *It is recommended that the camera is to be protected whilst the vehicle is being washed to avoid damage to the surface of the vehicle and the camera from car wash equipment, brushes or or hard objects such as small stones that may be contained therein.*

### Cleaning the underside



*Do not clean the front compartment with high pressure water since it may damage the electrical system of the vehicle.*

From time to time, but particularly during winter months when salt has been used on the roads, use a hose to wash the underside of the car. Flush away accumulations of mud

and thoroughly clean those areas where debris can easily collect (wheel arches and panel seams, for example).

### IMPORTANT

- Avoid cleaning the vehicle in direct sunlight.
- When cleaning the vehicle in winter avoid spraying water directly onto door locks and panel gaps due to risk of icing.
- Do not use rough sponges or cloth to clean the car, this will damage the paintwork finish.
- When cleaning the headlamps do not use a dry cloth or sponge, use only warm soapy water.

### ***Cleaning with High Pressure Cleaner***

Always read the manufacturers operating instructions.

When using high pressure washers, always ensure there is adequate distance between the spray nozzle and any soft materials, decals or rubber seals.

**Note:** *DO NOT direct the pressure washer nozzle directly toward the high voltage components or high voltage connections.*

### IMPORTANT

- Please pay attention to the operating instructions of high pressure cleaner.
- Soft parts on the vehicle should be kept in a large enough distance from the high pressure cleaner.

### **Polishing the Paintwork**

Occasionally treat the paint surface with an approved polish containing the following properties:

- Very mild abrasives to remove surface contamination without removing or damaging the paint.
- Filling compounds that will fill scratches and reduce their visibility.
- Wax to provide a protective coating between the paint and the elements.

**Note:** *If possible, avoid applying polish or wax products to window glass and rubber seals.*

### **Matte paint**

Matte paint is a special kind of coating, and special care should be taken when washing cars and caring for them.

It is recommended to wash the car by hand and do not use a rough sponge or car wash cloth. When cleaning and wiping, do not use excessive force. Avoid washing your car in direct sunlight.

- Do not use a high pressure water jet or steam to clean the vehicle. If the vehicle is quite dirty, it is necessary to pre-clean the car before washing it. Clean the body dust and other particles that may damage the paint surface first.
- Spray the body with plenty of clean water and dry the body after washing it from the roof downwards using a soft sponge and neutral wax-free car wash solution.

During the daily care of your car, attention shall also be paid to:

- If the paint film comes into contact with resin or grease, as well as insect residue or bird excrement, remove it immediately to avoid irreversible damage to the matte paint surface.
- If there are oil stains or fingerprints on the matte paint surface, remove them immediately with a clean cloth, do not use excessive force to avoid irreversible damage to the matte paint surface.

- In order to maintain the matte effect of the paint surface, abrasives, polishes and polishing waxes cannot be used, and the body cannot be polished.
- Do not use any stickers, patches, magnets or similar to prevent damage to the paint surface.
- Be sure to repair the paint film in a qualified professional repair workshop.

### Wiper Blades

Wash in warm soapy water. DO NOT use spirit or solvent based cleaners.

### Windows and Mirrors

Regularly clean all windows, inside and out, using an approved glass cleaner.

**Windscreen:** In particular, clean the outside of the screen with glass cleaner after washing the car with wash and wax products, and before fitting new wiper blades.

**Rear screen:** Clean the inside with a soft cloth, using a side to side motion to avoid damaging the heating elements.

**Mirrors:** Wash with soapy water. Use a plastic scraper to remove ice. DO NOT use abrasive cleaning compounds or metal scraper.

## Plastic Components

Any plastic components should be cleaned using conventional cleaning methods and not be treated with abrasive materials.

## Paint Damage

Any paint damage or stonechips should be treated with suitable paint/lacquer materials immediately to avoid invalidating the Anti Corrosion Warranty.

## Weather Strips

Any weather strips or rubber aperture seals should be treated with suitable materials (silica gel) if they are cleaned using strong detergents, this should avoid any sticking and maintain the service life of the seal.

## Wheels



***When cleaning the wheels any materials or water that contact the brake.***

In order to ensure the wheels are kept in optimum condition they should be cleaned regularly.

Only use a recommended non-acidic propriety wheel cleaner. Always read the instructions on the product.

## Cleaning the Interior

### Condenser, radiator and cooling fan

During daily driving, the condenser, radiator and cooling fan of the vehicle may accumulate some dirt, leading to deviations in the air conditioning system, cooling system, and vehicle noise. Please pay attention to daily maintenance and cleaning. If there is dirt, please rinse with water or wipe with a cloth. Be careful not to damage the fins of the condenser, radiator and cooling fan blades.

### Air conditioning cleaning

During daily use of car air conditioning, some dirt may accumulate inside the air conditioning system, which can affect its normal operation. Therefore, it is necessary to clean the interior of the air conditioning system. It is recommended to go to an authorized after-sales service center and have a professional handle the operation.

The air conditioner shall be cleaned in the form of spray to avoid the vehicle failure caused by liquid such as detergent flowing into the on-board electrical appliances.

### Plastic materials

Clean plastic-faced materials with diluted upholstery cleaner then wipe with a damp cloth.

**Note: DO NOT polish dashboard components – these should remain non-reflective.**

### Carpet and fabrics

Clean with diluted upholstery cleaner - test a concealed area first.

### Leather

Clean leather trim with warm water and a non-detergent soap. Dry and polish the leather with a dry, clean, lint-free cloth.

**Note: DO NOT use petrol, detergents, furniture creams or polishes as cleaning agents.**

### Instrument Pack, Infotainment Display

Clean with a dry cloth only. DO NOT use cleaning fluids or sprays.

## Airbag Module Covers



***DO NOT allow these areas to be flooded with liquid and DO NOT use petrol, detergent, furniture cream or polishes.***

To protect damage to the airbag SRS, the following areas should be cleaned sparingly with a damp cloth and upholstery cleaner ONLY:

- Steering wheel centre pad.
- Area of dashboard containing the passenger airbag.
- Area of roof lining and front pillar finishers which enclose the side head impact protection modules.

## Seat Belts



***DO NOT use bleaches, dyes or cleaning solvents on seat belts.***

Extend the belts, then use warm water and a non-detergent soap to clean. Allow the belts to dry naturally; DO NOT retract them or use the car until they are completely dry.





## **Technical Data**

---

<i>Technical Data Dimensions</i>	346
<i>Weights</i>	348
<i>Main Engine Parameters</i>	351
<i>Dynamic Performance Parameters</i>	353
<i>Parameters of Drive Motor*</i>	354
<i>Recommended Fluids and Capacities</i>	355
<i>Wheel Alignment (Unladen Condition)</i>	357
<i>Wheels and Tyres</i>	358
<i>Tyre Pressure (Cold)</i>	359

## Technical Data Dimensions



Item, unit	Parameter
Overall length A , mm	4430
Overall width B , mm	1818
Overall height C (unladen), mm	1635
Wheelbase D , mm	2610
Front overhang E , mm	960
Rear overhang F , mm	860

## TECHNICAL DATA

Item, unit	Parameter
Front wheel track, mm	1539
Rear wheel track, mm	1560
Minimum ground clearance (laden), mm	140
Minimum turning circle diameter, m	10.64
Fuel tank capacity, L	41 / 55


**Note:** *Vehicle length not including the license plate.*

**Note:** *Rearview mirrors and the deformed portion of tyre wall directly above the touchdown point are not included in the total width.*

**Weights**

Item, unit	Parameter
Person in cab, person	5
Unladen vehicle weight (kerb), kg	1380 / 1410 / 1420 / 1198 / 1220 / 1255 / 1330 / 1370 / 1295 / 1390
Gross vehicle weight, kg	1830 / 1880 / 1890 / 1745 / 1780 / 1840 / 1631 / 1653 / 1688 / 1823 / 1728
Unladen front axle weight, kg	862 / 881 / 887 / 800 / 821 / 858 / 725 / 738 / 775 / 846
Unladen rear axle weight, kg	518 / 529 / 533 / 495 / 509 / 532 / 473 / 482 / 480 / 524
Laden front axle weight, kg	975 / 1003 / 1010 / 912 / 934 / 971 / 831 / 844 / 881 / 906 / 962
Laden rear axle weight, kg	855 / 877 / 880 / 833 / 846 / 869 / 877 / 800 / 809 / 807 / 822 / 861

## Towing Weights



Item, Units	Parameters
Towing limit unbraked, kg	500
Towing limit braked, kg	500
Towing hitch load, kg	50

## TECHNICAL DATA

Item, Units	Parameters
Wheel centre to centre of tow ball A , mm	942
Towing device mounting points	B

**Note:** *When towing a trailer, the vehicle speed MUST not exceed 62 mile/h( 100 km/h).*

**Note:** *Prior to towing a trailer, please check the rear tyre pressures, inflate to at least 20 kPa ( 0.2 bar) above the recommended pressure - DO NOT allow the tyre pressure to exceed 300 kPa ( 3.0 bar), this can be dangerous.*

## Main Engine Parameters

Item, unit	Parameter			
Engine	1.5T	1.5L PFI	1.5L GDI	1.5L HEV
Bore × Stroke, mm × mm	73.5×88.1	73.5×88.1	73.5×88.1	72×92
Total displacement, L	1.496	1.495	1.495	1.498
Compression ratio	10.5±0.4	11.6±0.4	12.2±0.4	16.0±0.5
Maximum net power, kw	125	81	85	75
Engine speed at maximum power, rev/min	5500	6000	6000	6000
Maximum torque, Nm	275 (South Africa, ADR)	142 (South Africa) 140 (ADR)	148 (UK)	128 (UK)

## TECHNICAL DATA

Engine speed at maximum torque, rev/min	3000~4000	4500	4500	4500
Fuel grade , RON	RON 95# unleaded petrol and above (South Africa, ADR)	RON 92# unleaded petrol and above (South Africa) RON 91# unleaded petrol and above (ADR)	Unleaded gasoline RON 95 and above or gasohol E5-E10 (UK)	RON 95# unleaded petrol and above(ADR) Unleaded gasoline RON 95 and above or gasohol E5-E10(UK)



## Dynamic Performance Parameters

Item, unit	Parameter					
	GS62H HT II	GS64 CVT	GS64 MT	GS61 CVT	GS62 MT	GS62 CVT
Maximum speed, km/h	168	170	179	185	180	176
Gradeability, %	30					

**Note:** The dynamic performance parameters are test data under specific conditions.

**Note:** Gradeability is affected by different road surfaces, tyre pressures, tyre tread depth and vehicle load.

## TECHNICAL DATA

### Parameters of Drive Motor\*

Item	Front drive motor
Motor type	Permanent magnet synchronous motor
Rated Power/Peak Power, kW	TM:50/100 GM:45/60
Rated Torque/Peak Torque, Nm	TM:250 GM:140
Rated Speed/Maximum Speed, rpm	TM:5026/13000 GM:7162/13000
Protection Grade	IP67

**Recommended Fluids and Capacities**

Name	Grade	Capacity
Engine oil (after-sales replacement), L	C5&SP 0W-20	4
Engine coolant, L	Glycol (OAT)	6.2 ( 1.5L MT&CVT )
		6.4 ( 1.5L HEV )
		7 ( 1.5T CVT )
		3 ( 1.5T CVT )
		3.4 ( 1.5L HEV )
Engine Intercooler Coolant, L		
Drive motor coolant, L		
Hybrid transmission oil, L	Castrol BOT794	1.5
Manual transmission oil (MT), L	Castrol BOT503	1.8
Auto transmission oil (CVT) , L	Shell SL-2100	6.86
Brake fluid, L	DOT 4	0.85
Washer fluid, L	Original MG Motor windscreen washer fluid	2.5

## TECHNICAL DATA

Name	Grade	Capacity
Air conditioning refrigerant	R-134a*	520±20 g
	R-1234yf*	0.52±0.02 kg
	HFC-1234yf* contains fluorinated greenhouse gases	0.52±0.02 kg
		GWP 0.501
		CO <sub>2</sub> eq 0.0003t

## Wheel Alignment (Unladen Condition)

Item, unit		Parameters
Front Wheels	Camber Angle	-27 $\pm$ 45'
	Castor Angle	5°53 $\pm$ 45'
	Toe-in Angle (total toe-in)	6 $\pm$ 12'
	King Pin Inclination	13°13 $\pm$ 45'
Rear Wheels	Camber Angle	-1°25 $\pm$ 45'
	Toe-in Angle (total toe-in)	12 $\pm$ 20'

## TECHNICAL DATA

### Wheels and Tyres

Wheel Rim Size	6.5J×16	7.0J×17	7.0J×18
Tyre Size	215/60 R16 95H	215/55 R17 94V 215/55 R17 98V	215/50 R18 92V 215/50 R18 96V
Spare Wheel*	Wheel Rim Size	4B×16	
	Tyre Size	T125/90R16 98M	

### Tyre Pressure (Cold)

Wheels	All Conditions
Front Wheels	250kPa/2.5bar/37psi
Rear Wheels	250kPa/2.5bar/37psi
Spare Wheel*	420kPa/4.2bar/60psi